

Always report or correct any conditions that may result in injury to personnel if operation is to be continued.

Before starting the engine or operating any of the crusher components, see that no loose bars, tools, or parts are laying in or on any part of the equipment, as they could cause serious damage to the equipment or bodily injury to personnel.

Before attempting to operate the equipment, make certain the roll crusher and the sources of power are properly grounded. Death by electrocution could result from improperly grounded equipment.

Never fill the fuel tank while the engine is running. Be sure there are no open flames which may ignite the fuel vapor while filling the tank. Always provide a metal-to-metal contact between the fuel container and the fuel tank to avoid igniting the fuel vapors with a static spark.

Keep catwalks and decks free of grease, oil, and mud to prevent slipping and falling.

When operating the crusher in an inclosed area, exhaust gases must be piped to the outside. The exhaust gases contain carbon monoxide which can be fatal if inhaled.

When servicing batteries, do not smoke or use open flame in the vicinity. Batteries generate hydrogen, a highly explosive gas.

Do not operate the crusher with belt guards removed.

Make certain that all personnel are clear of the crusher before engaging the clutch or starting any of the components. Serious injury or death could result.

DURING OPERATION

Always report or correct any conditions that may result in injury to personnel if operation is to be continued.

Do not continue operation of the equipment unless the roll crusher and the source of power are properly grounded. Death by electrocution could result from improperly grounded equipment.

Keep catwalks and decks free of grease, oil, ice and mud to prevent slipping and falling. Use handrails to avoid falling from the crusher or into machinery.

Keep clear of moving machinery at all times to prevent bodily injury.

Stop operation when cleaning, adjusting, or lubricating the components of the roll crusher.

Use extreme caution in removing the radiator cap from an over-heated engine.

Never fill the fuel tank while the engine is running. Be sure there are no open flames which may ignite the fuel vapor while filling the tank. Always provide a metal-to-metal contact between the fuel container and the fuel tank to avoid igniting the fuel vapors with a static spark.

Ether is highly explosive and toxic. Handle ether capsules with extreme caution to prevent rupture until installed in the capsule chamber to avoid fire, explosion, and personal injury.

AFTER OPERATION

Always report or correct any condition that may result in injury to personnel if operation is to be continued.

Stop operation when cleaning, adjusting, or lubricating the components of the roll crusher

RANGE }
p. 3 }

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D.C., 12 September 1964

Operator's Manual

CRUSHER, ROLL: DIESEL AND ELECTRIC DRIVEN;

WHEEL MOUNTED, PNEUMATIC TIRES; 75 TON PER HOUR

(EAGLE CRUSHER MODEL 5230B) FSN 3820-788-5999

(EAGLE CRUSHER MODEL 5230D) FSN 3820-876-7876

COMPONENT OF CRUSHING AND SCREENING PLANT,

DIESEL AND ELECTRIC DRIVEN; WHEEL MOUNTED

75 TON PER HOUR

TM 5-3820-205-10/1, 24 January 1964, is changed as follows:

The title is changed as shown above.

Page 2. In paragraph 1a, line 3, after "5230B," add "Model 5230D."

Paragraph 1d is superseded as follows:


d. The reporting of errors, omissions, and commendations for improving this publication by the individual user is encouraged. Re-

MPP, 4300 Goodfellow Boulevard, St. Louis, MO 63120.

Paragraph 2 is superseded as follows:

2. Forms and Records

DA forms and procedures used for equipment maintenance will be only those prescribed in TM 38-750, Army Equipment Record Procedures.



SHIPPING DIMENSIONS

| | |
|--------|---------------|
| LENGTH | 495 IN. |
| WIDTH | 118 IN. |
| HEIGHT | 146 IN. |
| WEIGHT | 61,450 LBS. |
| CUBAGE | 4,935 CU. FT. |

ME 3820-205-10/1/

Figure 1.1. Roll crusher—left rear, three-quarter view (Model 5230D).

Page 5. In paragraph 4b (1), line 2, after "5230B," add "and 5230D."

Page 6. In paragraph 4b (2), line 2, after "85," add (Model 5230B) and 6009-P (Model 5230D)."

In paragraph 4b (5), line 2, after "4517," add (Model 5230B) and 4517A (Model 5230D)."

In paragraph 4b (6), line 2, after "4601," add (Model 5230B) and 4601B Model 5230D)."

In paragraph 4b (7), line 2, after "5031," add "(Model 5230B) and 5031A (Model 5230D)."

In paragraph 4b (8), line 2, after "3028," add "(Model 5230B) and 4715 (Model 5230D)."

In paragraph 4b (10), line 2, after "5930," add "(Model 5230B) and 5930-B (Model 5230D)."

Page 7. Paragraph 4b (21) is superseded by the following:

(21) Dimensions and weights.

| Model | 5230B | 5230D |
|-------------------|---|---|
| Overall length | 495 in. | 495 in. |
| Overall width | 120 in. | 118 in. |
| Overall heights | 143 in. | 146 in. |
| Weight | 59,500 lb. | 61,450 lb. |
| Volume | 4,944 cu. ft. | 4,935 cu. ft. |
| Center of gravity | 72 in. above ground level, 89 in. forward between center of bogie wheels. | 74 in. above ground level, 87 in. forward between center of bogie wheels. |

Table 1. Maintenance and operating supplies

| (1) Component application | (2) Federal stock number | (3) Description | (4) Quantity required for initial operation | (5) Quantity required for 8 hrs operation | (6) Notes |
|---------------------------------------|--------------------------------|---|---|---|--|
| CRANKCASE | | OIL, LUBRICATING: 55-gal. drum as fol- lows: | | | (1) Includes quantity of to fill engine oil tern as follows: |
| | 9150-265-9436 (2) | OE 30 | 24 qt. | (3) | |
| | 9150-265-9429 (2) | OE 10 | 24 qt. | (3) | Crankcase—18 q |
| | 9150-242-7604 (2) | OES | 24 qt. | (3) | Oil filter—6 qts |
| TANK, FUEL | | FUEL OIL, DIESEL: Bulk as follows: | | | (2) See C9100-IL for ad- ditional data and re- quisitioning procedu |
| | 9140-286-5283 (2) | DF-A | 100 gal (5) | 76 gal (6) | |
| | 9140-286-5286 (2) | DF-1 | 100 gal (5) | 76 gal (6) | (3) See LO 5-3820-205-2 |
| | 9140-286-5294 (2) | DF-2 | 100 gal (5) | 76 gal (6) | for grade applicat and replenishm intervals. |
| ENGINE START- ING AIDS. | 2910-355-6377 | CAPSULE, METAL: Pressure primed (1M0-10). | 1 (8) | | (4) Use oil as prescribed first item. |
| RADIATOR | | WATER: ANTIFREEZE: 55-gal. drum as follows: | | | (5) Tank capacity |
| | 6850-243-1990 | Ethylene glycol | | | (6) Average fuel consum- tion is 9.5 gals. |
| | 6850-174-1806 | Compound arctic | | | hour of continu operation. |
| GEAR ASSEMBLY, CONVEYOR DRIVE. | | OIL, LUBRICATING: (4) | 5 qt | (3) | (7) Quantity indicated the minimum quired for one ea Start when the te perature is bel 40° F. |
| RETURN CON- VEYOR GEAR REDUCER. | | OIL, LUBRICATING: (4) | 4 qt | (3) | |
| ELEVATING WHEEL GEAR REDUCER. | | OIL, LUBRICATING: (4) | 2 qt | (3) | |
| GEAR ASSEMBLY, FEEDER DRIVE. | | OIL, LUBRICATING: (4) | 2 qt | (3) | |
| CRUSHER FRAMES | | OIL, LUBRICATING, GEAR: 55-gal. drums as follows: | | | |
| | 9150-577-5848 | GO 140 | 92 qt | (3) | |
| | 9150-577-5845 | GO 90 | 92 qt | (3) | |
| | 9150-257-5443 | GOS | 92 qt | (3) | |
| GREASE POINTS | | GREASE, AUTOMO- TIVE AND ARCTIC | | | |




Figure 11.1. Actuating the roll crusher electrical system (model 5230D).

BATTERY-GENERATOR INDICATOR:
REGISTERS CONDITION OF BATTERY.

TACHOMETER-HOUR-METER:
RECORDS ENGINE RPM AND
RUNNING TIME.

**HIGH COOLANT
TEMPERATURE
WARNING LIGHT**

**LOW LUBRICATING
OIL PRESSURE
WARNING LIGHT**

TEMPERATURE GAGE:
REGISTERS COOLANT
TEMPERATURE.

OIL PRESSURE GAGE:
REGISTERS ENGINE
OIL PRESSURE.

AIR CLEANER INDICATOR:
INDICATES CONDITION OF
FILTER.


**RED SIGNAL
EXPOSED MEANS
FILTER SERVICE
IS NECESSARY.**

IGNITION SWITCH:
CONTROLS STARTING
AND STOPPING OF
ENGINE.

**THROTTLE LEVER: CONTROLS
ENGINE SPEED. STOP POSITION**

**ETHER STARTING
AID (2): FOR COLD
WEATHER STARTING.**

**CLUTCH LEVER: ENGAGES
OR DISENGAGES CLUTCH.**



ELECTRICAL SYSTEM FROM OVERLOADS. FACT
MUST BE IN THE "ON" POSITION FOR OPERATION





Figure 12.1 (4). Controls and instruments (model 5230D).

CAUTION: DO NOT CRANK THE ENGINE FOR MORE THAN 30 SECONDS AT A TIME. ALLOW ONE MINUTE BETWEEN ATTEMPTS IF ENGINE FAILS TO START.

1. DISENGAGE THE CLUTCH AND MOVE THE THROTTLE LEVER TO 1/4 OPEN.
2. TURN IGNITION SWITCH TO "ON" POSITION, PRESS STARTER BUTTON (RELEASE IMMEDIATELY WHEN ENGINE STARTS). (SEE NOTE.)
3. MOVE THROTTLE LEVER TO "RUN" POSITION.
4. RUN ENGINE AT 1,100 RPM UNTIL OPERATING TEMPERATURE IS REACHED BEFORE APPLYING LOAD.
5. OBSERVE ALL INSTRUMENTS AND GAGES FOR PROPER OPERATING RANGE.



CAUTION: STOP ENGINE IF IGNITION SWITCH FAILS TO RETURN TO "RUN" POSITION AFTER ENGINE STARTS. APPLY LOAD ONLY AFTER COMPLETE ENGINE WARMUP.

NOTE: UNITS OF EQUIPMENT WITHIN SERIAL NUMBER RANGE 6590 THRU 6629 ARE EQUIPPED WITH A DUAL IGNITION-STARTER SWITCH.

NORMAL READINGS

| | |
|-----------------------|-------------|
| ENGINE TEMPERATURE | 165-185° F. |
| BATT.-GEN. INDICATOR | GREEN RANGE |
| OIL PRESSURE | 55-65 PSI |
| TACHOMETER/HOUR METER | 1,340 RPM |




Figure 14.1. Stopping the engine (Model 5230D).

Page 55. Item 9, "is superseded by" "Check to see if red signal is visible." Check the pre-

cleaner and service it when the level approaches the arrow indicator on

JOH

REMOVE BATTERY FILL CAPS AND FILL EACH CELL WITH DISTILLED WATER TO 1/8 INCH ABOVE PLATES





Figure 27.1. Batteries service (Model 5230D).



DRAW PULL CATCH AND
POSITION CLAMP (4) SO BELT
GUARD CAN BE REMOVED.

REMOVE BELT GUARD

TROOP INSTALLED OR AUTHORIZED LIST

Section I. INTRODUCTION

I. Scope

This appendix lists basic issue items and items troop installed or authorized which accompany the crusher and are required by the crew/operator for operation, installation, or operator's maintenance.

I. General

This basic issue items and items troop installed or authorized list is divided into the following sections:

a. *Basic Issue Items List*—Section II. Not applicable.

b. *Items Troop Installed or Authorized List*—Section III. A list in alphabetical sequence of items which, at the discretion of the unit commander, may accompany the end item, but are not subject to be turned in with the end item.

3. Explanation of Columns

The following provides an explanation of columns in the tabular list of items troop installed or authorized, section III.

a. *Source, Maintenance, and Recoverability Code(s) (SMR)*: Not applicable.

b. *Federal Stock Number*. This column indicates the Federal stock number assigned to the item which will be used for requisitioning purposes.

c. *Description*. This column indicates the Federal item name and any additional description of the item required.

d. *Unit of Measure (U/M)*. A 2-character alphabetic abbreviation indicating amount or quantity of the item upon which the allowances are based; e.g., fit, ea, pr; etc.

e. *Quantity Authorized*. This column indicates the quantity of the item authorized to be used with the equipment.

Section III. ITEMS TROOP INSTALLED OR AUTHORIZED LIST

| (1) SMR code | (2) Federal stock number | (3) Description | (4) Unit of meas | (5) Qty au |
|--------------------|--------------------------------|--------------------|---------------------------|---------------|
| | 4210-555-8837 | EXTINGUISHER, FIRE | ea | 1 |

To be distributed in accordance with DA Form 12-25B, (qty rqr block No. 449)
Maintenance Requirements for Rock Drilling Equipment.

OPERATOR'S MANUAL

**CRUSHER, ROLL: DIESEL AND ELECTRIC DRIVEN; WHEEL MOUNTED, PNEUMATIC
TIRES; 75 TON PER HOUR (EAGLE CRUSHER MODEL 5230B) FSN 3820-788-599
COMPONENT OF CRUSHING AND SCREENING PLANT; DIESEL AND ELECTRIC
DRIVEN; WHEEL MOUNTED; 75 TON PER HOUR**

| | Paragraph |
|--|--------------|
| CHAPTER 1. INTRODUCTION | |
| Section I. General..... | 1, 2 |
| II. Description and data..... | 3-5 |
| CHAPTER 2. INSTALLATION AND OPERATION INSTRUCTIONS | |
| Section I. Service upon receipt of equipment..... | 6-9 |
| II. Controls and instruments..... | 10, 11 |
| III. Operation of equipment..... | 12-21 |
| IV. Operation of auxiliary materiel used in conjunction with the roll crusher..... | 22, 23 |
| CHAPTER 3. MAINTENANCE INSTRUCTIONS | |
| Section I. Operator's tools and equipment..... | 24, 25 |
| II. Lubrication..... | 26, 27 |
| III. Preventive maintenance services..... | 28, 29 |
| IV. Troubleshooting..... | 30-44 |
| V. Field expedient repairs..... | 45-49 |
| VI. Fuel system..... | 50-54 |
| VII. Cooling system..... | 55-57 |
| VIII. Engine electrical system..... | 58, 59 |
| IX. Airbrake system..... | 60, 61 |
| X. Engine clutch assembly..... | 62, 63 |
| XI. Roll crusher assembly..... | 64, 65 |
| XII. Vibrating screen assembly..... | 66-68 |
| XIII. Feeder assembly..... | 69, 70 |
| XIV. Rotary elevator assembly..... | 71, 72 |
| XV. Return (under) conveyor assembly..... | 73, 74 |
| XVI. Main (feed) conveyor assembly..... | 75, 76 |
| CHAPTER 4. DEMOLITION OF THE ROLL CRUSHER TO PREVENT ENEMY USE..... | 77-81 |

CHAPTER I

INTRODUCTION

Section I. GENERAL

1. Scope

a. These instructions are published for the use of the personnel to whom the Roll Crusher, Eagle Crusher Model 5230B is issued. They provide information on the operation, lubrication, and preventive maintenance services of the equipment, accessories, components, and attachments.

b. Appendix I contains a list of publications applicable to this manual. Appendix II contains the basic issue items authorized for use by the operator. The maintenance allocation chart is located in TM 5-3820-205-20/1-1.

c. Numbers in parentheses on illustrations indicate quantity. Numbers preceding nomenclature callouts on illustrations indicate the preferred maintenance sequence.

d. The direct reporting by the individual user, of errors, omissions, and recommenda-

tions for improving this manual is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Technical Manual Parts or Supply Manual 7, 8, or 9) will be used for reporting these improvements. This form must be completed in triplicate using pencil or typewriter. The original and one copy must be forwarded direct to the Commanding General, U. S. Army Mobility Support Center, 1000 SMOMS-MM, P. O. Box 119, Columbus, GA 31906. One information copy will be provided to the individual's immediate supervisor, officer, noncommissioned officer, or sergeant (etc.).

2. Record and Report Forms

For record and report forms applicable to the operator, refer to TM 38-750.


Note. Applicable forms, excluding standard forms which is carried by the operator, will be kept in a bag mounted on the equipment.

Section II. DESCRIPTION AND DATA

3. Description


a. *Roll Crusher.* The Roll Crusher, Eagle Crusher Model 5230B (figs. 1 and 2) is a portable, self-contained unit used to crush and grade aggregate. A four cycle, six cylinder diesel engine operates the crusher roll assembly. Electric motors, driven by an extraneous power source, operate the vibrator screen assembly, return (under) conveyor, main (feed) conveyor, rotary elevator, and reciprocating feeder assembly. These components of the roll crusher, mounted on a trailer and dolly, are described in appropriate sections of this manual.


must be set up on firm level ground and as close to the source of material to be processed as possible, and in position so the conveyor can dispel the processed aggregate at the desired location for stock piling or hauling. Figure 1 illustrates a typical crushing and screening plant layout where the crusher may be used as a component. The positions of the various components as shown are not necessarily a standard one; only the relationship to each other is indicated. For example, only the feed charge conveyor is absolutely necessary for operation, the remaining three indicate




ENC 3020-200-10/1/1

Figure 1. Roll crusher, left rear, three-quarter view.





ROLL CRUSHER



DISCHARGE CONVEYOR

ROLL CRUSHER

4. Identification and Tabulated Data

a. *Identification.* The roll crusher has 15 major identification and instruction plates which are applicable to the operator.

- (1) *Corps of Engineers identification plate.* Located on the left of the main frame of the trailer, below the vibrating screen assembly. It gives the Federal stock number, model number, and dimensions.
- (2) *Engine manufacturer's identification and data plate.* Located on the left side of the engine block, behind the fuel injection pump. It gives the manufacturer, model, and tappet clearance.
- (3) *Clutch identification and instruction plate.* Located on the clutch housing inspection hole. It gives the adjustment and lubrication data.
- (4) *Transportation data plate.* Located on the left of the main frame of the trailer, below the vibrating screen assembly. It gives overall length, width, height, and center of gravity.
- (5) *Feeder, return (under) conveyor, and rotary elevator motor identification plates.* Provides manufacturer, model, horsepower, amps (amperes), volts, and rpm (revolutions per minute). The plates are identical and are located on the motor housing.
- (6) *Secondary trailer identification plate.* Provides the manufacturer and serial number. It is located on the left of the main frame of the trailer.
- (7) *Dolly identification plate.* Provides the manufacturer, model, and serial number. It is located on the front of the dolly frame below the fifth wheel.
- (8) *Vibrating screen identification plate.*

vibrating screen motor housing.

- (10) *Main (feed) conveyor motor identification plate.* Provides the manufacturer, model, and serial number, amps, volts, and cycles. It is located on the conveyor motor housing.
- (11) *Main (feed) conveyor gear reducer identification plate.* Provides the manufacturer, class, horsepower, and ratio. It is located on the gear reducer housing.
- (12) *Rotary elevator and return conveyor gear reducer identification plate.* Provides the manufacturer, class, horsepower, and ratio. It is located on the rotary elevator gear reducer housing.
- (13) *Feeder gear reducer identification plate.* Provides the manufacturer, class, horsepower, and ratio. It is located on the feeder gear reducer housing.
- (14) *Main control panel identification data plate.* Provides the manufacturer, volts, phase, cycles, and serial number. It is located inside the main control panel on the upper left-hand side.
- (15) *Main control panel caution plate.* Provides the manufacturer, volts, phase, cycles, and serial number. It is located on the outside of the main control panel door. It states the safe ground rod and lead should be installed at the power source before using the receptacles.

b. Tabulated Data.

(1) General.

| | |
|--------------------------|---------------------------|
| Manufacturer..... | Eagle Crusher Co. |
| Model..... | 5230B |
| Type..... | Roll Crusher |
| Plant unit function..... | Secondary |
| Tire pressure..... | 100 psi (pounds per inch) |

Type.....Diesel
 Cycle.....4
 Number of cylinders.....6
 Rated horsepower.....144 hp (horsepower) at
 1,400 rpm
 Oil pressure.....55-65 psi
 Brake horsepower.....202 hp at 1,400 rpm
 Cooling system:
 Type.....Liquid
 Temperature range.....165° to 185° F. (degrees)
 (Fahrenheit)

Electrical system:

 Operating voltage.....24 v (volts)
 Number of batteries.....4 (series parallel
 connected)
 Type of batteries.....Storage, 12-v, 6-cell (type
 designation 6TN).
 Type of ground.....Negative
 Air cleaner-type.....Dry
 Clutch-type.....Friction, dry, positive-
 action

(3) Roll crusher assembly.

Manufacturer.....Eagle Crusher Co., Inc.
 Model.....24 x 30
 Size of discharge opening.....¼ to 3 in. (inches)
 Speed in rpm—rolls.....87-90
 Ratio of reduction.....3.38 to 1

(4) Vibrating screen assembly.

Manufacturer.....Allis-Chalmers Manufac-
 turing Co.
 Model.....S
 Type.....Ripl-flo
 Size.....4 x 10 DD
 Maximum speed.....900 rpm

(5) Reciprocating feeder.

Manufacturer.....Eagle Crusher Co., Inc.
 Model.....4517
 Capacity (24 in.).....175 tph (tons per hour)

(6) Rotary elevator.

Manufacturer.....Eagle Crusher Co., Inc.
 Model.....4601
 Size.....72 in. dia (diameter) x 24
 in. w (wide)

(7) Main (feed) conveyor.

Manufacturer.....Eagle Crusher Co., Inc.
 Model.....5031
 Capacity.....175 tph
 Belt width.....24 in.

(8) Return (under) conveyor.

Manufacturer.....Eagle Crusher Co., Inc.
 Model.....30288
 Capacity.....175 tph

Manufacturer.....General Electric
 Model.....5KG215BG202
 Type.....KG
 Horsepower.....5
 Revolutions per minute.....1,745
 Volt.....208-220/440
 Phase.....3
 Cycle.....60
 Amperes.....14.2/7.1
 Time rating.....Continuous

(12) Vibrating screen motor.

Manufacturer.....General Electric
 Model.....5KG4284B2
 Type.....KG
 Horsepower.....15
 Revolutions per minute.....1,755
 Volt.....208-220/440
 Phase.....3
 Cycle.....60
 Amperes.....40.8/20.4
 Time rating.....Continuous

(13) Main (feed) conveyor motor.

Manufacturer.....General Electric
 Model.....5KG4256B2
 Type.....KG
 Horsepower.....10
 Revolutions per minute.....1,745
 Volt.....208-220/440
 Phase.....3
 Cycle.....60
 Amperes.....27.4/13.7
 Time rating.....Continuous

(14) Main (feed) conveyor gear reducer.

Manufacturer.....General Electric
 Model.....7GT215FDONC
 Class.....1
 Horsepower.....16.9 hp at 1,750 rpm
 Ratio.....15:1
 Code.....XS

(15) Rotary elevator gear reducer.

Manufacturer.....General Electric
 Model.....7GT207FDONC
 Class.....1
 Horsepower.....11.1 hp at 1,750 rpm
 Ratio.....15:1
 Code.....WS

(16) Feeder gear reducer.

Manufacturer.....General Electric
 Model.....7GT207FDONC
 Class.....1
 Horsepower.....11.1 hp at 1,750 rpm

| | |
|--------------------------------|-------------------------------|
| aggregate sizes. | |
| crusher rolls aggregate sizes. | 3 in. to ¼ in. discharge size |
| conveyor belt width..... | 24 in. |

(19) Adjustment data.

| | |
|---|--|
| Defectors (hopper loaded) and belt scrappers. | Barely touch conveyor belt |
| Conveyor belt..... | Just enough to prevent slipping when loaded. |
| Generator belt..... | ¾ in. deflection midway between pulleys. |
| Electric motor drive belts..... | ½ in. deflection midway between pulleys. |
| Roll adjusting spring..... | 23 in. |

(20) Capacities.

| | |
|------------------------------------|-------------------|
| Fuel tank..... | 100 gal (gallons) |
| Crankcase..... | 18 qt (quarts) |
| Oil filters..... | 6 qt |
| Radiator..... | 70 qt |
| Gear assembly conveyor drive. | 5 qt |
| Return conveyor gear reducer. | 4 qt |
| Gear assembly, feeder drive. | 2 qt |
| Elevating wheel gear reducer. | 2 qt |
| Crusher frames (crusher gearcase). | 92 qt |

(21) Dimensions and weights.

| | |
|---------------------|---------|
| Overall length..... | 495 in. |
|---------------------|---------|

| | |
|------------------------|---|
| Center of gravity..... | 72 in. above ground level |
| | 89 in. forward between center of bogie wheels |

5. Difference in Models

This manual covers only the Eagle Model 5230B Roll Crusher, serial number ranges 6550 through 6587 and 6590 through 6629. Where differences exist between the two serial number ranges, each serial number range is covered separately in the applicable maintenance section of this manual. Units within serial number range 6590 through 6629 have two diesel engine air cleaners, units within serial number range 6550 through 6587 have one. Units within serial number range 6590 through 6629 have both coolant temperature and lubricating oil pressure warning lights, but the units within serial number range 6550 through 6587 do not. Units within serial number range 6590 through 6629 are equipped with a dual ignition-start switch, units within serial number range 6550 through 6587 are equipped with a separate switch for the ignition circuit and another switch for the starter energizing circuit.

CHAPTER 2

INSTALLATION AND OPERATION INSTRUCTIONS

Section I. SERVICE UPON RECEIPT OF EQUIPMENT

Unloading the Roll Crusher

The operator may assist in unloading the roll crusher from the common carrier. The operator may help remove the tie-down cables, strapping, lashing, and the like which secure the roll crusher on the carrier. Organizational Maintenance personnel will perform the remaining operations.

Inspecting and Servicing the Roll Crusher

Note. Make sure the roll crusher is completely de-energized before servicing. Make certain preservatives have been removed from the crankcase and fuel tanks.

1. Perform the preventive maintenance services listed in paragraph 29.

2. Make a complete visual inspection to see that the required tools, repair parts, publications, accessories, and attachments are with the crusher and are in serviceable condition.

3. Visually inspect the roll crusher for loss of parts or damage which may have occurred during loading, shipping, or unloading.

4. Report all damage and deficiencies to organizational maintenance.

Installation or Setting-Up Instructions

1. Locate the roll crusher on a flat or leveled surface. If necessary, use any suitable equipment such as a bulldozer to level the site. Plan the site so there will be no obstruction to trucks or other hauling vehicles going to and from the crusher. Refer to figure 3 for suggested placement of plant components. After the crusher is installed, level the area immediately under the

c. The crusher is equipped with four manual screw-type leveling jacks. Lower the leveling jacks (A, fig. 4) and position the jacks into the jack pad recess as instructed on B, figure 4. If the ground is soft or provides a poor bearing surface, place timbers or other suitable supports under the jack pads.

d. Level the trailer frame. Check in several places to avoid having a twist or sag in the frame. Adjust the jacks accordingly. Accuracy in leveling is very important, because an improperly leveled crusher unit may cause drive belts and conveyor belts to run off; material to travel to one side of screens; and roll mountings of the vibrating screen to twist.


e. Crib the roll crusher by raising the front end with the leveling jacks, keeping the crusher level, and build the cribbing solidly up to the frame. Screw the jacks back in a few turns, allowing the weight to rest on the cribbing. Crib under the rear end of the crusher frame in a similar manner.

Caution: Install the leveling jacks and cribbing so that roll crusher will be level lengthwise and crosswise, and the weight of the crusher is removed from the wheels and axles.


f. Install the drawbar jack as illustrated in figure 4, (on units of equipment within No. range 6590 through 6629.)


g. Position the discharge conveyor of the crushing and screening plant as illustrated in figure 3.

h. Install the ground rod as instructed





A





C





EMC 3820-205-10

Figure 5. Grounding the roll crusher.


jumper cable to the control panel, and connect the main power cable to the control panel and main power source as instructed on figure 8.

Warning: Make certain the roll crusher and the source of power, are properly grounded be-

fore installing the short main power the power source.

k. Connect the feeder jumper cable to the feeder motor as instructed on figure 9.

l. Install the feeder relief chute exte



ENC 3820-205-10/1 7

Figure 6. Main power cable installed on reel.


the feeder relief chute as instructed on figure 10.

m. Open the main control panel door and push the circuit breakers to the ON position as instructed on figure 11.

9. Movement to a New Worksite

a. Remove all aggregate material from the conveyor belts, hoppers, and crusher.

b. Disconnect the main power cable and the short main power cable from the power source





TURN CRANK COUNTERCLOCKWISE.
REMOVE CABLE FROM REEL.

REMOVE WING NUT (2)
AND 'U' BOLT.

ADJUST BRAKE
WHEEL TO PREVENT
REEL FROM SPINNING.
RELEASE LOCK.

REMOVE SEAL (2).





INSTALL CAP
SCREW (4).

FEEDER RELIEF CHUTE

FEEDER RELIEF
CHUTE EXTENSION




Figure 11. Actuating the roll crusher electrical system.

stow the extension in reverse of the instructions on figure 10.

l. Tow the roll crusher a maximum of 20 miles per hour over-the-road or 10 miles per hour maximum cross-country to the new work-site.

Note. Refer to figure 1 and dimensions, weights, and tire p

Caution: Make certain attached and secure before

m. Install and set up tl
8).

FOOTBY ELEVATOR
CIRCUIT BREAKER

MAIN (UNDER) CONVEYOR
CIRCUIT BREAKER

SIDE CONVEYOR NO. 2
CIRCUIT BREAKER

SIDE CONVEYOR NO. 1
CIRCUIT BREAKER

FEEDER CIRCUIT BREAKER

MAIN (FEED) CONVEYOR CIRCUIT BREAKER

VIBRATING SCREEN CIRCUIT BREAKER

NOTE: SET ALL CIRCUIT BREAKERS
IN THE "ON" POSITION BEFORE
OPERATING THE ROLL CRUSHER.
CLOSE PANEL DOOR.

10. General

This section describes, locates, illustrates, and furnishes the operator or crew sufficient information about the various controls and instruments for proper operation of the roll crusher.

11. Controls and Instruments

The purpose, location, and use of the con-


trols, and normal readings of the controls, and gages are illustrated on figure

Caution: Operator's switch box properly closed and sealed to prevent from entering the box and causing controls to corrode and become unusable. All control boxes should be examined that doors are properly sealed and closed.




FUEL GAGE: REGISTERS
LEVEL OF FUEL IN FUEL
TANK.

FUEL SHUTOFF VALVE: CONTROLS
FLOW OF FUEL FROM THE FUEL TANK.



A

B



FUEL HAND PRIMER: PRIMES
LOW PRESSURE FUEL SYSTEM
AND PURGES FILTER OF AIR.

BATTERY-GENERATOR INDICATOR:
REGISTERS CONDITION OF BATTERY.

TEMPERATURE GAGE:
REGISTERS COOLANT
TEMPERATURE.

OIL PRESSURE GAGE:
REGISTERS ENGINE
OIL PRESSURE.

TACHOMETER-HOUR-METER:
RECORDS ENGINE RPM AND
RUNNING TIME.

FILTER CLEANER INDICATOR:
INDICATES CONDITION OF
FILTER

THROTTLE LEVER
RUN POSITION.

IGNITION SWITCH:
CONTROLS STARTING
AND STOPPING OF
ENGINE.

RED SIGNAL:
EXPOSED MEANS
FILTER SERVICE
IS NECESSARY.

STARTER BUTTON:
USED TO START
ENGINE.

THROTTLE LEVER: CONTROL
ENGINE SPEED. STOP POSIT

RESET BUTTON:
UNLOCKS AND
LOWERS RED
SIGNAL.

**ETHER STARTING
AID (2):** FOR
COLD WEATHER
STARTING.

CLUTCH LEVER: ENGAGES
OR DISENGAGES CLUTCH.

ON UNITS OF EQUIPMENT WITHIN SERIAL NUMBER 6550 THROUGH 6587 ONLY.

D

MSC 3820-205-10/1/12

adjustment. Proper adjustment is 0.020 inch for intake valves and 0.024 inch for exhaust. (HOT)

20 CONTROLS AND INSTRUMENTS. Inspect for loose mounting, loose connections, and proper operation. Normal operating readings for instruments are as follows: Oil pressure gage - 55 to 65 psi, Water temperature gage - 165° to 185°F, Ammeter - green range, Tachometer - 1,400 rpm.

NOTE: OPERATIONAL TEST. During operation check for unusual noise or vibration, leaks, and proper operation.

Each trouble symptom stated is followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause. Any trouble beyond the scope of organizational maintenance shall be reported to field maintenance, 3d echelon.

22. Starter Fails to Crank Engine

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---------------------------------|--|
| Starter switch defective..... | Replace starter switch (par. 92). |
| Poor electrical connection..... | Clean and tighten battery cables and other electrical connections (par. 80). |
| Battery discharged | Replace batteries (par. 80). |
| Starter brushes worn..... | Replace starter brushes (par. 86). |
| Starter solenoid defective..... | Replace starter solenoid (par. 85). |

23. Engine Hard to Start or Fails to Start

| <i>Probable cause</i> | <i>Possible remedy</i> |
|----------------------------------|--|
| Battery charge low..... | Recharge or replace batteries (par. 80). |
| Fuel lines clogged | Clean fuel lines (par. 69). |
| Fuel injection pump defective. | Replace fuel pump. Report this condition to field maintenance, 3d echelon. |
| Fuel injectors dirty..... | Replace fuel injectors (par. 65). |
| Rocker arm clearance incorrect. | Adjust the rocker arms (par. 101). |
| Injection pump timing incorrect. | Time injection pump. Report this condition to field maintenance, 3d echelon. |
| Starter defective | Replace starter (par. 86). |
| Defective air cleaner..... | Repair air cleaner (par. 63). |
| Fuel tank valve closed..... | Open fuel tank valve. |

24. Engine Misses or Runs Erratically

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---------------------------------|--|
| Rocker arm clearance incorrect. | Adjust rocker arms (par. 101). |
| Fuel injectors defective..... | Replace fuel injectors (par. 65). |
| Fuel pump defective..... | Replace fuel pump. Report this condition to field maintenance, 3d echelon. |

Engine temperature too high (safety device operated).

Oil pressure low (safety switch operated).

Engine safety switch defective.

Overspeed governor defective.

Remove and test thermostats (par. 107). Replace defective thermostats (par. 107).

Inspect for and repair leaks in oil lines (par. 75).

Replace engine safety switch (par. 91).

Replace overspeed governor (par. 90).

26. Engine Overheats

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Thermostat defective | Replace thermostats (par. 107). |
| Fan belts worn and slipping on pulley. | Replace fan belts (par. 104). |
| Injection pump timing incorrect. | Time injection pump. Report this condition to field maintenance, 3d echelon. |
| Back pressure in exhaust system. | Inspect for restrictions in muffler and exhaust system (par. 77). |
| Defective water pump..... | Replace water pump (par. 105). |

27. Engine Lacks Power

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|---|
| Fuel injector defective..... | Replace fuel injectors (par. 65). |
| Fuel injection pump defective. | Replace injection pump. Report this condition to field maintenance, 3d echelon. |
| Restricted fuel supply or air in system. | Remove fuel line and clean (par. 69). Bleed fuel system (TM 5-3820-205-10/2). |

28. Engine Will Not Idle Smoothly

| <i>Probable cause</i> | <i>Possible remedy</i> |
|-----------------------------------|--|
| Rocker arm clearance incorrect. | Adjust rocker arms (par. 101). |
| Engine operating temperature low. | Replace defective thermostat (par. 107). |
| Defective fuel injectors..... | Replace fuel injectors (par. 65). |
| Fuel pump defective..... | Replace fuel pump. Report this condition to field maintenance, 3d echelon. |

| | |
|--|---|
| rocker arm clearance incorrect. | Adjust rocker arms (par. 101). |
| Worn main or connecting rod bearings. Loose piston pin. Broken piston or ring, loose or worn timing gears. | Replace as necessary. Report this condition to field maintenance, 3d echelon. |
| Injection pump timing incorrect. | Time fuel pump. Report this condition to field maintenance, 3d echelon. |

0. Engine Has Low or No Oil Pressure

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Oil pressure gage defective. | Replace gage (par. 87). |
| Oil pressure gage line clogged or broken. | Clean or replace oil line (par. 87). |
| Air in oil cooler bypass valve or broken spring. | Clean valve and replace spring if necessary (par. 72). |
| Oil too light or diluted. | Drain and replace with recommended grade lubricant. Refer to LO 5-3820-205-20/2. |

1. Exhaust Smoke Excessive

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Engine temperature low. | Replace thermostat (par. 106). |
| Fuel injectors defective. | Replace fuel injectors (par. 65). |
| Poor grade diesel fuel. | Drain fuel system and replace with proper grade fuel. |
| Worn or stuck rings, or worn valve guides and seals. | Replace as necessary. Report to field maintenance, 3d echelon. |
| Restriction in air supply. | Check and clean air cleaner (TM 5-3820-205-10/2). |

2. High Oil Consumption

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--------------------------------|---|
| Oil leaks. | Locate and repair leaks (par. 87). |
| Too high oil level maintained. | Check oil level and fill to indicated full mark on bayonet gage. |
| Incorrect grade of oil. | Refer to current lubrication order and fill with proper grade of oil. |

| | |
|--|--|
| Electrolyte level improper. | Adjust electrolyte to proper level with distilled water (par. 80). |
| Generator brushes worn or generator defective. | Replace generator brushes (par. 91). Test and replace generator (par. 83). |
| Generator regulator defective. | Test and replace generator regulator (par. 83). |
| Connections in wiring shorted or loose. | Check all wiring for short or loose connections (par. 83 and 84). |

34. Power Takeoff Clutch Slips or Grabs

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|---|
| Clutch out of adjustment. | Adjust clutch (TM 5-3820-10/2). |
| Worn clutch plate lining, broken throwout yoke or springs, oil soaked lining. Warped clutch plates. | Replace as necessary. Report this condition to field maintenance, 3d echelon. |

35. Discharge Conveyor Inoperative

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|--|
| Conveyor electric motor belts worn or broken. | Replace worn or broken belts (par. 129). |
| Drive sheave on conveyor motor or gear reducer defective. | Replace defective sheave (par. 159). |
| Defective gear reducer. | Replace defective gear reducer (par. 159). |
| Electric motor starting switch defective or defective wiring. | Replace electric motor starting switch (par. 129). Repair defective wiring (par. 129). |

36. Grooves or Cuts Appearing in Conveyor Belt

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Discharge conveyor hopper hitting belt. | Replace or repair hopper. Report to field maintenance, 3d echelon. |
| Rocks wedged between side or back of discharge conveyor and belt. | Remove rocks. |
| Rock or gravel sticking to head belt scraper and return idler rollers. | Clean out rock or gravel. |
| Roller on idler not | Check idlers for tight |

Crusher overloaded ----- Slow down pan feeder, especially when heavy hard stone is being crushed.

38. Material Piling on Screen Under Grizzly

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--------------------------------|---|
| Worn or slipping drive belts. | Adjust or replace drive belts (par. 128). |
| Defective electric motors. | Inspect and replace electric motor if necessary (par. 128). |
| Defective rubber mounting. | Replace rubber mounting (par. 151). |
| Defective drive sheave or key. | Replace sheave and key (par. 128). |

39. Insufficient Production

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|--|
| Crusher running too slow. | Speed up engine rpm. |
| Corrugation worn smooth on lower end of jaws. | Jaws should be reversed. Report this condition to field maintenance, 3d echelon. |
| Oversized rock being fed to crusher. | Feed smaller rock by scalp- ing off the larger rocks before loading. |

40. Pan Feeder Not Operating Properly or Inoperative

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|---|
| Drive belts slipping or broken. | Replace drive belts (par. 127). |
| Defective electric motor. | Replace electric motor (par. 127). |
| Defective feeder drive gear assembly. | Repair feeder drive gear assembly. Report to field maintenance, 3d echelon. |
| Defective or damaged bars, pins, or rollers. | Replace bars, pins, and rollers (par. 145). |
| Locks wedged between feeder hopper chain belt. | Remove rocks. |
| Accumulation of dirt and sand in rollers and im- proper lubrication. | Clean chain belt and lubri- cate. (LO 5-3820-205- 20 2). |

41. Pan Feeder Hydraulic Hoses

Insufficient, dirty, or im- proper grade hydraulic fluid. Replace damaged cylin- der or O-rings. (par. 137).

Damaged or leaking oil tank. Check fluid in oil tank, drain, flush and refill w. proper grade fluid. (T 5-3820-205-10/2).

Replace oil tank (par. 130).

42. Tail and Marker Lights Inoperative

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Burned out lamp. | Replace lamp (pars. 123, 124, and 125). |
| Defective wiring. | Repair or replace wiring (pars. 111 and 123). |
| Defective trailer electrical coupling or receptacle. | Repair or replace coupling or receptacle (par. 110). |

43. Brakes Faulty

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|---|
| Slack adjusters out of ad- justment. | Adjust slack adjusters (par. 174). |
| Defective brake hose, lines, or fittings. | Replace hose (par. 142). Repair or replace line or fittings (par. 143). |
| Worn or oil soaked brake assemblies. | Replace brake assemblies (par. 175). |
| Defective air chamber. | Replace air chamber (par. 139). |
| Damaged or defective relay valve. | Replace relay valve (par. 140). |
| Clogged or defective air filters. | Service air filters (TM 5-3820-205-10/2) or re- place air filters (par. 141). |
| Leaking or damaged air tank or fittings. | Replace air tank or fittings (pars. 142 and 143). |

44. Unable to Adjust Moveable Jaw

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|---|
| Broken or defective adjusting worm and gears. | Replace worm and gears. Report this condition to field maintenance, 3d echelon. |
| Broken toggle plate. | Replace toggle plate. Re- port to field maintenance, 3d echelon. |

45. Crusher Vibrates Excessively

and where supplies and repair parts are not available and normal corrective action cannot be performed. When this condition exists, the following expedient repairs may be used in emergencies, upon the decision of the unit commander. Equipment so repaired must be removed from operation as soon as possible and properly repaired before being placed in operation again.

1. Engine Stops or Runs Erratically

| <i>Trouble</i> | <i>Expedient remedy</i> |
|--------------------------|--|
| Clogged fuel filter----- | Removed clogged filter element (par. 67). Connect fuel lines together bypassing filters. |

Section VI. RADIO INTERFERENCE SUPPRESSION

1. General Methods Used to Attain Proper Suppression

Essentially suppression is attained by providing a low resistance path to ground for stray currents. The methods used include shielding the ignition and high-frequency wires, grounding the frame with bonding straps, and using capacitors and resistors. For general information on radio interference suppression, see TM 11-483.

2. Interference Suppression Components

a. *Primary Suppression Components.* The engine-to-frame bonding strap is illustrated on figure 9.

b. *Secondary Suppression Components.*

- (1) *Tooth-type lockwashers.* Tooth-type lockwashers are used to assure a good metal-to-metal contact where electrical components are mounted.
- (2) *Shielded cable.* The generator is equipped with a shielded cable connecting the generator and generator regulator.

3. Replacement of Suppression

housing (par. 107) operate without the stat.

49 Conveyors Will Not Operate When Start Button is Depressed

| <i>Trouble</i> | <i>Expedient remedy</i> |
|---|--|
| Defective START and STOP electrical motor pushbutton control. | Remove electrical wire from rear of defective pushbutton (par. 131) contact wires directly, passing the button. Disconnect motors from main electrical control panel until a new pushbutton can be obtained. |

ing the bolt (5), washers (6), and nut (7) that secure it to the timing gear cover (1) and the engine frame (4). Install a new bonding strap and mounting hardware. Be certain to make a good metal-to-metal contact.

b. *Secondary Suppression Components.*

(1) *Tooth-type lockwashers.*


(a) If proper suppression is to be maintained, it is necessary that a good metal-to-metal contact is obtained by tightening the mounting hardware employing tooth-type lockwashers.

(b) For replacement of tooth-type lockwashers, refer to paragraphs 83, 84, and 86.

(2) *Shielded cable.* Replace the shielded generator-to-generator regulator cable (pars. 83 and 84).

53. Testing of Radio Interference Suppression Components

Test the capacitors for leaks and shorts with a capacitor tester; replace defective capacitors. If test equipment is not available and interference is indicated, isolate the cause of interference.



- | | | | |
|---|-------------------------|---|---|
| 1 | Timing gear cover | 4 | Engine frame |
| 2 | Nut, $\frac{5}{16}$ -18 | 5 | Bolt, machine, $\frac{5}{16}$ -18 x $\frac{3}{4}$ in. |
| 3 | Bonding strap | 6 | Washer, lock, ET, $\frac{5}{16}$ in. |

Figure 9. Radio interference suppression components.

CHAPTER 4

ENGINE MAINTENANCE INSTRUCTIONS

Section I. MANUAL AND MECHANICAL CONTROLS AND INSTRUMENTS

I. General

The location and purpose of the controls and instruments are given in TM 5-3820-205-10/2.

II. Engine Clutch Levers

a. Removal. Remove the two engine clutch levers as instructed on figure 10.




Figure 10. Engine clutch levers, removal and installation.

56. Throttle Control Lever

a. Removal.

- (1) Disconnect the throttle control cable from the fuel injection pump as instructed on figure 11.
- (2) Remove the throttle control lever from the instrument panel as instructed on figure 12.

b. Cleaning and Inspection. Clean and inspect all parts for damage. Replace as necessary.

c. Installation.

- (1) Install the throttle control lever on the instrument panel in reverse of instructions on figure 12.
- (2) Connect the throttle control cable to the fuel injection pump as instructed on figure 11.

57. Tachometer-Hourmeter and Drive

a. Removal. Remove the tachometer-hourmeter and drive from the instrument panel and engine as instructed on figure 11 and 12.

b. Disassembly. Disassemble the tachometer drive as illustrated on figure 13.

c. Cleaning, Inspection, and Repair.

- (1) Clean all parts in an approved cleaning solvent and dry thoroughly.
- (2) Inspect the tachometer-hourmeter for broken glass, and defective drive cable. Replace a defective tachometer-hourmeter and drive cable.
- (3) Inspect the tachometer drive




Figure 11. Throttle control cables and tachometer drive, removal and installation.

c. Installation. Install the tachometer-hour-meter and drive on the instrument panel and engine in reverse of the instructions on figures 11 and 12.

58. Fuel Gage

a. Removal. Remove the fuel gage as instructed on figure 14.

b. Cleaning and Inspection. Clean and inspect the fuel gage for damage. Replace a damaged gage.

c. Installation. Install the fuel gage in reverse of instructions on figure 14.

59. Fuel Pumps

a. Removal. Remove the fuel pump as

specified in the instructions. Inspect all parts for damage. Replace if necessary.

c. Installation.

(1) Install the fuel primer and secondary fuel filter in reverse of instructions on figure 15.

(2) Bleed the fuel system (TM 5-3820-205-10/2).

60. Air Cleaner Indicator

a. Removal. Remove the air cleaner indicator as instructed on figure 16.

b. Cleaning and Inspection. Clean and inspect all parts. Inspect the air cleaner




Figure 12. Instrument panel, rear view.

61. Hand Cranking Assembly

a. Removal. Remove the hand cranking assembly from the engine as instructed on figure 17.


d. Disassembly. Disassemble the hand cranking assembly as illustrated on figure 18.


c. Cleaning, Inspection, and Repair. Clean

and inspect. Replace or repair worn, damaged, or defective parts as necessary.

d. Reassembly. Reassemble the hand cranking assembly illustrated on figure 18.

e. Installation. Install the hand cranking assembly on the engine in reverse of the instructions on figure 17.






REMOVE SCREW (5).



REMOVE FUEL GAGE AND GASKET.

EMC 3820-205-20/2

Figure 14. Fuel gage, removal and installation.



NOTE. THE SECONDARY FUEL FILTER MUST BE REMOVED TO REMOVE THE FUEL PRIMER.

NOTE. DRAIN PRIMARY FUEL FILTER.

MSC 3820-205-20/2/15

Figure 15. Fuel primer and fuel filters, removal and installation.




Figure 16. Air cleaner indicator, removal and installation.





Figure 17. Hand cranking assembly, removal and installation.



The diesel fuel system consists of a 100-gal. fuel tank, primary fuel filter, secondary fuel filter, fuel primer, fuel injection pump, engine overspeed governor, fuel injectors, air cleaner, intake manifolds, ether starting aids, and the necessary lines and fittings for distributing the diesel fuel to the components of the fuel system.

3. Air Cleaner

a. Removal. Remove the air cleaner and prime as instructed on figure 19.

b. Disassembly.

- (1) Remove the air cleaner indicator (par. 60).
- (2) Disassemble the air cleaner as illustrated on figure 20.

c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Replace gaskets. Repair or replace all damaged parts.

d. Reassembly.

- (1) Reassemble the air cleaner as illustrated on figure 20.
- (2) Install the air cleaner indicator (par. 60).

e. Installation. Install the air cleaner and prime in reverse of instructions on figure 19.

4. Intake Manifolds

a. Removal.

- (1) Remove the air cleaner pipe (par. 63).
- (2) Remove the two intake manifolds as instructed on figure 21.

b. Cleaning and Inspection. Clean and inspect all parts. Replace any damaged or defective parts.

c. Installation.

- (1) Install the two intake manifolds in reverse of instructions on figure 21.

Note. Correct torque for manifold nuts is 50-55 foot-pounds.

- (2) Install the air cleaner pipe (par. 63).

an injector nozzle valve sticking open in cylinder which immediately precedes that cylinder in the engine firing order. During injection to the cylinder which has the nozzle valve sticking open, fuel rushes into that cylinder with no restriction, causing a scavenging effect in the pump distributor rotor. This causes a partial loss in fuel pressure to the following injector, the nozzle fails to open, and combustion does not occur in that cylinder.

b. On-Equipment Testing.

- (1) Start and operate engine at idle speed (TM 5-3820-205-10/2).
- (2) Momentarily loosen injector fuel line assembly (fig. 5) on each injector in turn. Note fuel injector where loosening of fuel line assembly causes erratic effect on engine operations.

Warning: Keep hands away from escaping fuel spray when loosening injector fuel line assemblies.

- (3) Stop the engine and replace the injector noted in (2) above.
- (4) Start the engine as in (1) above. If the operation is still erratic, determine the firing order (par. 4b) and replace injector that injects immediately prior to fuel injector found in (2) above.



c. Removal. Remove the six fuel injectors as instructed on figure 21.


d. Cleaning and Inspection. Clean and inspect all parts. Replace the gaskets and damaged parts.

e. Installation. Install the fuel injectors in reverse of instructions on figure 21.

f. Testing.

- (1) Remove one fuel injector from engine, leaving the fuel line connected to the fuel injection pump.
- (2) Start the engine (TM 5-3820-205-10/2).
- (3) Hold a target 12 inches from the





MSC 3820-205-20 2 20 (1)

1 Serial Nos. 2050 through 2057

Figure 20. Air cleaners, exploded view.



(5) Test the remaining fuel injectors in a similar manner.

(6) Stop the engine (TM 5-3820-205-

66. Ether Starting Aids

a. Removal.

(1) Remove the ether starting aid



Serial Nos. 2050 through 2129
Figure 20—Continued.

MSC 3820-205-20/1/18 ①

e. Installation.

- (1) Install the ether starting aid lines on the intake manifold (par. 64).
- (2) Install the ether starting aids and bracket in reverse of instructions on figure 22.

67. Fuel Filters


a. Removal. Remove the primary and secondary fuel filters as instructed on figure 15.

b. Cleaning and Inspection. Clean and inspect all parts. Replace as needed.

68. Fuel Tank and Cap

a. Removal.

- (1) Remove the fuel gage (par. 58).
- (2) Remove the fuel tank cap and strainer (TM 5-3820-205-10/2).
- (3) Remove the clearance marker light (par. 125).
- (4) Remove the fuel tank and bracket as illustrated on figure 23.



REMOVE NUT (12).

PORTANT

REMOVE INTAKE
OLD (2)
GASKET (2).

REMOVE ELBOW (2).

REMOVE CLIP (2).

REMOVE CLIP.

REMOVE TEE (5).

LOOSEN NUT AND REMOVE LINE (2).

ELBOW (3).

REMOVE ADAPTER (6).

REMOVE ELBOW (6).

REMOVE ADAPTER (6).


REMOVE
TEE (2).

REMOVE
ADAPTER

LOOSEN NUT (4)
REMOVE LINE (4).

LOOSEN NUT AND REMOVE
LINE (6).
REMOVE NUT (12), FUEL
INJECTOR (6), AND
GASKET (6).

LOOSEN NUT (11)
REMOVE LINE (6).



REMOVE CAP SCREW (4).

REMOVE MOUNTING BRACKET.

CHAMBER CAP

REMOVE CHAMBER BASE
FROM MOUNTING BRACKET.

REMOVE NUT.

CHAMBER BASE

LOOSEN NUT AND
REMOVE FITTING.

NOTE: REMOVE THE REMAINING OTHER STARTING
AID IN A SIMILAR MANNER

EMC 3820-205-20/2

[illegible]THE MAPS γ_A AND γ_B

2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 2680, 2681, 26

RECEIVED 1977 41

1 APRIL 2004

REMOVED FROM FILE

501 GUMF NG7 2

• 4 • • LEFT-VF BRACKET

DISCONTINUITY 49

DISCONNECT ELECTRIC LEADS.

REMOVE SCREW (4).

NOTE DRAIN THE FUEL TANK

Remove fuel tank cap and strainer (par. 52) (fig. 20, 205-10 2).

Remove fuel gage (par. 58).

Removal and Fittings

Remove the fuel lines from the fuel injectors (par. 59).

Remove the fuel lines from the fuel filter (par. 60).


Remove the fuel lines from the fuel primer (par. 61).

Remove the fuel lines from the fuel pump (par. 65).

b. Cleaning, Inspection, and Repair. Clean and inspect all parts. Repair or replace damaged parts.

c. Installation.

- (1) Connect the fuel lines to the fuel injector pump in reverse of instructions on figure 24.
- (2) Connect the fuel lines to the fuel injectors (par. 65).
- (3) Connect the fuel lines to the fuel filters (par. 67).
- (4) Connect the fuel lines to the fuel primer (par. 59).



will crush the copper gaskets allowing the screws to bottom.

General

b. Cleaning and Inspection. Clean and inspect the oil filters and bracket. Replace damaged parts.

c. Installation. Install the oil filters a mounting bracket in reverse of instruction figure 25.

72. Oil Cooler Bypass Valve


a. *Removal.* Remove the oil cooler bypass valve as illustrated on figure 26.



b. *Cleaning and Inspection.* Clean and inspect all parts. Replace all worn or damaged parts as necessary.

c. *Installation.* Install the oil cooler bypass valve illustrated on figure 26.

Oil Filters and Mounting Bracket

a. Removal. Remove the oil filters and mounting bracket as instructed on figure 25.





EMC 3820-205-20/2/23

Figure 62. Oil cooler bypass valve, removal and installation.

(1) Remove the oil filters and bracket (par. 71).

(2) Remove the oil cooler as in figure 27.

b. *Cleaning and Inspection.* Clean the oil cooler. Replace if necessary.

c. *Installation.*

(1) Install the oil cooler in reverse of instructions on figure 27.

(2) Install the mounting bracket and filters (par. 71).

74. Crankcase Breather

a. *Removal.* Remove the crankcase breather as instructed on figure 27.

b. *Cleaning and Inspection.* Clean the crankcase breather. Replace if necessary.

c. *Installation.* Install the crankcase breather in reverse of instructions on figure 27.

75. Oil Lines and Fittings

a. *Removal.* Remove the oil lines and fittings (pars. 71 and 74).

b. *Cleaning and Inspection.* Clean the oil lines and fittings. Replace if necessary.

c. *Installation.* Install the oil lines and fittings (pars. 71 and 74).

THE STATE OF TEXAS

COUNTY OF DALLAS

IN SENATE

AND

HOUSE OF REPRESENTATIVES

1901

(1)

(2)

(3)

(4)

(5)

(6)

(7)

(8)

(9)

(10)

(11)

(12)

(13)

The engine exhaust system consists of two air-cooled manifolds mounted on the left side of the cylinder head below the water manifold. The exhaust pipe extends through the hood of the engine which provides for the mounting of the muffler. Water is prevented from entering the exhaust system and cylinder head by a breather cap, secured to the top of the manifold.

77. Muffler Assembly

Removal. Remove the muffler in reverse of the instructions in figure 7.

Cleaning and Inspection. Clean and inspect the muffler and clamps. Replace a defective muffler and mounting clamps.

Installation. Install the muffler as instructed in figure 7.


a. Removal.

- (1) Remove the muffler as instructed in figure 77).
- (2) Remove the engine housing and mounting ports (par. 97).
- (3) Remove the exhaust pipe and manifold folds as instructed on figure 77.

b. Cleaning and Inspection. Clean and inspect the exhaust pipes and manifold for damage. Replace damaged parts.

c. Installation.

- (1) Install the exhaust pipe and manifold in reverse of instructions in figure 77.
- (2) Install the engine housing and mounting ports (par. 97).
- (3) Install the muffler assembly as instructed in figure 77.



The electrical system of the jaw crusher is a 24-volt system which consists of four batteries, generator, generator regulator, starter, pressure gage and sending unit, water temperature gage and sending unit, battery indicator gage, overspeed governor, safety ignition switch, and the necessary wiring and connections to complete the system. Figure 1 is a wiring diagram for the jaw crusher electrical system.

Batteries and Cables

a. Testing.

- (1) Use a hydrometer to test each battery cell; each cell should read 1.280 specific gravity at 80°F. Recharge if the reading is 1.250 or less.
- (2) Use a voltmeter to test each cell for voltage. Each full charged cell must deliver 2 volts. A low voltage indicates a low charge or a defective cell. Recharge the battery if the output voltage varies more than 30 percent between cells, replace the battery.

Warning: Do not smoke or allow an open flame near charging batteries. Serious injury from explosion and acid could result. Avoid spilling electrolyte on clothing or flesh. Acid causes severe burns.

a. Removal.

- (1) Loosen locknut (fig. 6) and place clamp handle up or at right angle to battery terminal.
- (2) Remove cables from battery terminals; inspect clamps for loose or corroded condition. Remove corrosion and coat battery terminals and clamps with grease.

c. Cleaning and Inspection. Clean and inspect the batteries. Replace as necessary.

a. Removal.

- (1) Remove the batteries and cables (page 80).
- (2) Remove the battery box as instructed on figure 29.

b. Disassembly. Disassemble the battery box as illustrated on figure 30.

c. Cleaning, Inspection, and Repair. Clean and inspect the battery cables and box. Repair or replace all damaged parts.

d. Reassembly. Reassemble the battery box as illustrated on figure 30.

c. Installation.

- (1) Install the battery box in reverse of instructions on figure 29.
- (2) Install the batteries and cables (page 80).

82. Battery Charging Receptacle

a. Removal. Remove the battery charging receptacle as instructed on figure 31.

b. Cleaning and Inspection. Clean and inspect the battery charging receptacle for damage or defects. Replace a defective receptacle if necessary.

c. Installation. Install the battery charging receptacle in reverse of instructions on figure 31.

83. Generator Regulator

a. Removal. Remove the generator regulator from the jaw crusher as instructed on figure 32.

b. Cleaning, Inspection, and Repair. Clean and inspect. Replace a worn, damaged, or defective generator regulator.

c. Installation. Install the generator regulator in reverse of the instructions on figure 32.

Caution: The engine generator must be polarized.




Figure 29. Battery box, removal and installation.

vibration, heavy arcing, and burning. Polarize the generator by disconnecting the field lead at the regulator and momentarily connecting a jumper lead between the generator field terminal and the regulator battery terminal. Remove the jumper lead and connect field lead to the generator (3, fig. 33).

d. Test and Adjustment.

(1) Mechanical adjustment.


- (a) Disconnect regulator-to-battery cable.
- (b) Remove regulator cover as instructed on figure 32.
- (c) Press down on the cutout

correct air gap for the cutout relay is 0.048 inch.

Note. Do not measure the cutout relay air gap between the brass residual pin in the coil and the armature.

- (d) Should the cutout relay air gap not be as specified, bend the armature stop up or down to obtain the proper clearance.

Caution: Make certain the cutout relay contact bracket is in proper position to allow both contact points to close simultaneously.




MSC 3820-205-20/2/30

Figure 30. Battery box, exploded view.

screws securing the cutout relay contact bracket to the cutout relay and raise or lower the cutout relay contact bracket until the specified air gap is obtained. Secure the ad-

(g) Push down on the voltage regulator armature (2, fig. 33) until the voltage regulator contact point bar touches the air gap adjusting screw. Measure the air gap between



REMOVE RECEPTACLE.

REMOVE SCREW (4).

CLUTCH HOUSING

NOTE: TAG AND DISCONNECT NECESSARY LEADS.

MSC 3820-205-20. 1 30

Figure 31. Battery charging receptacle, removal and installation.


correct voltage regulator air gap 0.084 inch.

- (h) Adjust the current regulator air gap to 0.115 inch in the same manner the voltage regulator unit was adjusted, described in (g) above.
- (2) *Electrical adjustments.* Install set test adapters.

Note. Refer to 3, figure 38 and polarity the generator.

- (a) *Cutout relay closing voltage.* With voltmeter connected as shown on figure 33, start the engine and slowly increase speed until the cutout relay contact points close. Observe voltage reading at which this occurs. It should be between 28 and 32 volts. If adjustment is necessary, turn cutout relay adjusting screw clockwise to increase or

NOTE: IF REGULATOR IS TO BE ADJUSTED REMOVE SCREW (4) AND COVER. REPLACE COVER AFTER ADJUSTMENTS ARE MADE.



REMOVE GENERATOR REGULATOR.

REMOVE NUT (4).

COVER

DISCONNECT AND REMOVE ELECTRICAL LEAD.

REMOVE SCREW AND LEAD.





Figure 33. Generator regulator adjustment and test wiring diagram.

counterclockwise to decrease the closing voltage. Set closing voltage at 26 volts.

- (b) *Voltage regulator opening voltage.* With voltmeter connected as shown on 5, figure 33, increase rpm to operating speed. Observe reading on voltmeter. It should read between 27.5 and 29.5 volts. If adjustment is necessary, turn the voltage regulator adjusting screw clock-

shown on 6, figure 33 and with the test set carbon pile load set at 25 to 30 amps or, first having operated the starter for 10 to 20 seconds to provide the load, increase rpm to operating speed, observe reading on ammeter at which points first vibrate. This should be between 38 and 42 amperes. If adjustment is necessary, adjust the current regulator to 40 amperes



MSC 3820-205-20 1 32 (2)

Figure 33—Continued.

and amperage output through several cycles of increasing and decreasing engine speed from idle-to-operating-to-idle speed to make sure adjustments are stable.

Remove adapters and connect cables.

Install regulator cover.

Generator and Bracket

Test.

Make a test connection as shown on figure 33.

Start engine and slowly build up rpm to operating speed. Observe voltage. The minimum voltage is

(3) If voltage is not built up to required value, generator is defective and must be replaced.

b. Removal. Remove the generator and mounting bracket from the engine as instructed on figure 34.


Note. If removing bracket, remove the generator (par. 83).

c. Cleaning, Inspection, and Repair.

(1) Clean the generator with a cloth dampened with approved cleaning solvent.

(2) Inspect the generator for loose assembly hardware.

(3) Rotate



NOTE: MOMENTARILY CONNECT THE JUMPER WIRE AS ILLUSTRATED TO POLARIZE THE GENERATOR.

MSC 3820-205-20/2/33 ③

③

Figure 33.—Continued.

or the field pole shoes. Replace a defective generator.


- (4) Inspect and replace brushes as instructed in *d* below.

d. Brush Replacement.

- (3) Install new brushes on the generator in reverse of instructions on figure 33.

e. Installation.

- (1) Install the generator and mounting bracket on the engine in reverse of



MSC 3820-205-20/2/33 ④

④

Figure 37—Continued.

- (2) If the starter operates, the solenoid is defective. Replace a defective solenoid.
- b. *Removal.* Remove the starter solenoid from the starter as instructed on figure 36.
- c. *Cleaning, Inspection, and Repair.* Clean and inspect. Replace a defective solenoid.
- d. *Installation.* Install the starter solenoid on the starter in reverse of the instructions on figure 36.

6. Starter

a. On-equipment Test.


- (1) Connect a heavy jumper lead across the large terminals on the starter solenoid.
- (2) If the starter does not operate, the solenoid is defective. Replace a defective solenoid.

c. Cleaning, Inspection, and Repair.

- (1) Clean the starter with a cloth dampened with an approved cleaning solvent.
- (2) Replace a damaged or defective starter as necessary.

d. Brush replacement.

- (1) Remove the cover band from the starter as instructed on figure 36.
- (2) Remove the brushes from the starter as instructed on figure 37.
- (3) Inspect the brushes for worn, or chipped condition. Replace brushes if worn to less than one-half inch in length. Inspect the brush holder for



(5)

Figure 33—Continued.

- (5) Install the cover band on the starter in reverse of the instructions on figure 36.

Installation. Install the starter on the line in reverse of the instructions on figure

- (2) Install the oil pressure gage in reverse of instructions on figure 38.

88. Water Temperature Gage and Sending Unit

a. Removal.

- (1) Remove the water temperature gage as instructed on figure 38.
- (2) Remove the water temperature gage sending unit as instructed on figure 40.

b. Cleaning and Inspection. Clean and inspect the water temperature gage and sending unit for damage. Replace as required.

c. Installation.


- (1) Install the water temperature gage

Oil Pressure Gage and Sending Unit

a. Removal.

- (1) Remove the oil pressure gage as instructed on figure 38.
- (2) Remove the oil pressure gage sending unit as instructed on figure 39.

b. Cleaning and Inspection. Clean and inspect the oil pressure gage and sending unit for damage. Replace as necessary.



MSC 3820-205-20 2/33 (6)

Figure 43--Continued.

89. Battery Generator Indicator

a. Removal. Remove the battery generator indicator as instructed on figure 38.

b. Cleaning and Inspection. Clean and inspect the battery indicator gage for damage. Replace as necessary.

c. Installation. Install the battery generator indicator in reverse of instructions on figure 38.

90. Overspeed Governor

a. Removal. Remove the overspeed governor as instructed on figure 41.

b. Cleaning and Inspection. Clean and inspect the governor for damage. Replace as necessary.

91. Safety Switch and Water Temperature Sending Unit

a. Removal. Remove the water temperature sending unit and safety switch as instructed on figure 42.

b. Cleaning and Inspection. Clean and inspect the safety switch and water temperature sending unit for damage. Replace as necessary.

c. Installation. Install the water temperature sending unit and safety switch in reverse of instructions on figure 42.





Figure 34. Generator and mounting bracket, removal and installation.



b. *Cleaning and Inspection.* Clean and inspect the starter switch for defects. Replace as required.

c. *Installation.* Install the starter switch in reverse of instructions on figure 38.

93. Engine Wiring and Warning Lights

a. *Wiring.*

- (1) *Removal.* Remove the engine wiring as instructed on figures 38 and 42.
- (2) *Cleaning, inspection, and replacement.* Clean and inspect the engine wiring. Repair or replace as necessary.
- (3) *Installation.* Install the engine wiring in reverse of instructions on figures 38 and 42.

b. *Warning Lights.*

- (1) *Removal.* Remove the warning light assembly as instructed on C, figure 38.




Figure 86. Starter, solenoid, and cover band, removal and installation.




Figure 37. Starter brush replacement.





Figure 38. Gages and switch, removal and installation.



MSC 3820-205 20 2 39







Figure 40. Water temperature gauge sending unit manifold, removal and installation.


Figure 39. Oil pressure gauge sending unit, removal and installation.



ENC 3820-205-20 2 41

Figure 41. Overspeed governor, removal and installation.





C

MSC 3820-205-20/1/41 (2)

Remove the engine and high water temperature warning lights (on units of equipment within serial No. range 2090 through 2129 only)

Figure 42—Continued.

Section VI. ENGINE HOUSING

General

The engine housing is constructed of precast concrete and includes the doors, door supports, side panels, hood, radiator cowl, and necessary attaching hardware.

Water Drain Lines

Removal. Remove the drain lines as instructed on figure 13.
Installation. Clean and inspect the drain lines and replace as necessary. Install the drain lines in reverse of removal instructions on figure 13.

- b. Cleaning, Inspection, and Repair.* Clean and inspect the doors for any damage. Repair or replace if necessary.
- c. Installation.* Install the doors in reverse of instructions on figure 44.

97. Engine Door Supports and Side Panels

- a. Removal.*
 - (1) Remove the crankcase and water drain lines (par. 95).
 - (2) Remove the doors (par. 96).
 - (3) Remove the engine door supports and side panels as instructed on figure 45.
- b. Cleaning*




Figure 43. Drain lines, removal and installation.

c. Installation.

- (1) Install the engine side panels and door supports in reverse of instructions on figure 45.
- (2) Install the crankcase and water drain lines (par. 95).
- (3) Install the engine doors (par. 96).

8. Hood, Radiator Cowling, and Rear Panel

a. Hood, and Radiator Cowling Removal.

- (1) Remove the muffler (fig. 7).
- (2) Remove the door supports and side panels (par. 97).
- (3) Remove the hood and radiator cowling from the unit as instructed on figure 45.

66).

- (3) Remove the safety ignition switch (par. 91).
- (4) Remove the tachometer-hourmeter (par. 57).
- (5) Remove the indicator gages and switches (pars. 87 through 89 and 92).
- (6) Remove the battery charging receptacle (par. 82).
- (7) Remove the rear panel from the unit as instructed on figure 45.

c. *Cleaning, Inspection, and Repair.* Clean and inspect. Replace or repair worn, damaged or defective parts as necessary.

d. Hood, and Radiator Cowling Installation.

- (1) Install the hood and radiator cowling on the unit in reverse of the instructions on figure 45.
- (2) Install the door supports and side panels (par. 97).
- (3) Install the muffler (fig. 7).

e. Rear Panel Installation.

- (1) Install the rear panel on the unit in reverse of the instructions on figure 45.
- (2) Install the indicator gages (pars. 87 through 89 and 92).
- (3) Install the tachometer-hourmeter (par. 57).
- (4) Install the safety ignition switch (par. 91).
- (5) Install the other starting aids (par. 66).
- (6) Install the air cleaner (par. 63).

REMOVE DOOR

REMOVE SCREW (5)

NOTE: REMOVE THE REMAINING TWO (2) IN A SIMILAR MANNER.

ENC 3820-205-2G 2 C




Figure 45. Engine housing, removal and installation.

Section VII. VALVE COVER AND ROCKER ARM ASSEMBLY

99. General

The engine intake and exhaust valves are located in the cylinder heads. There are three intake and three exhaust valves, rocker arms, and rocker arm adjusting screws located under each valve cover. The valve covers and breather

- (1) Remove the engine hood (par. 98).
 - (2) Remove the two valve covers and breather as instructed on figure 46.
- b. *Cleaning and Inspection.* Clean and inspect all parts. Replace gaskets and damaged parts.




Figure 46. Valve covers and breather, removal and installation.

1. Rocker Arm Adjustment

a. Removal. Remove the valve covers and breather (par. 100).

b. Adjustment. Adjust each of the six in-

take and six exhaust valve rocker arms as instructed on figure 47.

c. Installation. Install the valve covers and breather (par. 100).





Figure 47. Rocker arm adjustment.

Section VIII. •ENGINE COOLING SYSTEM

02. General

The engine cooling system consists of a fan

temperature is controlled by the thermostat keep the engine at operating temperature. The water is cooled by the fan pulling cool



TO REMOVE THE SCREW (10)

TO REMOVE THE SCREW (11)

TO REMOVE THE BELTS, LOOSEN ADJUSTING
SCREW SCREW GENERATOR MOUNTING RUT (2).
PUSH GENERATOR IN TOWARD ENGINE AND
SLIP BELTS OFF GENERATOR AND FAN PULLEYS

b. *Cleaning and Inspection.* Clean and inspect the fan belt for fraying or any other damage. Replace as necessary.

c. *Installation.*

(1) Install the fan belts in reverse of instructions on figure 48.

(2) Install the fan guard (par. 103).

d. *Adjustment.* Adjust the fan belt (TM 5-3820-205-10/2).

05. Fan and Water Pump

a. *Removal.*

(1) Drain the cooling system (TM 5-3820-205-10/2).

(2) Remove the fan belts (par. 104).

(3) Remove the fan and water pump as instructed on figure 49.

b. *Cleaning and Inspection.* Clean and inspect the fan and water pump for damage. Replace as necessary.

c. *Installation.*

(1) Install the fan and water pump in reverse of instructions on figure 49.

(2) Install the fan belts (par. 104).

(3) Fill the cooling system (TM 5-3820-205-10/2).

106. Radiator Shroud

a. *Removal.*

(1) Drain the cooling system (TM 5-3820-205-10/2).

(2) Remove the engine hood (par. 98).



(3) Remove the fan (par. 105).

(4) Remove the radiator shroud as instructed on figure 50.

b. *Cleaning and Inspection.* Clean and inspect the radiator shroud. Replace as necessary.

c. *Installation.*

(1) Install the radiator shroud in reverse of instructions on figure 50.






Figure 50. Radiator shroud, removal and installation.

- (1) Remove the fan (par. 105).
- (2) Remove the engine hood (par. 98).
- (3) Fill the cooling system (TM 5-3820-205-10/2).

- (2) Fill the cooling system (TM 5-3820-205-10/2).

107. Thermostat and Housing

- a. Removal.
 - (1) Drain the cooling system (TM 5-3820-205-10/2).
 - (2) Remove the thermostat and housing as instructed on figure 51.

b. Cleaning and Inspection. Clean and inspect the thermostats and housing. Replace if necessary.

c. Installation. Place the thermostat and suitable water in a pan or pail of water and heat the thermostat should start to open at 170° F. and be fully open at 180°-185° F. Replace the thermostat.

108. Water Manifold

a. Removal.

- (1) Drain the cooling system (TM 5-3820-205-10/2).
- (2) Remove the thermostats and housing (par. 107).
- (3) Remove the water manifold as instructed on figure 40.

b. Cleaning and Inspection. Clean and inspect the water manifold for any damage. Replace if necessary.

c. Installation.

- (1) Install the water manifold in reverse of instructions.






Figure 51. Thermostat and housing, installed view.



A




B



1 - 1/2" x 1/2" x 1/2" installed

Figure 53—Continued.



EMC 3820-20

Figure 54. Tail and blackout lights, exploded view.

Section II. DOLLY ASSEMBLY

112. General

The dolly assembly consists of a drawbar, lunette, fifth wheel, wheels, and wheel bearing assemblies. The dolly is used to carry the front end of the trailer frame when the unit is being pulled as a full trailer. The fifth wheel includes a jaw-latch mechanism for connecting or disconnecting the dolly assembly from the trailer.

113. Dolly Assembly

a. Removal.

- (1) Crib the jaw crusher (TM 5-3820-205-10/2).
- (2) Remove the dolly assembly as illus-

c. Installation.

- (1) Install the dolly assembly of instructions on figure 55.
- (2) Remove the cribbing (TM 205-10/2).

114. Fifth Wheel

a. Removal.

- (1) Remove the dolly assembly
- (2) Remove the fifth wheel as on figure 55.

b. Disassembly. Disassemble the as illustrated on figure 56.

c. Cleaning, Inspection, and Remo




Figure 55. Fifth wheel and dolly assembly, removal and installation.

e. Installation.

- (1) Install the fifth wheel in reverse of instructions on figure 55.
- (2) Install the dolly assembly (par. 113).

15. Dolly Wheels and Tires

a. Removal.

- (1) Use a suitable lifting device and place dolly axle on blocks.
- (2) Remove the dolly wheels and tires as instructed on figure 57.

b. Cleaning, Inspection, and Repair.

- (1) Clean studs and nuts with an approved cleaning solvent and dry thoroughly.
- (2) Clean hub, wheel faces, and nut cavities of all dirt.


Repair tires and tubes as instructed in TM 9-1870-1.

c. Installation.

- (1) Install inner wheel on hub.


Note. Number the studs 1 to 6.


- (2) Install inner capnuts on studs 1 and 4 and torque to 150 to 200 foot-pounds.
- (3) Install the remaining capnuts and torque Nos. 2, 5, 3, and 6 to 500 to 600 foot-pounds in that order. Retorque Nos. 1 and 4 to 500 to 600 foot-pounds.
- (4) Install the outer wheel assembly making sure that the outer wheel valve stem is opposite the inner valve stem.
- (5) Install two outer nuts on opposite



EMC 3820-205-2

Figure 56. Fifth wheel, exploded view.





MSC 3820-205-20 1 56

Figure 57. Dolly wheel, removal and installation.

and torque to 500 to 600 foot-pounds in the sequence outlined above.

- (7) Remove the two outer nuts (5) above and reinstall with washers and torque to 500 to 600 foot-pounds.
- (8) Remove the dolly from the blocks using a suitable lifting device and road test approximately 10 miles. After first mile, fifth mile, and tenth mile retorque inner and then outer nuts to 500 to 600 foot-pounds. If at the tenth mile torque value has dropped below 400 foot-pounds, remove wheels, investigate, and repeat entire procedure.

Caution: A trestle (Motor Vehicle Maintenance, 5-ton) will be used in final torquing operations, taking care that drive extensions are parallel to the ground at all times.

6. Wheel Bearing and Hub Assemblies

a. Removal and Disassembly.

- (1) Remove the dolly wheels (par. 115).
- (2) Remove and disassemble the wheel bearings and hub assembly as illustrated on figure 58.

Note. Install hubs with right-hand stubs on right side of the vehicle and hubs with left-hand stubs on left side of the vehicle.

- (2) Install the wheel bearing adjusting nut. Screw the nut against the bearing as the wheel is revolved. Be sure there is sufficient clearance between the brakeshoe and drum so brakeshoe drag will not interfere with the bearing adjustment.
- (3) Tighten the adjusting nut to 50-foot-pounds torque while the wheel is being rotated. Rotate the wheel in both directions to correctly position the bearings.
- (4) Back off adjusting nut $\frac{1}{4}$ to $\frac{1}{2}$ turn, and install the adjusting nut lockwasher. If the holes in lockwasher do not fit dowel protruding from adjusting nut, the washer may be removed and turned over, which changes hole locations.
- (5) Install the outer locknut and torque to 250 to 400 foot-pounds.

Note. The use of an impact wrench is discouraged; however, if used, the final torquing will be accomplished by hand using a smooth downward effort.

117. Air Hoses and Fittings

a. *Removal.* Remove the air hoses as illustrated on figure 59.

Note. On units of equipment within serial No. range 2090 through 2129 the hoses and cable are suspended by the Flexo-Stick assembly.


b. *Cleaning and Inspection.* Clean and inspect all air hoses and fittings for damage or deterioration. Replace as required.

c. *Installation.* Install the air hoses and fittings in reverse of instructions on figure 59.

118. Drawbar

a. Removal.

- (1) Remove Flexo-Stick assembly from



MSC 3820-205-20/2/58

Figure 58. Wheel bearing and hub assembly, exploded view.

b. Cleaning and Inspection. Clean and inspect the drawbar for damage. Replace if necessary.

c. Installation.

- (1) Install the drawbar in reverse of instructions on figure 59.
- (2) Install Flexo-Stick assembly on the drawbar (TM 5-3820-205-10/2).

119. Lunette

a. Removal. Remove the lunette as instructed on figure 59.

b. Cleaning and Inspection. Clean and inspect the lunette for wear. Replace if necessary.

c. Installation. Install the lunette in reverse

120. Reflectors

a. Removal. Remove reflectors as instructed on figure 53.

b. Cleaning and Inspection. Clean and inspect reflectors for damage. Replace damaged reflectors as necessary.


c. Installation. Install the reflector in reverse of instructions on figure 53.

121. Safety Chains

a. Removal. Remove the safety chains as instructed on figure 59.

b. Cleaning, Inspection, and Repair. Clean and inspect the safety chains for wear and damage. Repair by welding, or use repair link suitable heavy clevises.


c. Installation. Install the safety chain



EMC 3820-206-20/2/54

1 Serial No. 2060 through 2087

Figure 59. Drawbar, air hose, fittings, safety chain, and lunette, removal and installation.



NOTE: USE A SUITABLE CUTTING DEVICE TO REMOVE CHAIN.

MSC 3820-205-20/2/59 (2)

2 Serial No. 2090 through 2120

Figure 59--Continued.

CHAPTER 6

CRUSHER MAINTENANCE INSTRUCTIONS

Section I. CRUSHER ELECTRICAL SYSTEM

122. General

The crusher electrical system is comprised of two separate systems. The 24-volt chassis electrical system consists of taillights, blackout light, clearance or marker lights, and necessary wiring to complete the circuit. This system derives its power from the crusher prime mover. The crusher motors electrical system consists of three 10-horsepower electrical motors, an operator's control box, main electrical control panel and necessary wiring, switches, and electrical hardware to complete the circuits.

123. Taillights

a. Removal and Disassembly. Remove and disassemble the taillights (par. 111).

b. Cleaning, Inspection, and Repair. Clean, inspect, and repair taillight (par. 111).

c. Reassembly and Installation. Reassembly and install taillights (par. 111).

124. Blackout Taillight

a. Removal. Remove the blackout taillight (par. 111).

b. Cleaning, Inspection, and Repair. Clean, inspect, and repair the blackout taillight (par. 111).

c. Installation. Install the blackout taillight (par. 111).

125. Clearance (Marker) Lights and Electrical Conduit

a. Removal. Remove the clearance lights and

c. Cleaning, Inspection, and Repair. Clean and inspect all parts for breaks, cracks, loose or missing hardware, corrosion, and frayed or damaged insulation. Repair or replace if necessary.

d. Reassembly. Reassemble the clearance lights as illustrated on figure 61.

e. Installation. Install the clearance lights and electrical conduit in reverse of instructions on figure 60.

126. Crusher Electrical Connector

a. Removal. Remove the crusher electrical connector (par. 110).

b. Cleaning, Inspection, and Repair. Clean inspect and repair the crusher electrical connector.

c. Installation. Install the crusher electrical connector (par. 110).

127. Pan Feeder Drive Motor, Belts, and Turn Buckle Assembly

a. Removal.

(1) Remove the pan feeder motor as instructed on figure 62.

(2) Remove the turn buckle assembly illustrated on figure 62.

b. Cleaning, Inspection, and Repair. Clean and inspect all parts for loose or missing hardware and defective or damaged parts. Replace a defective part.

c. Installation.

(1) Install the pan feeder motor and drive




Figure 60. Clearance light and electrical conduit, removal and installation.

Scalper Vibrating Screen Drive Motor and Belts

Removal.

- (1) Remove the belt guard (TM 5-3820-205-10/2).
- (2) Remove the scalper vibrating screen drive motor and belts as instructed on figure 63.


Cleaning and Inspection. Clean all parts inspect for loose or missing hardware and aged or defective parts. Replace a defective part as necessary.

129. Discharge Conveyor Drive Motor and Belts

a. Removal. Remove the discharge conveyor drive motor and belts as instructed on figure 62.

b. Cleaning and Inspection. Clean all parts and inspect for loose or missing hardware, and damaged or defective parts. Replace defective parts as necessary.

c. Installation. Install the discharge conveyor motor and drive belts in reverse of the instructions on figure 62.



EMC 3820-205-20/2/66

Figure 61. Clearance light, exploded view.

ther damage. Replace a defective or damaged heater or magnetic starter if necessary.

Installation. Install the magnetic starter in reverse of instructions on figure 64.

Pushbutton Controls

Removal. Remove pushbutton controls as instructed on figure 65.

Cleaning and Inspection. Clean and inspect all parts. Replace a damaged or defective pushbutton control if necessary.

Installation. Install the pushbutton control in reverse of instructions on figure 65.

Power Cable

Removal. Remove the power cable from the cable reel (TM 5-3820-205-10/2).

Cleaning and Inspection. Clean and inspect

the power cable for cut or deteriorated insulation, breaks, damaged connectors, or other damage. Replace a defective or damaged power cable.

c. Installation. Install the power cable on the cable reel (TM 5-3820-205-10/2).

133. Main Electrical Emergency Stop Control Button

a. Removal. Remove the main electrical emergency stop control button as instructed on figure 65.

b. Cleaning and Inspection. Clean and inspect all parts. Replace a defective or damaged part as necessary.

c. Installation. Install the main electrical emergency stop control button in reverse of instructions on figure 65.

NOTE: REMOVE THE MAIN CONVEYOR MOTOR BELTS AND MOUNTING IN A SIMILAR MANNER.

NOTE: REMOVE SCREWS AND JUNCTION

REMOVE COVER TAG AND DISCONNECT ELECTRICAL LEADS.

REMOVE SCREWS (2)

REMOVE MOTOR

DISCONNECT CONDUIT CONNECTOR FROM ELECTRICAL LEADS FROM JUNCTION BOX

GEAR HOUSING

OPEN LOCKING PIN (2) AND TOP OF GEAR HOUSING IS TO BE REMOVED AND REMOVE DRIVE

REMOVE CAP SCREWS (4)

REMOVE DUST SHIELD

DRIVE BELT

REMOVE CAP SCREWS (4)





Figure 63. Scalper vibrator screen drive motor and belts, removal and installation.



NOTE: REMOVE REMAINING MAGNETIC
STARTERS IN A SIMILAR MANNER.

REMOVE SCREW (4).

REMOVE HEATER STRIP (2).


REMOVE MAGNETIC STARTER.


REMOVE SCREW (3).

REMOVE LEAD (16).

NOTE: TAG LEADS FOR
PROPER INSTALLATION.

NOTE: LOOSEN THUMBSCREWS (4),
SLIDE KEEPERS AWAY FROM
OPERATOR'S CONTROL BOX
AND SWING PANEL OPEN.





B Operator's control box rear view

Figure 65—Continued.

Section II. HYDRAULIC SYSTEM

General

The crusher hydraulic system includes a tank and an internally mounted, hand operated pump. A hose with a manually operated valve connects the pump to the five stage hydraulic cylinder used to raise or lower the pan feeder assembly.

Hydraulic Hose, Pump, and Valve

Removal.

(1) Drain the hydraulic system (TM 5-


c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Replace or repair all damaged parts.

d. Reassembly. Reassemble the hydraulic pump and valve as illustrated on figure 67.

e. Installation.

(1) Install the hose, pump, and valve in reverse of instructions on figure 66.

(2) Fill the hydraulic system (TM 5-3820-205-10/2).



Hydraulic hose, pump, and valve, installed
etc.

c. *Cleaning and Inspection.* Clean and inspect all parts. Replace all damaged parts.

c. *Installation.*


- (1) Install the hydraulic tank and pump in reverse of instructions on figure 68.
- (2) Install the hose, pump, and valve (par. 135).

137. Hydraulic Cylinder and Hose

a. *Removal.* Remove the hydraulic cylinder and hose as instructed on figure 69.

b. *Cleaning and Inspection.* Clean and inspect all parts. Replace all damaged parts.

c. *Installation.* Install the hydraulic cylinder and hose in reverse of instructions on figure 69.



MSC 3820-205-20/2/67

Figure 67. Hydraulic pump and valve, exploded view.





Figure 68. Hydraulic tank and bracket, installed view.



138. General

The air system consists of the hose, lines, valves, filters, chambers, and air tank. The air system is used to actuate the brakes when the law crusher is being towed from one location to another.

139. Air Brake Chamber

a. Removal. Remove the air brake chamber as instructed on figure 70.

b. Cleaning and Inspection. Clean and inspect all parts. Replace a defective air brake chamber.

c. Installation. Install the air brake chamber in reverse of instructions on figure 70.

140. Relay Valve

a. Removal. Remove the relay valve as instructed on figure 71.

inspect the relay valve. Replace a defective relay valve.

c. Installation. Install the relay valve in reverse of instructions on figure 71.

141. Air Filter

a. Removal. Remove the air filter as instructed on figure 72.


b. Cleaning and Inspection. Clean and inspect the air filters. Replace a defective filter.

c. Installation. Install the air filter in reverse of instructions on figure 72.

142. Air Tank

a. Removal. Remove the air tank as instructed on figure 73.

b. Cleaning and Inspection. Clean and inspect the air tank. Replace a defective air tank.



CAUTION BLEED AIR FROM SYSTEM
BEFORE DISCONNECTING
AIR HOSE.

REMOVE NUT (2).

REMOVE PIN.


DISCONNECT AIR HOSE.

NOTE: REMOVE THE REMAINING AIR
CHAMBERS IN A SIMILAR
MANNER.

MSC 3820-205-20 1 70 ②


2 Serial No. range 2030 through 2129

Figure 70—Continued.



A On units of equipment within serial No. range 2050 through 2087 only


Figure 71. Relay valve, installed view.



MSC 3820-205-20/2/71 (2)

B—On units of equipment within serial No. range 2090 through 2129 only

Figure 71—Continued.






Figure 6. Air tank removal and installation


a. Installation. Install the air tank in reverse of the instructions on figure 73.

3. Couplings and Hoses


a. Removal. Remove the coupling and hoses instructed on figure 74.

b. Cleaning, Inspection, and Repair. Clean and inspect all parts. Replace or repair all damaged parts.

c. Installation. Install the couplings and hoses in reverse of the instructions on figure 7



A



B

EMC 3820-205-20/2-69

A—Couplings rear view

B—Couplings front view

Figure 74. Couplings and hoses, removal and installation.

Section IV. PAN FEEDER ASSEMBLY

144. General

The pan feeder initially receives the rock to be crushed and feeds it into the scalper vibrating screen assembly. The pan feeder assembly consists of a hopper, an electric motor, motor drive belts, reducer gears, drive sheaves, sprockets, frame and an apron which is made up of bars, pins, rollers, and pans assembled together to form an endless metal belt.

145. Pan Feeder Apron.

a. *General.* Remove the pan feeder apron as instructed on figure 75.

b. *Cleaning, Inspection, and Repair.* Clean and inspect all parts. Pay particular attention to the bearings of the rollers and the end pans. Reweld any loose end pan welds. Replace a defective or damaged part as necessary.

c. *Installation.* Install the pan feeder apron in reverse of the instructions on figure 75.

d. *Adjustment.* Adjust the tension of the pan feeder apron as instructed on figure 75.

a. Removal. Remove the scalper vibrating screen rubber deflectors as instructed on figure 77.

b. Cleaning and Inspection. Clean and inspect all parts. Inspect the rubber deflectors for cuts, tears, or signs of deterioration. Replace a damaged or defective part as necessary.

c. Installation. Install the scalper vibrating screen rubber deflectors in reverse of the instructions on figure 77.

150. Grizzly Bars

a. Removal. Remove the grizzly bars as instructed on figure 78.

b. Cleaning and Inspection. Clean and inspect all parts. Replace a damaged parts as required.

c. Installation. Install the grizzly bars in reverse of instructions on figure 78.


a. Removal.

- (1) Remove the scalper vibrating screen drive belt guard (TM 5-3820-10/2).
- (2) Remove the scalper vibrating screen assembly rubber mountings as instructed on figure 79.

b. Cleaning and Inspection. Clean and inspect all parts. Replace a damaged or defective part as necessary.

c. Installation.

- (1) Install the scalper vibrating screen assembly rubber mountings in reverse of instructions on figure 79.
- (2) Install the scalper vibrating screen drive belt guard (TM 5-3820-10/2).







Figure 78. Grizzly bars, removal and installation.

NOTE REMOVE REMAINING RUBBER MOUNTINGS IN A SIMILAR MANNER.



NOTE ATTACH SUITABLE LIFTING DEVICE TO THE SCALPER VIBRATING SCREEN ASSEMBLY, RAISE AND BLOCK SECURELY.



b. *Disassembly.* Disassemble the diverter box, chutes, and gate as illustrated on figure 81.

c. *Cleaning, Inspection, and Repair.* Clean

e. *Installation.* Install the diverter box and coarse chute in reverse of instructions on figure 80.




ENC 3B29-2LS-23 2 75

A- Diverter box installed

B- Coarse chute installed

Figure 80. Diverter box and coarse chute, removal and installation.



153. General

The crusher assembly consists of a movable jaw and a stationary jaw made to crush aggregate any size from 1½ inches to 5 inches. The crusher is driven by belts from the diesel engine drive sheave to the crusher grooved balance wheel.

154. Drive Belt Guard Assembly

a. Removal. Remove the drive belt guard as instructed on figure 82.

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged or defective parts.

c. Installation. Install the drive belt guard assembly in reverse of instructions on figure 82.

155. Drive Belts

a. Adjustment.

- (1) Remove the outer belt guard (par. 154).
- (2) Adjust the drive belt as instructed on figure 83.
- (3) Install the outer drive belt guard (par. 154).

b. Removal.

- (1) Remove the outer belt guard (par. 154).
- (2) Loosen drive belt tension as instructed on figure 83 and remove drive belts.

c. Cleaning and Inspection. Clean and inspect drive belts. Replace belts as a set if any are damaged or defective.

d. Installation.

- (1) Install the drive belts and adjust tension in reverse of instructions on figure 83.
- (2) Install the outer drive belt guard (par. 154).



156. Tension Spring

a. Removal. Remove the tension spring as instructed on figure 84.

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged parts.

c. Installation. Install the tension spring in reverse of instructions on figure 84.

d. Adjustment. For adjustment of tension spring, refer to TM 5-3820-205-1.



NOTE: LOOSEN ENGINE MOUNTING BOLT (4)
BEFORE TURNING ADJUSTING SCREWS.

ENGINE HOUSING

FRAME

ADJUSTMENT SCREW (2)

NOTE: TURN ADJUSTING SCREWS CLOCKWISE
TO LOOSEN BELTS AND COUNTERCLOCKWISE
TO TIGHTEN BELTS.

A

CRUSHER DRIVE SHEAVE

NOTE: ADJUST DRIVE BELTS TO A 1 IN.
DEFLECTION UNDER NORMAL THUMB
PRESSURE AT A POINT MIDWAY
BETWEEN THE SHEAVES.

DRIVE BELT (10)

ENGINE DRIVE SHEAVE




Figure 84. Tension spring and gear box covers, removal and installation.

Section VII. MAIN DISCHARGE CONVEYOR ASSEMBLY

157. General


The main discharge conveyor assembly receives the crusher rock from the crusher jaws, and may receive the material from the diverter box for conveying out the rear of the jaw crusher. The main discharge conveyor consists of a conveyor belt, an electric motor, motor drive shafts, reducer gears, drive pulleys, head and tail crapper assemblies, impact troughing and return rollers, head and tail shaft assemblies, and conveyor frame.

159. Main Discharge Conveyor Drive Gear Reducer and Sheave Assembly

a. Removal.

- (1) Remove the main discharge conveyor drive belts (par. 129).
- (2) Remove the main discharge conveyor drive gear reducer and sheave assembly as instructed on figure 86.
- (3) Remove drive sheave from gear reducer as instructed on figure 86.

b. Cleaning and Inspection. Clean and inspect



ENC 3920-235-

A. Main conveyor belt troughing adjustment.

Figure 85. Main conveyor belt, adjustment.

- (2) Install drive gear reducer in reverse of instructions on figure 86.
- (3) Install the main discharge conveyor drive belts (par. 129).

160. Head Belt Scraper Assembly

a. Removal. Remove the head belt scraper assembly as instructed on figure 87.

b. Disassembly. Disassemble the head belt scraper as illustrated on figure 88.

c. Cleaning, Inspection, and Repair. Clean


e. Installation. Install the head belt scraper assembly in reverse of instructions on figure 87.

161. Tail Scraper Assembly

a. Removal. Remove the tail scraper assembly as instructed on figure 89.

b. Disassembly. Disassemble the tail scraper assembly as illustrated on figure 90.

c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Repair or replace ineffective or damaged part as required.



B

EMC 302G-2G5-20 2 86

B--Main conveyor belt tension adjustment

Figure 85—Continued.

162. Impact Roller Assemblies

a. Removal. Remove the impact roller assemblies as instructed on figure 91.

b. Disassembly. Disassemble the impact roller assemblies as illustrated on figure 92.

c. Cleaning, Inspection, and Repair. Clean and inspect all parts for damage or defects. Repair or replace as necessary.


d. Reassembly. Reassemble the impact roller

b. Disassembly. Disassemble the troughing roller assemblies as illustrated on figure 93.

c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Repair or replace defective or damaged parts as necessary.

d. Reassembly. Reassemble the troughing roller assemblies as illustrated on figure 94.

e. Installation. Install the troughing roller assemblies in reverse of instructions on figure 95.



REMOVE TURNBUCKLE.

REMOVE CAP SCREW.

REMOVE CAP SCREW (3).

REMOVE KEY.

REMOVE SCREW AND SLEEVE.

NOTE: INSTALL THREE SCREWS IN
THREADED HOLES; TURN SCREWS
IN TO REMOVE SHEAVE FROM
SHAFT.




Figure 86—Continued.






Figure 87. Head belt scraper assembly, removal and installation.




MSC 3820-205-20/2/

Figure 88. Head belt scraper assembly, exploded view.



EMC 3820-205-20/2/84

Figure 89. Tail scraper assembly, removal and installation.



MSC 3820-205-20/1/90

Figure 90. Tail scraper assembly, exploded view.




Figure 91. Impact roller assemblies, removal and installation.







Figure 92. Impact roller assemblies, exploded view.






MSC 3820-205-20/2/94

Figure 94. Troughing roller assemblies, exploded view.





MSC 3820-205-20

Figure 96. Return roller assembly, exploded view.

c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Repair or replace defective or damaged parts as necessary.

d. Reassembly. Reassemble the return roller assembly as illustrated on figure 96.

e. Installation. Install the return roller assembly in reverse of instructions on figure 95.

Section VIII. FRAME ASSEMBLY

165. General

The frame consists of the platforms, ladders, pintle hook and bracket, leveling jacks and supports, power cable and reel assembly, and toolbox.

166. Leveling Jacks and Supports

a. Removal. Remove the leveling jacks and supports as instructed on figure 97.

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged or defective parts as necessary.


167. Pintle Hook and Bracket

a. Removal. Remove the pintle hook and bracket as instructed on figure 98.

b. Disassembly. Disassemble the pintle hook and bracket as illustrated on figure 99.



c. Cleaning, Inspection, and Repair. Clean and inspect all parts. Replace or repair damaged or defective parts as necessary.

d. Reassembly. Reassemble the pintle hook and bracket as illustrated on figure 99.





ENC 382C-205-2C 2

Figure 97. Leveling jacks and support, removal and installation.



A





EMC 3820-205-20/2

Figure 99. Pintle hook, exploded view.

168. Toolbox


a. Removal. Remove the toolbox as instructed on figure 100.

b. Cleaning and Inspection. Clean and in-

169. Power Cable Reel Assembly

a. Removal.

(1) Remove clearance lights from power cable reel mounting.



EPT 3F20-215-2a 2 95

Figure 106. Toolbox, removal and installation.

- (3) Remove the power cable reel assembly as instructed on figure 101.

Disassembly. Disassemble the power cable assembly as illustrated on figure 102.

Cleaning, Inspection, and Repair. Clean inspect all parts. Repair or replace all aged or defective parts.

Reassembly. Reassemble the power cable assembly as illustrated on figure 102.

Installation.

- 1) Install the power cable reel assembly in reverse of instructions on figure 101.

- 2) Install the electrical conduit on the power cable reel mounting bracket (par. 125)

power cable reel mounting bracket (par. 125).

170. Ladders and Platforms

a. Removal.

- (1) Disconnect the electric power supply (TM 5-3820-205-10 2) before removing the ladders or platforms.
- (2) Remove the ladders and platforms as instructed on figure 103.

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged or defective parts.

c. Installation.

- (1) Install the platforms and ladders in reverse of instructions on figure 103.




Figure 101. Power cable reel assembly, removal and installation.







Figure 162. Power cable reel assembly, exploded view.





NOTE: REMOVE OPERATOR'S CONTROL
BOX FROM THE RAILING.



A

EMC 3820-205-20/2/98①

A—Upper platform grates and guard rails installed view
Figure 103. Ladders and platforms, removal and installation.


REMOVE FLOOR GRATE (2).


REMOVE CAP SCREW (24).

REMOVE CAP SCREW (8).

REMOVE CAP SCREW (8).


REMOVE GUARDRAIL





EMC 3820-205-20 2 96 (3)

C—Intermediate ladder installed view
Figure 103—Continued.




D

EMC 3820-205-20/2/98 ④


D—Battery box grating cover installed view

Figure 105—Continued.




E -Conveyor transport bracket and lower platform grating installed view

Figure 103—Continued.



F--Upper platform in the same manner
 Figure 103--Continued.



G. Lower platform ladder installed view

Figure 103---Continued.

Section IX. REAR WHEELS, TIRES, AND BRAKE ASSEMBLY

171. General

The rear wheels, tires, and brake assembly consists of wheels, tires, hub, slack adjusters, and brake assembly. The wheels are dual-type and separated by a spacer. The assembly is secured to the hub and brakedrum.

172. Rear Wheels and Tires

a. Removal. Remove the rear wheels and tires in the same manner as the dolly wheels and tires (par. 115a).

b. Cleaning, Inspection, and Repair. Clean and inspect, replace or repair the tires and wheels in the same manner as the dolly wheels and tires (par. 115b).

173. Rear Wheel Hub Assembly and Brakedrum

a. Removal.

- (1) Remove the rear wheel assembly (par. 172).
- (2) Remove and disassemble the bearings, hub, and brakedrum assembly (par. 116).

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged or defective parts. Lubricate wheel bearing (par. 116).

c. Installation.

- (1) Reassemble and install the

chamber (par. 139).

- (2) Remove slack adjuster as instructed on figure 104.

b. Cleaning and Inspection. Clean and inspect all parts. Replace all damaged or defective parts.

c. Installation.

- (1) Install the slack adjuster in reverse of instructions on figure 104.
- (2) Connect linkage to air brake chamber (par. 139).

d. Adjustment. Adjust the slack adjusters as instructed on figure 104.

(par. 116).


- (2) Remove the brake assembly as instructed on figure 105.


b. Cleaning, Inspection, and Adjustment. Clean and inspect all parts. Replace all damaged or defective or worn parts.

c. Installation.

- (1) Install the brake assembly as instructed on figure 105.
- (2) Install the wheel hub assembly (par. 116).

d. Adjustment. Adjust the slack adjusters as instructed on figure 104 (par. 174).





NOTE: REMOVE REMAINING BRAKE SHOE ASSEMBLIES IN A SIMILAR MANNER.

EMC 3820-205-20/2/100

Figure 105. Brake assembly, removal and installation.

CHAPTER 7

SHIPMENT AND LIMITED STORAGE

Section I. SHIPMENT WITHIN ZONE OF INTERIOR

176. Preparation of Jaw Crusher for Shipment

a. General. Detailed instructions for the preparation of the jaw crusher for domestic shipment are outlined within this paragraph. Preservation will be accomplished in sequence that will not require the operation of previously preserved components.

b. Inspection. The jaw crusher will be inspected for any unusual conditions such as damage, rusting, accumulation of water, and pilferage. Inspection shall be completed as outlined on the quarterly preventive maintenance Services. All deficiencies will be recorded on DA Form 2404 (Equipment Inspection and Maintenance Worksheet).

c. Cleaning and Drying. Clean and dry the jaw crusher by an approved method. Approved methods of cleaning and drying, types of preservatives, and methods of application are described in TM 38-230.

d. Painting. Paint all surfaces when the paint has been removed or damaged. Refer to TB ENG 60 for detailed cleaning and painting instructions.

e. Depreservation Guide. A properly annotated DA Form 2258 (Depreservation Guide of Engineer Equipment) will be completed concurrently with preservation for each item of mechanical equipment. Any peculiar requirements will be outlined in blank spaces 27 through 33. The completed depreservation guide will be placed in a waterproof envelope,

solution of 50 percent water to 50 percent ethylene glycol conforming to Specification MIL-PRC-1548.

Note. It is not necessary to drain the system if the solution is changed. If temperatures below -25°F are encountered, conforming to Specification MIL-PRC-1548 in its undiluted condition.

g. Lubrication System. If the oil level is low and no leaks are apparent, refer to lubrication chart and fill with the proper lubricant. Operate the engine at a fast speed until the lubricant has been circulated throughout the system.

h. Sealing of openings. Openings to permit the direct entry of water into the interior of engine-driven equipment, such as starters, engine, etc., shall be sealed with preservative tape conforming to Specification MIL-T-60, type 111, class 1.

i. Fuel Tank. If the fuel tank is empty, it will be fogged with type P-19, grade 2, preservative oil, conforming to MIL-PRC-1548. It is not necessary to drain fuel from the domestic shipment.

j. Hydraulic Control System and Hydraulic Brake.

- (1) Fully retract the piston rod until the linkage will permit an oil seal to be installed.
- (2) Coat exposed portion of the piston rod and operating valve controls with type P-6 preservative oil conforming to Specification MIL-PRC-11796, class 3. If possible, use a preservative solution of 50 percent water to 50 percent ethylene glycol conforming to Specification MIL-PRC-1548.

n. Batteries and Cables. Batteries will be secured in compartments. Batteries will be filled and fully charged. Cables will be disconnected and secured so as to prevent contact with the terminals.

o. Pneumatic Tires. Tires will be inflated to their normal required operating pressure.

p. Air Receivers. Remove pipe plugs from tanks and spray or fog the tank interior with type P-10, grade 2, engine preservative oil conforming to Specification MIL-L-21260 and re-install. Open draincock to allow excess preservative oil to drain. Leave draincock open to allow condensation to drain.

q. Disassembly, Disassembled Parts, Basic Issue Items.

- (1) Disassembly will be limited to the removal of parts and projecting com-

equipment to prevent movement. Shroud exposed hose not protected by storage facilities with waterproof Kraft wrapping paper (UU P-271).

177. Loading Jaw Crusher for Shipment

a. Construct a ramp of suitable material as illustrated on figure 3, and tow the jaw crusher onto the carrier as instructed in paragraph 6.

b. If a loading ramp or material is not available and a suitable lifting device illustrated on figure 4 is used, the equipment will be loaded as follows:

- (1) Attach lifting cables to jaw crusher as instructed in paragraph 6.
- (2) Lift the jaw crusher and place it in the center of the carrier.
- (3) Remove lifting cables from the jaw crusher. Block and secure the jaw crusher as illustrated on figure 2.

Section II. LIMITED STORAGE

78. Preparation of Jaw Crusher for Storage

a. General. Detailed instructions for preparing the jaw crusher for limited storage is outlined in this paragraph. Limited storage is defined as storage not to exceed 6 months. Refer to AR 743-505.

b. Inspection. Refer to paragraph 176b.

c. Cleaning and Drying. Refer to paragraph 176c.

d. Painting. Refer to paragraph 176d.

e. Depreservation Guide. Refer to paragraph 176e.

f. Cooling System. Refer to paragraph 176f.

g. Lubrication System. Refer to paragraph 176g.

h. Sealing of Openings. Refer to paragraph 176h.

i. Fuel Tank. Tanks will be drained and sprayed or fogged with type P-10, grade 2, engine preservative oil conforming to Specification MIL-L-21260.

j. Hydraulic Control System; Except Hydraulic Brake. Refer to paragraph 176j.

k. Exterior Surfaces. Refer to paragraph 176l.

3. Fire Protection

FM 5-687 Repairs and Utilities: Fire Protection Equipment and Appliances; Inspections, Operations, and Preventive Maintenance.
FM 9-1799 Ordnance Maintenance: Fire Extinguishers.

4. Lubrication

LO 5-3820-205-20/2 Lubrication Order.

5. Operating Instructions

FM 5-3820-205-10/2 Operator's Manual.

6. Painting and Preservation

FB ENG 60 Preservation and Painting of Serviceable Corps of Engineers Equipment.
FM 9-213 Painting Instructions for Field Use.

7. Preventive Maintenance

AR 750-5 Organization, Policies, and Responsibilities for Maintenance Operations.
FM 9-1870-1 Care and Maintenance of Pneumatic Tires.
FM 9-6140-200-15 Storage Batteries, Lead-Acid Type.
FM 38-750 The Army Equipment Records System and Procedures.

8. Publication Indexes

DA Pam 108-1 Index of Army Motion Pictures, Film Strips, Slides, and Phono-Recordings.
DA Pam 310-1 Index of Administrative Publications.
DA Pam 310-2 Index of Blank Forms.
DA Pam 310-3 Index of Doctrinal, Training, and Organizational Publications.
DA Pam 310-4 Index of Technical Manuals, Technical Bulletins, Supply Manuals, (types 4, 6, 7, 8, and 9), Supply Bulletins, Lubrication Orders, and Modification Work Orders.
DA Pam 310-5 Index of Graphic Training Aids and Devices.
DA Pam 310-25 Index of Supply Manuals—Corps of Engineers.

II. Training Aids

FM 5-25

Explosives and Demolitions.

FM 21-5

Military Training.

FM 21-6

Techniques of Military Instruction.

FM 21-30

Military Symbols.

APPENDIX II

MAINTENANCE ALLOCATION CHART

Section I. INTRODUCTION

1. General

This Appendix contains explanations of all maintenance and repair functions authorized for the various echelons. Section II contains the maintenance allocation chart.

2. Maintenance

Maintenance is any action taken to keep material in a serviceable condition or to restore it to serviceability when it is unserviceable. Maintenance of material includes the following:

a. Service. To clean, preserve, and replenish fuel and lubricants.

b. Adjust. To regulate periodically to prevent malfunction.

c. Inspect. To verify serviceability and detect incipient electrical or mechanical failure by scrutiny.

d. Test. To verify serviceability and detect incipient electrical or mechanical failure by use of special equipment such as gages, meters, and the like.

e. Replace. To substitute serviceable assemblies, subassemblies, and parts for unserviceable components.

f. Repair. To restore an item to serviceable condition through correction of a specific failure or unserviceable condition. This function includes, but is not limited to, inspecting, clean-

weapons system, or components of a weapon system.

i. Overhaul. To restore an item to completely serviceable condition as prescribed by serviceability standards developed and published by heads of technical services. This is accomplished through employment of the technique of "Inspect and Repair Only as Necessary" (IROAN). Maximum utilization of diagnostic and test equipment is combined with minimum disassembly of the item during the overhaul process.

3. Explanation of Columns

a. Functional Group. The functional group is a numerical group set up on a functional basis. The applicable functional grouping indexes (obtained from the Mobility Command functional grouping indexes) are listed on the maintenance allocation chart in the appropriate numerical sequence. These indexes normally are set up in accordance with their function and proximity to each other.

b. Components and Related Operation. This column contains the Functional Grouping Index heading, subgroup headings, and a brief description of the part starting with the normal name. It also designates the operations to be performed such as service, adjust, inspect, test, replace, repair, and overhaul.

indicated functions of lower echelons.

the operation being performed.

| Functional group | Components and related operation | Echelons of maintenance | | | | | Remarks |
|------------------|---|-------------------------|---|---|---|---|---------------------------------|
| | | 1 | 2 | 3 | 4 | 5 | |
| 1 | ENGINE | | | | | | |
| 0100 | ENGINE ASSEMBLY | | | | | | |
| | Engine, Diesel | | | | | | |
| | Service ----- | X | | | | | |
| | Inspect ----- | X | | | | | |
| | Test ----- | | | X | | | Compression. |
| | Replace ----- | | | | X | | |
| | Repair ----- | | | X | | | |
| | Overhaul ----- | | | | X | | |
| 0101 | CRANKCASE, BLOCK, CYLINDER HEAD | | | | | | |
| | Cylinder and Crankcase Assembly | | | | | | |
| | Repair ----- | | | X | | | |
| | Sleeves, Cylinder | | | | | | |
| | Replace ----- | | | | X | | |
| | Head, Cylinder | | | | | | |
| | Replace ----- | | | X | | | |
| | Repair ----- | | | X | | | |
| 0102 | CRANKSHAFT | | | | | | |
| | Crankshaft Assembly | | | | | | |
| | Replace ----- | | | | X | | |
| | Repair ----- | | | | | X | Metalizing, grinding, aligning. |
| | Pulley and Damper, Vibration | | | | | | |
| | Replace ----- | | | X | | | |
| | Bearings, Main | | | | | | |
| | Replace ----- | | | | X | | |
| 0103 | FLYWHEEL ASSEMBLY | | | | | | |
| | Flywheel Assembly | | | | | | |
| | Repair ----- | | | | X | | Replacing ring gear. |
| 0104 | PISTONS, CONNECTING RODS | | | | | | |
| | Pistons; Rings; Pins; Retainers; Bearings | | | | | | |
| | Replace ----- | | | | X | | |
| | Rods, Connecting | | | | | | |
| | Replace ----- | | | | X | | |
| | Repair ----- | | | | X | | |
| 0105 | VALVES, CAMSHAFTS AND TIMING SYSTEM | | | | | | |
| | Valves and Seats | | | | | | |
| | Replace ----- | | | | X | | |
| | Repair ----- | | | | X | | |

| | | | | | |
|------|---|---|---|---|---|
| | Replace | | X | | |
| | Rods, Push | | | X | |
| | Replace | | | | |
| | Followers, Cam; Camshaft; Bearings; Gears; Seals; Cover | | | | |
| | Replace | | | | X |
| 0106 | ENGINE LUBRICATION SYSTEM | | | | |
| | Pump, Oil | | | | |
| | Replace | | | | X |
| | Repair | | | | X |
| | Filter Assembly, Oil | | | | |
| | Service | X | | | |
| | Replace | | X | | |
| | Cooler, Oil | | | | |
| | Replace | | X | | |
| | Valve, By-pass | | | | |
| | Replace | | X | | |
| | Breather | | | | |
| | Service | X | | | |
| | Replace | | X | | |
| | Pan, Oil | | | | |
| | Replace | | | | X |
| | Lines | | | | |
| | Replace | | X | | |
| | Gage, Level | | | | |
| | Replace | X | | | |
| 0107 | ENGINE STARTING SYSTEM | | | | |
| | Crank, Hand | | | | |
| | Replace | | X | | |
| | Support Assembly | | | | |
| | Repair | | X | | |
| 0108 | MANIFOLDS | | | | |
| | Manifolds | | | | |
| | Replace | | X | | |
| 02 | CLUTCH ASSEMBLY | | | | |
| 0200 | CLUTCH ASSEMBLY | | | | |
| | Clutch Assembly | | | | |
| | Service | X | | | |
| | Adjust | X | | | |
| | Repair | | | X | |
| | Disks | | | | |
| | Replace | | | X | |
| | Repair | | | X | |
| | Plates | | | | |
| | Replace | | | X | |
| 0202 | CLUTCH RELEASE MECHANISM | | | | |
| | Shaft, Cross; Yoke, Throwout | | | | |
| | Replace | | | X | |
| | Lever | | | | |
| | Replace | | X | | |
| 03 | FUEL SYSTEM | | | | |

Exter

| | | | | | |
|------|---|---|---|---|--|
| 0802 | FUEL PUMPS Injection Pump, Diesel | | X | | |
| | Replace ----- | | | X | |
| | Repair ----- | | | | |
| | Drive, Injection Pump | | | X | |
| | Replace ----- | | | X | |
| | Repair ----- | | | | |
| 0804 | AIR CLEANER Air Cleaner Assembly | X | | | |
| | Service ----- | | X | | |
| | Repair ----- | | | | |
| 0806 | TANKS, LINES, FITTINGS Tank, Fuel | X | | | |
| | Service ----- | | X | | |
| | Replace ----- | | | | |
| | Cap, Fuel Tank | | X | | |
| | Replace ----- | | | | |
| | Lines | | X | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | | |
| | Fittings | | X | | |
| | Replace ----- | | | | |
| 0808 | ENGINE SPEED GOVERNOR----- | | | | |
| 0809 | FUEL FILTERS Filter Assembly | X | | | |
| | Service ----- | | X | | |
| | Replace ----- | | | | |
| 0811 | ENGINE STARTING AIDS Starting Aid, Ether | X | | | |
| | Service ----- | | X | | |
| | Replace ----- | | | | |
| | Lines and Fittings | | X | | |
| | Replace ----- | | | | |
| 0812 | THROTTLE CONTROLS Controls, Throttle | | X | | |
| | Replace ----- | | | | |
| 04 | EXHAUST SYSTEM | | | | |
| 0401 | MUFFLER AND PIPES Muffler and Pipes, Exhaust | | X | | |
| | Replace ----- | | | | |
| 05 | COOLING SYSTEM | | | | |
| 0501 | RADIATOR Radiator Assembly | X | | | |
| | Service ----- | | X | | |
| | Inspect ----- | | | X | |

| | | | | | |
|------|------------------------------------|---|---|---|---|
| 0503 | HEADERS, THERMOSTATS AND GASKET | | | | |
| | Thermostat | | | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| | Fittings; Hoses; Clamps; Header | | | | |
| | Replace ----- | | X | | |
| 0504 | WATER PUMP | | | | |
| | Pump Assembly, Water | | | | |
| | Service ----- | X | | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | X | |
| 0505 | FAN ASSEMBLY | | | | |
| | Fan, Engine Cooling | | | | |
| | Replace ----- | | X | | |
| | Guard, Fan | | | | |
| | Replace ----- | | X | | |
| | Belts, Fan | | | | |
| | Adjust ----- | X | | | |
| | Replace ----- | | X | | |
| 06 | ELECTRICAL SYSTEM | | | | |
| 0601 | GENERATOR | | | | |
| | Generator Assembly | | | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | X | |
| | Brushes | | | | |
| | Replace ----- | | X | | |
| 0602 | GENERATOR REGULATOR | | | | |
| | Regulator, Generator | | | | |
| | Adjust ----- | | X | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| 0603 | STARTING MOTOR | | | | |
| | Starter Assembly | | | | |
| | Service ----- | X | | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | X | |
| | Brushes; Solenoid | | | | |
| | Replace ----- | | X | | |
| 0606 | ENGINE SAFETY CONTROLS | | | | |
| | Switch, Engine Safety Control | | | | |
| | Replace ----- | | X | | |
| | Governor, Overspeed | | | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | | X |
| 0607 | INSTRUMENT OR ENGINE CONTROL PANEL | | | | |
| | Gages; Switches | | | | |
| | Replace ----- | | X | | |

| | | | | | |
|------|--------------------------------|---|---|---|--|
| 0609 | LIGHTS | | | | |
| | Lamps; Doors; Lens; Lights | | | | |
| | Replace ----- | | X | | |
| 0610 | SENDING UNITS | | | | |
| | Sending Units | | | | |
| | Replace ----- | | X | | |
| 0612 | BATTERIES | | | | |
| | Batteries | | | | |
| | Service ----- | X | | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| | Box; Cables | | | | |
| | Repair ----- | | X | | |
| 0613 | HULL OR CHASSIS WIRING HARNESS | | | | |
| | Wiring, Chassis | | | | |
| | Repair ----- | | X | | |
| | Coupling, Trailer Electrical | | | | |
| | Replace ----- | | X | | |
| | Repair ----- | | X | | |
| 0615 | RADIO INTERFERENCE SUPPRESSION | | | | |
| | Components | | | | |
| | Test ----- | | X | | |
| | Replace ----- | | X | | |
| 0 | FRONT AXLE | | | | |
| 1000 | FRONT AXLE ASSEMBLY | | | | |
| | Dolly; Drawbar; Lanette | | | | |
| | Replace ----- | | X | | |
| | Axle; Frame | | | | |
| | Replace ----- | | | X | |
| 11 | REAR AXLE | | | | |
| 1100 | REAR AXLE ASSEMBLY | | | | |
| | Axle Assembly, Rear | | | | |
| | Repair ----- | | | X | |
| 1108 | WALKING BEAMS | | | | |
| | Beams, Walking | | | | |
| | Service ----- | X | | | |
| | Repair ----- | | | X | |
| 12 | BRAKES | | | | |
| 1202 | SERVICE BRAKES | | | | |
| | Brakes Assemblies | | | | |
| | Repair ----- | | X | | |
| 1206 | MECHANICAL BRAKE SYSTEM | | | | |
| | Slack Adjusters | | | | |
| | Service ----- | X | | | |
| | Adjust ----- | | X | | |
| | Replace ----- | | X | | |

| | | | | |
|------|---|---|---|---|
| | Chambers, Air | | X | |
| | Replace ----- | | X | |
| | Repair ----- | | | X |
| | Valve, Relay | | | |
| | Replace ----- | | X | |
| | Repair ----- | | | X |
| | Filters, Air | | | |
| | Service ----- | X | | |
| | Replace ----- | | X | |
| | Reservoir, Air | | | |
| | Service ----- | X | | |
| | Replace ----- | | X | |
| | WHEELS | | | |
| 311 | WHEEL ASSEMBLY | | | |
| | Wheel Assemblies | | | |
| | Service ----- | | X | |
| | Repair ----- | | X | |
| 313 | TIRES, TUBES | | | |
| | Tires | | | |
| | Service ----- | X | | |
| | Replace ----- | | X | |
| | Tubes | | | |
| | Replace ----- | | X | |
| | Repair ----- | | X | |
| | FRAME, TOWING ATTACHMENTS | | | |
| 501 | FRAME ASSEMBLY | | | |
| | Frame Assembly | | | |
| | Replace ----- | | | X |
| | Platforms; Ladders | | | |
| | Replace ----- | | X | |
| 503 | PINTLES | | | |
| | Hooks, Pintle | | | |
| | Service ----- | X | | |
| | Repair ----- | | X | |
| 506 | FIFTH WHEEL | | | |
| | Fifth Wheel Assembly | | | |
| | Service ----- | X | | |
| | Repair ----- | | X | |
| | BASIC ISSUE ITEMS, MANUFACTURER INSTALLED | | | |
| 100 | BASIC ISSUE ITEMS, MANUFACTURER OR DEPOT INSTALLED | | | |
| | Accessories | | | |
| | Replace ----- | | X | |
| | BASIC ISSUE ITEMS TROOP INSTALLED | | | |
| 3200 | BASIC ISSUE ITEMS TROOP INSTALLED OR AUTHORIZED | | | |
| | Accessories; Common Tools; Publications | | | |

| 18 | HOOD | 1 | 2 | 3 | 4 |
|------|---|---|---|---|---|
| 1801 | HOOD | | | | |
| | Housing Assembly | | | | |
| | Replace ----- | | X | | |
| 1808 | STOWAGE RACKS, BOXES | | | | |
| | Box, Tool | | | | |
| | Replace ----- | | X | | |
| | Reel, Power Cable | | | | |
| | Repair ----- | | X | | |
| 22 | ACCESSORY ITEMS | | | | |
| 2202 | ACCESSORY ITEMS | | | | |
| | Reflectors | | | | |
| | Replace ----- | | X | | |
| | Cables and Hose | | | | |
| | Replace ----- | | X | | |
| 2210 | DATA PLATES AND INSTRUCTION HOLDERS | | | | |
| | Plates, Data | | | | |
| | Replace ----- | | | X | |
| | Plates, Identification and Instruction; Holder, Instruction | | | | |
| | Replace ----- | | X | | |
| 40 | ELECTRIC MOTORS | | | | |
| 4000 | MOTOR ASSEMBLY | | | | |
| | Service ----- | X | | | |
| | Replace ----- | | X | | |
| | Repair ----- | | | X | |
| | Overhaul ----- | | | | X |
| 4001 | ROTOR ASSEMBLIES | | | | |
| | Rotor | | | | |
| | Replace ----- | | | X | |
| 4002 | STATOR ASSEMBLIES | | | | |
| | Stator Assemblies | | | | |
| | Replace ----- | | | X | |
| | Repair ----- | | | | X |
| 4004 | VENTILATING SYSTEM | | | | |
| | Guard, Dust | | | | |
| | Replace ----- | | X | | |
| | Fan, Cooling | | | | |
| | Replace ----- | | | X | |
| 4006 | FRAME SUPORTS AND HOUSINGS | | | | |
| | End Assembly; Frame, Center | | | | |
| | Replace ----- | | | X | |
| | Repair ----- | | | | X |
| | Box, Junction | | | | |
| | Replace ----- | | X | | |
| 4007 | DRIVE COMPONENTS | | | | |
| | Pulley | | | | |
| | Replace ----- | | X | | |
| | Belts | | | | |
| | Adjust ----- | X | | | |
| | Replace ----- | | X | | |
| 4009 | CONTROL PANELS | | | | |
| | Panel, Main Control | | | | |

| | | | | |
|------|--|--|---|---|
| 4018 | Replace | | | X |
| | TERMINAL BLOCKS | | | |
| | Conduit, Power; Connectors; Receptacle | | | |
| | Replace | | | X |
| | Cable, Power | | | |
| | Replace | | X | |
| | Wiring | | | |
| | Repair | | X | |
| 43 | HYDRAULIC SYSTEMS | | | |
| 4300 | HYDRAULIC SYSTEM | | | |
| | System, Hydraulic | | | |
| | Service | | X | |
| | Inspect | | X | |
| 4301 | HOSE | | | |
| | Hose | | | |
| | Replace | | X | |
| 4302 | PUMP | | | |
| | Pump and Mounting Parts | | | |
| | Repair | | X | |
| 4307 | HYDRAULIC CYLINDERS | | | |
| | Cylinder, Hydraulic | | | |
| | Repair | | | X |
| 4308 | RESERVOIRS | | | |
| | Reservoir, Oil | | | |
| | Service | | X | |
| | Replace | | X | |
| 47 | GAGES; MEASURING DEVICES | | | |
| 4701 | INSTRUMENTS SPEED | | | |
| | Tachometer and Hour-meter Combination | | | |
| | Replace | | X | |
| | Tachometer Drive | | | |
| | Replace | | X | |
| | Repair | | X | |
| 4702 | GAGES | | | |
| | Gage, Fuel | | | |
| | Replace | | X | |
| 75 | CRUSHING EQUIPMENT COMPONENTS | | | |
| 7501 | BELTING | | | |
| | Belts, Main Drive | | | |
| | Adjust | | X | |
| | Replace | | X | |
| | Pulley, Main Drive | | | |
| | Replace | | | X |
| | Guards and Attaching Parts | | | |
| | Replace | | X | |
| | Conveyor Assembly, Discharge | | | |
| | Repair | | X | |
| | Frame, Conveyor; Hopper | | | |
| | Replace | | | X |
| | Belting | | | |
| | Adjust | | X | |
| | Replace | | | X |

| Functional group | Components and related operation | 1 | 2 | 3 | 4 | 5 | |
|------------------|----------------------------------|---|---|---|---|---|-----------------------|
| | | | | | | | |
| 7503 | PULLEYS | | | | | | Conveyor head pulley. |
| | Bearings | X | | | | | |
| | Service ----- | | | X | | | |
| | Replace ----- | | | | | | |
| | Shaft and Pulley----- | | | | | | |
| | Replace ----- | | | X | | | |
| 7504 | ROLLS | | | | | | |
| | Roller Assembly | | X | | | | |
| | Repair ----- | | | | | | |
| 7506 | SHAFTS | | | | | | |
| | Gear Assembly, Conveyor Drive | X | | | | | |
| | Service ----- | | X | | | | |
| | Replace ----- | | | X | | | |
| | Repair ----- | | | | | | |
| | Pulleys ----- | | X | | | | |
| | Replace ----- | | | | | | |
| 7510 | FEEDING FRAMES | | | | | | |
| | Feeder Assembly | | | X | | | |
| | Repair ----- | | | | | | |
| | Hopper | | | X | | | |
| | Replace ----- | | | | | | |
| 7512 | FEEDING SHAFTS | | | | | | |
| | Gear Assembly, Feeder Drive | X | | | | | |
| | Service ----- | | | X | | | |
| | Replace ----- | | | X | | | |
| | Repair ----- | | | | | | |
| | Pulleys ----- | | | X | | | |
| | Replace ----- | | | | | | |
| | Arm, Torque; Foot; Turn Buckle | | X | | | | |
| | Replace ----- | | | | | | |
| 7516 | PAN FEEDER | | | | | | |
| | Apron Assembly | X | | | | | |
| | Service ----- | | X | | | | |
| | Repair ----- | | | | | | |
| | Rollers | | | X | | | |
| | Replace ----- | | | X | | | |
| | Repair ----- | | | | | | |
| | Bars; Pins | | | X | | | |
| | Replace ----- | | | | | | |
| 7520 | CRUSHER FRAMES | | | | | | |
| | Crusher Assembly | X | | | | | |
| | Service ----- | X | | | | | |
| | Inspect ----- | | | X | | | |
| | Repair ----- | | | | | | |
| | Frame | | | | | X | |
| | Replace ----- | | | | | | |
| | Springs ----- | | | X | | | |

| | | | | | |
|------|------------------------------------|--|--|---|---|
| | Replace | | | | X |
| | Seats and Plates, Toggle | | | | |
| | Replace | | | X | |
| | Pitman | | | | |
| | Repair | | | | X |
| | Gear Box Assembly, Jaw Adjust | | | | |
| | Replace | | | X | |
| | Repair | | | X | |
| 7523 | SHAFTS | | | | |
| | Shaft Assemblies | | | | |
| | Replace | | | | X |
| | Bearing and Seals | | | | |
| | Replace | | | | X |
| | Wheel, Balance | | | | |
| | Replace | | | X | |
| 7525 | SCREENING BASE, BOX | | | | |
| | Box and Plates | | | | |
| | Replace | | | | X |
| | Rail, Center and Crossmember, Feed | | | | |
| | Replace | | | X | |
| | Mounting, Rubber | | | | |
| | Replace | | | X | |
| | Deflector, Rubber | | | | |
| | Replace | | | X | |
| | Underhopper | | | | |
| | Replace | | | | X |
| | Box Divert; Chute; Gate | | | | |
| | Replace | | | X | |
| 7528 | SCREENS AND ATTACHING PARTS | | | | |
| | Screens | | | | |
| | Replace | | | X | |
| | Bar, Grizzly | | | | |
| | Replace | | | X | |
| | Screen Assembly, Vibrating | | | | |
| | Repair | | | X | |
| 7529 | ECCENTRIC OR GYRATOR SHAFT | | | | |
| | Shaft Assembly | | | | |
| | Service | | | X | |
| | Replace | | | | X |
| | Bearings | | | | |
| | Replace | | | | X |
| | Guard and Pulley | | | | |
| | Replace | | | X | |
| | Wheel, Balance | | | | |
| | Replace | | | X | |
| 76 | FIRE FIGHTING EQUIPMENT | | | | |
| 7603 | FIRE EXTINGUISHERS | | | | |

INDEX

| | Paragraph | Page | | Page |
|-----------------------------------|--------------|------|-------------------------------------|---------|
| Adjustments: | | | Crusher electrical system: | |
| Brake assembly adjustment..... | 175 <i>d</i> | 135 | Pan feeder drive motor | |
| Drive belts adjustment..... | 155 <i>a</i> | 105 | and belts | |
| Fan belts adjustment..... | 104 <i>d</i> | 69 | Power cable | |
| Generator regulator adjustment.. | 83 <i>d</i> | 46 | Push button controls | |
| Main discharge conveyor | | | Scalper vibrating screen drive | |
| adjustment | 158 | 108 | motor and belts..... | |
| Pan feeder apron adjustment.... | 145 <i>d</i> | 98 | Taillights | |
| Rocker arm adjustment..... | 101 <i>b</i> | 66 | Troubleshooting | 35, 38, |
| Slack adjuster adjustment..... | 174 <i>e</i> | 135 | Crusher unit assembly: | |
| Tension spring adjustment..... | 156 <i>d</i> | 105 | Drive belt guard assembly..... | |
| Air brake chamber..... | 139 | 93 | Drive belts | |
| Air cleaner | 69 | 33 | General | |
| Air cleaner indicator..... | 60 | 26 | Tension spring | |
| Air filter | 141 | 93 | Description | |
| Air hoses and fittings..... | 117 | 78 | Difference in models..... | |
| Air system: | | | Discharge conveyor drive motor | |
| Air brake chamber..... | 139 | 93 | and belts | |
| Air filter | 141 | 93 | Diverter box, chutes, and gate..... | |
| Air tank | 142 | 93 | Dolly assembly: | |
| Couplings and hoses..... | 143 | 97 | Air hoses and fittings..... | |
| General | 138 | 93 | Dolly assembly | |
| Relay valve | 140 | 93 | Dolly wheels and tires..... | |
| Troubleshooting | 43 | 22 | Drawbar | |
| Air tank | 142 | 93 | Fifth wheel | |
| Batteries and cables..... | 80 | 45 | General | |
| Battery box | 81 | 45 | Lunette | |
| Battery charging receptacle..... | 82 | 45 | Reflectors | |
| Battery generator indicator..... | 89 | 54 | Safety chains | |
| Blackout taillight | 124 | 82 | Wheel bearings and hub | |
| Brake assembly | 175 | 135 | assemblies | |
| Clearance (Marker) lights and | | | Dolly assembly | |
| electrical conduit | 125 | 82 | Dolly electrical connector..... | |
| Couplings and lines..... | 143 | 97 | Dolly electrical system: | |
| Crankcase breather | 74 | 42 | Dolly electrical connector..... | |
| Crusher electrical connector..... | 126 | 82 | General | |
| Crusher electrical system: | | | Tail and blackout lights, and | |
| Blackout taillight | 124 | 82 | dolly electrical leads..... | |
| Clearance | 125 | 82 | Dolly wheel and tires..... | |
| Crusher electrical connector..... | 126 | 82 | Doors | |
| | | | Drawbar | |
| | | | Drive belt guard assembly..... | |
| | | | Drive belts | |
| | | | Eccentric shaft balance wheels..... | |

| | | | | |
|--|------------|--------|--|-----|
| Thermostat and housing | 107 | 70 | Ladders and platforms | 170 |
| Troubleshooting | 25, 26 | 20 | Leveling jacks and supports | 166 |
| Water manifold | 108 | 70 | Pintle hook and bracket | 167 |
| Engine door supports and side panels | 97 | 62 | Power cable reel assembly | 169 |
| Engine electrical system: | | | Toolbox | 168 |
| Batteries and cables | 80 | 45 | Fuel filters | 67 |
| Battery box | 81 | 45 | Fuel gage | 58 |
| Battery and charging receptacle | 82 | 45 | Fuel injectors | 65 |
| Battery generator indicator | 89 | 54 | Fuel line and fittings | 69 |
| Engine wiring and warning lights | 93 | 55 | Fuel pumps | 59 |
| General | 79 | 45 | Fuel system: | |
| Generator and bracket | 84 | 50 | Air cleaner | 63 |
| Generator regulator | 83 | 45 | Ether starting aids | 66 |
| Oil pressure gage and sending unit | 87 | 53 | Fuel filters | 67 |
| Overspeed governor | 90 | 51 | Fuel injectors | 65 |
| Safety switch and water temperature sending unit | 91 | 54 | Fuel line and fittings | 69 |
| Starter | 86 | 52 | Fuel tank and cap | 68 |
| Starter solenoid | 85 | 51 | General | 62 |
| Starter switch | 92 | 54 | Intake manifolds | 64 |
| Troubleshooting | 22, 30, 33 | 20, 21 | Troubleshooting | 27 |
| Water temperature gage and sending unit | 88 | 53 | Fuel tank and cap | 68 |
| Engine housing: | | | Generator and bracket | 84 |
| Doors | 96 | 62 | Generator regulator | 83 |
| Engine door supports and side panels | 97 | 62 | Grizzly bars | 150 |
| General | 94 | 62 | Hand cranking assembly | 61 |
| Hood, radiator cowl, and rear panel | 98 | 63 | Head belt scraper assembly | 160 |
| Water drain lines | 95 | 62 | Hood, radiator cowl, and rear panel: | |
| Engine lubrication system: | | | Cleaning, inspection, and repair | 98c |
| Crankcase breather | 74 | 42 | Hood and radiator cowl, installation | 98d |
| General | 70 | 41 | Hood, and radiator cowl, removal | 98a |
| Oil cooler | 73 | 42 | Rear panel installation | 98c |
| Oil cooler bypass valve | 72 | 41 | Rear panel removal | 98b |
| Oil lifters and mounting bracket | 71 | 41 | Hydraulic cylinder and hose | 137 |
| Oil lines and fittings | 75 | 42 | Hydraulic hose, pump and valve | 135 |
| Engine wiring and warning lights | 93 | 55 | Hydraulic system: | |
| Ether starting aids | 66 | 35 | General | 134 |
| Exhaust pipe and manifold | 78 | 44 | Hydraulic cylinder and hose | 137 |
| Exhaust system: | | | Hydraulic hose, pump, and valve | 135 |
| Exhaust pipe and manifold | 78 | 44 | Hydraulic tank | 136 |
| General | 76 | 44 | Troubleshooting | 41 |
| Muffler assembly | 77 | 44 | Hydraulic tank | 136 |
| Fan and water pump | 105 | 69 | Identification and tabulated data | 4 |
| Fan belts | 104 | 68 | Impact roller assemblies | 162 |
| Fan guard | 103 | 67 | Inspection and maintenance of jaw crusher in storage | 179 |
| | | | Installation of separately packed components | 9 |
| | | | Intake manifolds | 64 |

| | | | |
|--|-----|-----|--|
| Lubricating the adjusting gearboxes | 17 | 14 | Pan feeder drive motor and belts |
| Lubricating the starter inboard bearings | 18 | 14 | Pintle hook and bracket |
| Lubricating the wheel bearing assemblies | 16 | 14 | Power cable |
| Lubrication: | | | Power cable reel assembly |
| General | 15 | 14 | Preparation of jaw crusher for shipment: |
| Lubricating the adjusting gearboxes | 17 | 14 | Air cleaner |
| Lubricating the starter inboard bearings | 18 | 14 | Air receivers |
| Lubricating the wheel bearing assemblies | 16 | 14 | Batteries and cables |
| Lunette | 119 | 79 | Cleaning and drying |
| Main discharge conveyor assembly: | | | Cooling system |
| General | 157 | 108 | Depreservation guide |
| Head belt scraper assembly | 160 | 109 | Disassembly, disassembled parts, basic issue items |
| Impact roller assemblies | 162 | 110 | Exterior surfaces |
| Main discharge conveyor belt adjustment | 158 | 108 | Fuel tank |
| Main discharge conveyor drive gear reducer and sheave assembly | 159 | 108 | General |
| Return roller assembly | 164 | 110 | Hoses and couplings |
| Tail scraper assembly | 161 | 109 | Hydraulic control system, except hydraulic brake |
| Troughing roller assemblies | 163 | 110 | Inspection |
| Main discharge conveyor drive gear reducer and sheave assembly | 159 | 108 | Lubrication system |
| Main electrical emergency stop control button | 133 | 84 | Markings |
| Magnetic starter | 130 | 83 | Painting |
| Manual and mechanical controls and instruments: | | | Pneumatic tires |
| Air cleaner indicator | 60 | 26 | Sealing of openings |
| Engine clutch levers | 55 | 25 | Preparation of jaw crusher for storage: |
| Fuel gage | 58 | 26 | Air receivers |
| Fuel pumps | 59 | 26 | Batteries and cables |
| General | 54 | 25 | Cleaning and drying |
| Hand cranking assembly | 61 | 27 | Cooling system |
| Tachometer-hourmeter and drive | 57 | 25 | Depreservation guide |
| Throttle control lever | 56 | 25 | Disassembly, disassembled parts, basic issue items |
| Movement to a new worksite: | | | Draining of equipment |
| Dismantling for movement | 11 | 13 | Exterior surfaces |
| Reinstallation after movement to a new worksite | 12 | 13 | Fuel tank |
| Muffler assembly | 77 | 44 | General |
| Oil cooler | 73 | 42 | Hoses and couplings |
| Oil cooler bypass valve | 72 | 41 | Hydraulic control system; except hydraulic brake |
| | | | Inspection |
| | | | Lubrication |
| | | | Painting |
| | | | Pneumatic tires |
| | | | Sealing of openings |
| | | | Weatherproofing |
| | | | Preventive maintenance services: |
| | | | General |
| | | | Quarterly preventive maintenance services |



| | | | | | |
|--|-----|-----|--|--------------------|--------|
| Replacement of suppression components | 52 | 23 | Shipment within zone of interior: Loading jaw crusher for shipment | 177 | 138 |
| Testing of radio interference suppression components | 53 | 23 | Preparation of jaw crusher for shipment | 176 | 137 |
| Rear wheel hub assembly and brakedrum | 173 | 134 | Slack adjusters: | | |
| Rear wheels and tires | 172 | 134 | Special tools and equipment: | | |
| Rear wheel, tires and brake assembly: | | | Organizational maintenance | | |
| Brake assembly | 175 | 135 | repair parts | 14 | 14 |
| General | 171 | 134 | Special tools and equipment | 13 | 14 |
| Rear wheel hub assembly and brakedrum | 173 | 134 | Starter | 86 | 52 |
| Rear wheels and tires | 172 | 134 | Starter solenoid | 85 | 51 |
| Slack adjusters | 174 | 135 | Starter switch | 92 | 54 |
| Record and report forms | 2 | 3 | Tables: | | |
| Reflectors | 120 | 79 | Freezing points, composition, and specific gravities of military antifreeze materials, table 1 | 8i | 10 |
| Relay valve | 140 | 93 | Tachometer-hourmeter and drive | 57 | 25 |
| Replacement of suppression components | 52 | 23 | Tail and blackout lights, and dolly electrical leads | 111 | 72 |
| Return roller assembly | 164 | 110 | Taillights | 123 | 82 |
| Rocker arm adjustment | 101 | 66 | Tail scraper assembly | 161 | 109 |
| Safety chains | 121 | 79 | Tension spring | 156 | 105 |
| Safety switch and water temperature sending unit | 91 | 54 | Thermostat and housing | 107 | 70 |
| Scalper vibrating screen assembly: | | | Throttle control lever | 56 | 25 |
| Diverter box, chute, and gate | 151 | 103 | Toolbox | 168 | 123 |
| Eccentric shaft balance wheels | 148 | 100 | Troubleshooting: | | |
| General | 146 | 100 | Air system | 43 | 22 |
| Grizzly bars | 150 | 101 | Crusher assembly | 36, 37, 39, 44 | 21, 22 |
| Scalper vibrating screen assembly rubber mountings | 151 | 101 | Crusher electrical system | 35, 38, 40, 42 | 21, 22 |
| Scalper vibrating screen drive sheave | 147 | 100 | Engine assembly | 23, 28, 31, 32, 34 | 20, 21 |
| Scalper vibrating screen rubber deflectors | 149 | 101 | Engine cooling system | 25, 26 | 20 |
| Troubleshooting | 45 | 22 | Engine electrical system | 22, 30, 33 | 20, 21 |
| Scalper vibrating screen assembly rubber mountings | 151 | 101 | Fuel system | 27 | 20 |
| Scalper vibrating screen drive motor and belts | 128 | 83 | General | 21 | 20 |
| Scalper vibrating screen drive sheave | 147 | 100 | Valve cover and rocker arm assembly: | | |
| Scalper vibrating screen rubber deflectors | 149 | 101 | General | 99 | 65 |
| Scope | 1 | 3 | Rocker arm adjustment | 101 | 66 |
| Service upon receipt of equipment: | | | Valve covers and breather | 100 | 65 |
| Inspection and servicing the | | | Troubleshooting | 24-29 | 20-21 |
| | | | Water drain lines | 95 | 62 |
| | | | Water manifold | 108 | 70 |
| | | | Water temperature gage and sending unit | 88 | 53 |
| | | | Wheel bearing and hub assemblies | 116 | 78 |
| | | | Hydraulic system | 41 | 22 |
| | | | Scalper vibrating screen assembly | 45 | 22 |
| | | | Valve cover and rocker arm assembly | 24-29 | 20-21 |

| | |
|---------------------------|---------------------------|
| CNGB (1) | Army Tm1 (1) |
| CofEngrs (3) | USAOSA (2) |
| CSigO (1) | Engr Dist (2) |
| CofT (1) | Div Engr (2) |
| TSG (1) | Engr Fld Maint Shops (2) |
| USA Maint Bd (1) | USAEIDL (3) |
| USAARTYBD (2) | Engr Cen (5) |
| USAARMBD (2) | AMS (8) |
| USAIR (2) | Chicago Proc Ofc (10) |
| USARADBD (2) | USA Mob Spt Cen (36) |
| USAAESWBD (2) | ESCO (10) |
| USAAVNBD (2) | Fld Comd, DASA (8) |
| USCONARC (3) | USACOMZEUR (2) |
| USASMCOM (1) | USAREUR Engr Sup Con Agcy |
| USAMOCOM (2) | USAREUR Engr Proc Cen (2) |
| OS Maj Comd (5) except | MAAG (1) |
| USARJ (10) | JBUSMC (1) |
| USASETAF (2) | Units org under fol TOE: |
| MDW (1) | 5-48 (2) |
| Armies (2) | 5-114 (2) |
| Corps (2) | 5-115 (2) |
| USA Corps (1) | 5-117 (2) |
| Div (1) | 5-237 (5) |
| Engr Bde (1) | 5-262 (5) |
| USMA (2) | 5-267 (1) |
| Svc Colleges (2) | 5-278 (5) |
| Hr Svc Sch (2) except | 5-279 (2) |
| USAES (100) | 5-500 (EA, EB) (2) |
| Engr Sec, GENDEP (OS) 10) | |

• NG: None.


USAR: Same as Active Army except allowance is one copy to each unit.

For explanation of abbreviations used, see AR 320-50.



6 Control and distribution panel, front view

Figure 1—Continued.




| <u>LEGEND</u> | |
|---------------|----------------------------------|
| BAT. | BATTERY |
| B.I. | BATTERY INDICATOR |
| E.C.T. | ENGINE COOLANT TEMPERATURE |
| F.P. | FUEL INJECTION PRESSURE |
| GEN. | GENERATOR |
| M. | STARTER MOTOR |
| N.O. | NORMALLY OPEN |
| O.P. | ENGINE OIL PRESSURE |
| O.G. | OVER SPEED |
| S-1 | STARTER SWITCH |
| S-2 | ENGINE SAFETY SWITCH |
| SU-1 | SENDING UNIT COOLANT TEMPERATURE |
| SU-2 | SENDING UNIT FUEL PRESSURE |
| T. | TACHOMETER |
| V.R. | VOLTAGE REGULATOR |
| <u>SYMBOL</u> | |
| — | NEGATIVE |
| + | POSITIVE |
| □ | CONNECTOR |
| ⊥ | GROUND CONNECTION |
| ○ | TERMINAL |
| □ A | PIN CONNECTOR |

MSC 387

1 Serial No. range 2060 through 2087

Figure 1. Wiring diagram.



LEGEND

| | |
|--------|---|
| BAT. | BATTERY |
| B.I. | BATTERY GENERATOR INDICATOR GAGE |
| E.C.T. | ENGINE COOLANT TEMPERATURE GAGE |
| F.P. | FUEL INJECTION PUMP |
| GEN. | GENERATOR |
| M. | STARTER MOTOR |
| N.O. | NORMALLY OPEN |
| O.P. | ENGINE OIL PRESSURE |
| O.G. | OVER SPEED GOVERNOR |
| SI | STARTER-IGNITION SWITCH |
| SU1,3 | SENDING UNIT ENGINE COOLANT TEMPERATURE |
| SU2,4 | SENDING UNIT ENGINE OIL PRESSURE |
| T. | TACHOMETER |
| V.R. | VOLTAGE REGULATOR |


SYMBOL

| | |
|---|-----------------------------------|
| - | NEGATIVE |
| + | POSITIVE |
| □ | CONNECTOR |
| ⊖ | GROUND CONNECTIONS |
| ○ | TERMINAL |
| ⊠ | PIN CONNECTION |
| ⊕ | OIL PRESSURE WARNING LIGHT |
| ⊗ | COOLANT TEMPERATURE WARNING LIGHT |
| — | WIRE CONNECTED |

MSC 3820-205-20/1/

2 Serial No. range 2090 through 2129

Figure 1—Continued.



EMC 3820-20

3 Dolly wiring diagram

Figure 1—Continued.






Figure 1—Continued.

○ ~~TERMINAL~~

The diagram illustrates a 7-line telephone switchboard. Seven line cords, labeled S1 through S7, are arranged in two rows. Each cord has a terminal at the top and a terminal at the bottom. The bottom terminals are connected to a common terminal block labeled F-C. The connections are as follows: S1 to 3-4, S2 to 3-5, S3 to 2-3, S4 to 1-3, S5 to 2-4, S6 to 1-4, and S7 to 1-5. A ground symbol is connected to the common terminal block F-C.





| | |
|------|------------------------------|
| B | BUS GROUND |
| CB | CIRCUIT BREAKER |
| CB-1 | CIRCUIT BREAKER |
| CB-2 | CIRCUIT BREAKER |
| CB-3 | CIRCUIT BREAKER |
| CB-4 | CIRCUIT BREAKER |
| CB-5 | CIRCUIT BREAKER |
| F-C | FLEXIBLE CONDUIT |
| R-C | RIGID CONDUIT |
| JB-1 | JUNCTION BOX |
| JB-2 | JUNCTION BOX |
| JB-3 | JUNCTION BOX |
| R-1 | RECEPTACLE |
| R-2 | RECEPTACLE |
| R-3 | RECEPTACLE |
| S-1 | FEEDER MOTOR STARTER |
| S-2 | MAIN CONVEYOR MOTOR |
| S-3 | SCALPER SCREEN MOTOR |
| S-4 | SCALPER SCREEN MOTOR |
| S-5 | MAIN CONVEYOR MOTOR |
| S-6 | FEEDER MOTOR STOP |
| J-7 | OPERATORS SAFETY |
| S-8 | CONTROL PANEL SAFETY |
| TB-1 | TERMINAL BLOCK |
| TB-2 | TERMINAL BLOCK |
| TB-3 | RELAY BLOCK |
| FM | FEEDER MOTOR (10 HP) |
| MCM | MAIN CONVEYOR MOTOR |
| SSM | SCALPER SCREEN MOTOR |
| 3M | MAGNETIC LINE SWITCH |
| 4M | MAGNETIC LINE SWITCH |
| 5M | MAGNETIC LINE SWITCH |
| O.L. | OVER LOAD LINE SWITCH |
| 4L-1 | LINE OR CABLE IDENTIFICATION |

Control and distribution panel, front view

Figure 1—Continued.

NOTE: CIRCUIT BREAKERS PROTECT ROLL CRUSHER ELECTRICAL SYSTEM FROM OVERLOADS. THEY MUST BE IN THE "ON" POSITION FOR OPERATION.

ROTARY ELEVATOR
CIRCUIT BREAKER

RETURN (UNDER) CONVEYOR
CIRCUIT BREAKER

SIDE CONVEYOR NO. 2
CIRCUIT BREAKER

SIDE CONVEYOR NO. 1
CIRCUIT BREAKER

FEEDER CIRCUIT BREAKER

MAIN (FEED) CONVEYOR
CIRCUIT BREAKER

VIBRATING SCREEN
CIRCUIT BREAKER

NOTE: CIRCUIT BREAKERS AUTOMATICALLY GO TO "OFF" POSITION WHEN AN OVERLOAD OCCURS. RESET TO "ON" POSITION WHEN TROUBLE IS CORRECTED.

AND A STARTER TRIPS
CORRECT TRIMBLE AND PRESS
RESET RODS TO CLOSE CIRCUIT

ROTARY ELEVATOR
OVERLOAD RESET RODS


RETURN (UNDER) CONVEYOR
OVERLOAD RESET RODS

FEEDER OVERLOAD
RESET RODS



MAIN (FEED) CONVEYOR
OVERLOAD RESET RODS

VIBRATING SCREEN
OVERLOAD RESET RODS


G




H




I





EMERGENCY STOP BUTTON
(SAFETY CUT OUT SWITCH):
TRIPS MAIN CIRCUIT BREAKER
FOR EMERGENCY STOPS.

NOTE: START AND STOP BUTTONS CONTROL
ROLL CRUSHER ELECTRIC MOTORS.



M—Lower clutch control lever

Figure 12—Continued.

Section III. OPERATION OF EQUIPMENT

12. General

a. The instructions in this section are published for the information and guidance of the personnel responsible for the operation of the roll crusher.

b. The operator must know how to perform every operation of which the roll crusher is capable. This section gives instructions on

13. Starting the Engine


a. *Preparation for Starting.*

- (1) Perform the daily preventive maintenance services (par. 29).
- (2) See that the fuel shutoff valve (B, figure 12) is in the open position.

b. *Starting.* Start the engine in the numerical sequence as instructed on figure 13.

CAUTION: DO NOT CRANK THE ENGINE FOR MORE THAN 30 SECONDS AT A TIME. ALLOW ONE MINUTE BETWEEN ATTEMPTS IF ENGINE FAILS TO START.

1. DISENGAGE THE CLUTCH AND MOVE THE THROTTLE LEVER TO 1/4 OPEN.
2. TURN IGNITION SWITCH TO "ON" POSITION, PRESS STARTER BUTTON (RELEASE IMMEDIATELY WHEN ENGINE STARTS). (SEE NOTE)
3. MOVE THROTTLE LEVER TO "RUN" POSITION.
4. RUN ENGINE AT 1,100 RPM UNTIL OPERATING TEMPERATURE IS REACHED BEFORE APPLYING LOAD.
5. OBSERVE ALL INSTRUMENTS AND GAGES FOR PROPER OPERATING RANGE.



STARTER BUTTON

IGNITION SWITCH

THROTTLE LEVER

CLUTCH LEVER
DISENGAGED POSITION

CLUTCH LEVER
ENGAGED POSITION.


CAUTION: STOP ENGINE IF IGNITION SWITCH FAILS TO RETURN TO "RUN" POSITION AFTER ENGINE STARTS. APPLY LOAD ONLY AFTER COMPLETE ENGINE WARMUP.

NOTE: UNITS OF EQUIPMENT WITHIN SERIAL NUMBER RANGE 6590 THRU 6629 ARE EQUIPPED WITH A DUAL IGNITION-STARTER SWITCH.

NORMAL READINGS

ENGINE TEMPERATURE

165-185°F



1. MOVE THROTTLE LEVER DOWN UNTIL ENGINE IDLES AT 600 RPM.
2. DISENGAGE CLUTCH.
3. ALLOW ENGINE TO IDLE 5 MINUTES.
4. TURN IGNITION SWITCH TO "OFF" POSITION.
5. MOVE THROTTLE LEVER TO "OFF" POSITION.

MSC 3820

Figure 14. Stopping the engine.


- (2) Start the engine as outlined in *b* above. When pressing the starter button, activate the diesel engine ether starting aid as instructed in paragraph 22.

14. Stopping the Engine

Stop the engine by:

15. Operating Details


a. General. The operator must regulate flowing smoothly through the crusher (fig. 3) and not allow the material to build up or overflow from the conveyor or vibrating screen, or crushing rolls.




FEEDER RELIEF
CHUTE GATE

FEEDER RELIEF
CHUTE EXTENSION


1. INSTALL A CONVEYOR UNDER THE FEEDER RELIEF CHUTE EXTENSION. OPEN THE FEEDER RELIEF CHUTE GATE TO OBTAIN AGGREGATE FROM THE FEEDER RELIEF CHUTE.



2. LOOSEN NUT (4). RAISE OR LOWER LIFT GATE ASSEMBLY TO OBTAIN DESIRED AGGREGATE FLOW FROM FEEDER HOPPER NUT (4).



NOTE: MOVE THE GATE CONTROL HANDLE TO RIGHT TO DISCHARGE AGGREGATE FROM BOTH TOP AND BOTTOM VIBRATING SCREENS THROUGH THE UNDER HOPPER (FIG. 2). MOVE THE GATE CONTROL HANDLE TO LEFT TO DISCHARGE AGGREGATE SCREENED BY TOP VIBRATING SCREEN THROUGH THE LOWER CHUTE (FIG. 2), AND AGGREGATE SCREENED BY THE BOTTOM VIBRATING SCREEN THROUGH THE UNDER HOPPER (FIG. 2).



WITH THE THROTTLE LEVER SET TO OPERATE THE ENGINE AT IDLE SPEED, POSITION THE CLUTCH LEVER FORWARD TO ENGAGE THE CLUTCH, MOVE THE THROTTLE LEVER UP TO THE "RUN" POSITION.

MSC 320-205-10/1/15 ①

Figure 15—Continued.

capacity without overloading any of its components.

b. Operation.


- (1) Start the engine (par. 13).
- (2) Make certain the vibrator screens are of the proper size for the desired grade of aggregate (par. 69).

in operation at operator's control box (6, fig. 15).

- (2) Move main control switch handle to OFF position (5, fig. 15).
- (3) Disengage engine clutch (4, fig. 15).
- (4) Stop the engine (par. 14).

14. Operation in Extreme Cold (Below 0°

NOTE: BEFORE MOVING THE MAIN CONTROL SWITCH HANDLE TO 'ON' POSITION, OPEN THE CONTROL PANEL DOOR AND SEE THAT ALL CIRCUIT BREAKERS ARE IN THE 'ON' POSITION. CLOSE THE DOOR.



MOVE MAIN CONTROL SWITCH HANDLE TO 'ON' POSITION

MSC 3820-2

Figure 15—Continued.


- c. Keep batteries fully charged. After adding water to the batteries, run the engine for at least 1 hour.
- d. Keep fuel tank full at all times.
- e. Drain and service fuel filters frequently (par. 51).
- f. Lubricate as specified in LO 5-3820-205-20/1-1.

all points of application. Check frequently.

b. *Cooling.* Make sure the radiators are clean and free of any foreign matter. Avoid the use of water containing oil or other substances that would cause formation of scale or rust.

c. *Engine.* If engine becomes overheated from lack of water, allow it to cool before adding water. Then add water in

g. Refer to paragraph 13c for cold temperature starting procedure. Start the engine and allow engine to reach normal operating temperature.



6. PUSH START AND STOP BUTTONS TO CONTROL INDIVIDUAL ELECTRIC MOTORS FOR ROLL CRUSHER UNITS. SAFETY CUTOFF SWITCH IS FOR EMERGENCY ONLY.

MSC 3820-205-10/1/15 (5)

Figure 15—Continued.

18. Operation in Dusty or Sandy Areas

a. *Lubrication.* Clean filters frequently. Clean lubrication points before applying lubricant. Lubricate in accordance with LO 5-3820-205-20/1-1.

b. *Cooling.* Keep radiator caps and fans free

while pouring. Service air cleaner frequently to remove sand and dust.

19. Operation Under Rainy or Humid Conditions

a. *Lubrication.* Lubricate in accordance with

avoid condensation. Service the fuel filters frequently (par. 51).

d. Protection. Cover the engine, electric motors, and controls with a tarpaulin or similar protection when not in use. Remove covers and open engine panels to allow unit to dry during dry periods before operation. Paint or coat with grease all exposed metal surfaces to prevent rusting:

e. Conveyors and Belts. Keep the scrapers adjusted and belts as clean as possible. Clean the conveyors and belts after each operation to prevent material from drying, caking, and building up on them.

20. Operation in Salt Water Areas

a. General. The deterioration and corrosion of exposed metal surfaces is greatly accelerated in saltwater areas. Paint all exposed nonpolished surfaces (TM 9-213). Coat exposed parts of polished steel and other ferrous materials with standard issue rustproofing material, if available, or cover parts with a light coat of grease.

b. Cooling. Be sure the water used in the cooling system is free of salt or alkali. Use an approved rust inhibitor to prevent the formation of rust or scale in the cooling system.

Section IV. OPERATION OF AUXILIARY MATERIEL USED IN CONJUNCTION WITH THE ROLL CRUSHER

22. Cold Weather Starting Aid

a. General. The pressure primers are used to supply ether to the diesel engine for starting in cold weather as low as -25° F. The ether is piped into the engine intake manifolds to aid combustion at lower temperatures and should never be used when the engine is warm.

b. Operating. Operate the pressure primers to aid in starting the diesel engine as instructed on figure 16.

after having used this expedient.

c. Fuel System. Keep the fuel system free of eliminate condensation. Service the fuel system frequently.

d. Electrical System. Keep the electrical system clean and dry. Wipe off oil and salt deposits. Pay particular attention to electrical connections. Inspect the generator frequently and remove dirt and moisture.

21. Operation at High Altitudes

a. The engine in this unit is designed to operate under normal conditions up to 5,000 feet above sea level without special adjustments.

b. Above 5,000 feet engine efficiency is reduced. This is a normal condition and cannot be prevented, but maximum efficiency can be maintained by following the instructions carefully. Be sure the engine is clean and free of objects that might restrict the flow of air to the unit.


c. Be alert for radiator pressure. Do not allow the coolant to boil with excessive pressure. Inspect the radiator frequently for tight sealing.

23. Fire Extinguisher

(Carbon Dioxide Type)

a. Description. The carbon dioxide fire extinguisher is suitable for electrical and flammable liquid fires. The carbon dioxide is in the 5-pound size. The 5-pound extinguisher is portable.

b. Operation. Remove fire extinguisher to its location; break the seal, open the valve, and direct the stream of



RAISE LEVER, UNSCREW CAP,
INSERT ETHER CAPSULE, AND
INSTALL CAP.

(NOTE: BE SURE LEVER REMAINS IN RAISED
POSITION UNTIL ENGINE IS CRANKED.
PULL LEVER DOWN TO PIERCE CAPSULE,
WHILE CRANKING ENGINE. THIS ALLOWS
ETHER TO ENTER THE INTAKE MANIFOLD.

WARNING: ETHER IS HIGHLY EXPLOSIVE AND TOXIC. HANDLE ETHER CAPSULES WITH
EXTREME CAUTION TO PREVENT RUPTURE UNTIL INSTALLED IN CAPSULE
CHAMBER, AND ENGINE IS BEING CRANKED.

NOTE: ON UNITS OF EQUIPMENT WITHIN SERIAL NUMBER RANGE 6590 THROUGH 6629 THE
ETHER STARTING AIDS ARE LOCATED ONE ABOVE THE OTHER.

MSC 3820-205-10/1/16

Figure 16. Pressure primer instructions.

CHAPTER 3

MAINTENANCE INSTRUCTIONS

Section I. OPERATOR'S TOOLS AND EQUIPMENT

24. Special Tools and Equipment

No special tools or equipment is required by the operator for the maintenance of this roll crusher.

25. Basic Issue Tools and Equipment

Tools and repair parts issued with the roll crusher are listed in the items list, appendix II of this manual.

Section II. LUBRICATION

26. General Lubrication Information

a. This section contains a reproduction of the lubrication order and lubrication instructions which are supplemental to and not specifically covered in the lubrication order.

b. The lubrication order shown on figure 17 is an exact reproduction of the approved lubrication order for the roll crusher. For the current lubrication order, always refer to DA Pam 310-4.

27. Detailed Lubrication Information

a. Care of Lubricants.

(1) *General.* The primary function of a lubricant is to decrease the rate of wear, and to maintain the efficiency of a machine, by reducing friction between the moving parts and by dissipating frictional heat. If a lubricant is contaminated with dust, dirt, or water, it cannot perform its function. Every precaution must be taken to protect lubricants from contamination.

(2) *Storage.* Keep all lubricants and lubrication equipment in airtight containers. Lubricants should be stored in a cool, dry place.

(3) *Handling.* Whenever possible, lubrication operations should be done in a clean place. Clean the oil cans and containers before they are used. Protect them from dust. When covers are removed, clean the equipment with approved cleaning solvent and carefully dry before and after use.

b. *Points of Application.* Follow the instructions for each lubrication point listed in LO 5-3820-205-20/1-1 (figure 17). Apply the proper lubricant as indicated.

Note. Before lubrication, clean all lubrication points. Use approved cleaning solvent around these points. Do not use gasoline for any purpose. Dry thoroughly with lint-free cloth before applying lubricants. Reclean after lubrication.

c. OES Lubricating Oil.

(1) The crankcase oil level should be checked frequently as oil consumption may increase.

(2) The oil may require changing frequently because of contamination and sludge formation. Oil change is necessary during cold weather operation.

d. Oil Filter Assembly.

CRUSHER, ROLL: DIESEL AND ELECTRIC DRIVEN; WHEEL MOUNTED, PNEUMATIC TIRES; 75 TON PER HOUR (EAGLE CRUSHER MODEL 5230B) W/ENGINE, CONTINENTAL MODEL SD 802

Reference LO 5-3870-205-20/1-2 and -3, SM 10-1-C4-1

Intervals are based on normal hours of operations. Reduce to compensate for abnormal operations and severe conditions. During inactive periods, sufficient lubrication must be performed for adequate preservation.

Clean fittings before lubricating.

Relubricate after washing or hosing.


Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain gearcase when hot. Fill and check level.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT






FIG. 2

- KEY -

| LUBRICANTS | CAPACITY | EXPECTED TEMPERATURES | | | INTERVAL |
|--|----------|-----------------------|----------------|--------------|----------|
| | | Above +32°F | +40°F to -10°F | 0°F to -65°F | |
| OE - OIL, Engine, Heavy Duty | | OE 30 | OE 10 | OE 5 | Inter |
| Oil Can Points | | 9250 | 9110 | | oper |
| Elevating Wheel Gear Reducer | 2qt | | | | in hav |
| OES - OIL, Engine, Sub-zero | | | | | oper |
| GO - LUBRICATING OIL, Gear | | | | | |
| Roll Crusher Gearcase | 2 1/2 qt | GO 140 | GO 40 | GO 5 | |
| GOS - LUBRICATING OIL, Gear, Sub-zero | | | | | |
| GAA - GREASE, Automotive and Artillery | | | | | |

All Temperatures

NOTES

1. FOR OPERATION OF EQUIPMENT IN PROTRACTED COLD TEMPERATURES BELOW -10°F. Remove lubricants prescribed in the key for temperatures above -10°F. Clean parts with SOLVENT, dry-cleaning. Relubricate with lubricants specified in the key for temperatures below -10°F.

2. WHEEL BEARINGS. Every 1000 hours remove wheels, clean and inspect oil parts, replace damaged or worn parts, repack bearings, and reassemble.

3. OIL CAN POINTS. Every 50 hours lubricate linkage pins, clevises, and all exposed adjusting threads with OE, including leveling jacks as needed.

Copy of this Lubrication Order will remain with the equipment at all times, instructions contained herein are mandatory.

BY ORDER OF THE SECRETARY OF THE ARMY

G. H. DECKER
General, United States Army
Chief of Staff

OFFICIAL

J. C. LAMBERT,
Major General, United States Army,
The Adjutant General.

CRUSHER, ROLL: DIESEL AND ELECTRIC DRIVEN; WHEEL MOUNTED, PNEUMATIC TIRES; 75 TON PER HOUR (EAGLE CRUSHER MODEL 5230B) W/ENGINE CONTINENTAL MODEL SD 802

References: LO 5-3820-205-20/1-1 and -3, TM 5-3820-205-10/1, C 9100-SL

Intervals are based on normal hours of operations. Reduce to compensate for abnormal operations and severe conditions. During inactive periods sufficient lubrication must be performed for adequate preservation.

Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Clean fittings before lubricating.

Relubricate after washing or fording.


Drain gearcase when hot. Fill and check level.

FOLD


FOLD

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



FRONT SECTION



- KEY -

| | | - KEY - | | | |
|--|----------|-----------------------|---------------------|--------------|---|
| LUBRICANTS | CAPACITY | EXPECTED TEMPERATURES | | | INTERVALS |
| | | Above +32°F | +40°F to -10°F | 0°F to -65°F | |
| OE - OIL, Engine, Heavy Duty | | OE 30 or 9250 | OE 10 or 9110 | OES | Intervals given are in hours of normal operation. |
| Oil Can Points | | | | | |
| Upper Conveyor Gear Reducer | 5 qt | | | | |
| Under Conveyor Gear Reducer | 4 qt | | | | |
| Feeder Shaft Gear Reducer | 2 qt | | | | |
| OES - OIL, Engine, Sub-zero | | GO 140 | GO 90 | GOS | |
| GO - LUBRICATING OIL, Gear | | | | | |
| Roll Crusher Gearcase | 50 qt | | | | |
| GOS - LUBRICATING OIL, Gear, Sub-zero | | | | | |
| GAA - GREASE, Automotive and Artillery | | | | | |
| NOTES | | All Temperatures | | | |

NOTES

1. FOR OPERATION OF EQUIPMENT IN PROTRACTED COLD TEMPERATURES BELOW -10°F. Remove lubricants prescribed in the key for temperatures above -10°F. Clean parts with SOLVENT, dry-cleaning. Relubricate with lubricants specified in the key for temperatures below -10°F.

2. WHEEL BEARINGS. Every 1000 hours remove wheels, clean and inspect all parts, replace damaged or worn parts, repack bearings, and reassemble.

3. OIL CAN POINTS. Every 50 hours lubricate linkage pins, clenses, and all exposed adjusting threads with OE, including leveling jacks as needed.

4. ALL MOTOR BEARINGS. Remove fittings, install plugs, be lubricated only at time of disassembly by 3rd echelon.

Copy of this Lubrication Order will remain with the equipment at all times; instructions contained herein are mandatory.

BY ORDER OF THE SECRETARY OF THE ARMY:

OFFICIAL:

J. C. LAMBERT,
Major General, United States Army

EARLE G. WHEELER,
General, United States Army
Chief of Staff.

CRUSHER, ROLL: DIESEL AND ELECTRIC DRIVEN; WHEEL MOUNTED, PNEUMATIC TIRES; 75 TON PER HOUR (EAGLE CRUSHER MODEL 5230B) W/ENGINE CONTINENTAL MODEL SD 802

Reference: LO 5-3820-205-20/1-1 and -2, SM 10-1-C4-1

Intervals are based on normal hours of operations. Reduce to compensate for abnormal operations and severe conditions. During inactive periods sufficient lubrication must be performed for adequate preservation.

Clean fittings before lubricating.

Relubricate after washing or larding.


Clean parts with SOLVENT, dry-cleaning, or with OIL, fuel, Diesel. Dry before lubricating.

Lubricate points indicated by dotted arrow shafts on both sides of equipment.

Drain crankcase only when hot after operation; replenish and check level when cool.

LUBRICANT • INTERVAL

INTERVAL • LUBRICANT



| LUBRICANTS | CAPACITY | EXPECTED TEMPERATURES | | | INTERVAL |
|---------------------------------------|----------|-----------------------|---------------------|--------------|---|
| | | Above +32°F | +40°F to -10°F | 0°F to -65°F | |
| OE -OIL, Engine, Heavy Duty | | OE 30 or 9250 | OE 10 or 9110 | OES | Interval given or in hours normal operation |
| Crankcase | 24 qt | | | | |
| Oil Can Points | | | | | |
| OES -OIL, Engine, Sub-zero | | All Temperatures | | | |
| GAA -GREASE, Automotive and Artillery | | | | | |

NOTES

1. FOR OPERATION OF EQUIPMENT IN PROTRACTED COLD TEMPERATURES BELOW -10°F. Remove lubricants prescribed in the key for temperatures above -10°F. Clean parts with SOLVENT, dry-cleaning. Relubricate with lubricants specified in the key for temperatures below -10°F.

2. OIL FILTERS. After installing new filter elements, full crankcase, operate engine 5 minutes, check housing for leaks, check crankcase level, and bring to full mark.

3. OIL CAN POINTS. Every 50 hours lubricate throttle and governor linkage, pins and clevises. Fill crankcase breather to level mark with OE.


Copy of this Lubrication Order will remain with the equipment at all times, instructions contained herein are mandatory.

BY ORDER OF THE SECRETARY OF THE ARMY:


G. H. DECKER,
General, United States
Chief of Staff.

OFFICIAL:


R. V. LEE,
Major General, United States Army,
The Adjutant General.




REF. 1 MAIN ROLL SHAFT
REF. 11 MAIN ROLL SHAFT




REF. 2 ROLL CRUSHER GEARCASE FILL
REF. 4 DRIVE SHAFT HOUSING, OUTSIDE




REF. 3 DRIVE SHAFT HOUSING, INSIDE




REF. 5 ROLLER BEARING HOUSING




REF. 6 BEARING SEAL PLATE DRAIN



REF. 7 CONVEYOR SHAFT BEARINGS




REF. 8 FIFTH WHEEL LOCK PIN




REF. 8 ROLL CRUSHER GEARCASE LEVEL

REF. 10 ROLL CRUSHER GEARCASE DRAIN




REF. 12 FIFTH WHEEL HINGE PIN




REF. 13 FIFTH WHEEL HINGE PIN

REF. 14 FIFTH WHEEL HINGE PIN


REF. 15 FIFTH WHEEL PLATE




REF. 16 TRANSVERSE BEARING



REF. 17 NOSE REEL




REF. 18 ROLLER SHAFT BEARINGS




REF. 19 HOSE REEL

REF. 42 CONVEYOR TAIL SHAFT BEARING





REF. 19 HOSE REEL



REF. 20 ELEVATING WHEEL GEAR REDUCER FILL


REF. 24 ELEVATING WHEEL GEAR REDUCER LEVEL

REF. 25 ELEVATING WHEEL GEAR REDUCER DRAIN







REF. 23 PINTLE HOOK





REF. 26 ELEVATING WHEEL TRUNNION SHAFT




REF. 27 WHEEL BEARING
REF. 29 WHEEL BEARING
REF. 33 WHEEL BEARINGS




REF. 28 SLACK ADJUSTERS
REF. 44 BRAKE SHAFT
REF. 46 BRAKE SHAFT







REF. 34 PRESSURE ARM SHAFT





REF. 35 ROLL CRUSHER GEARCASE FILL




REF. 36 VIBRATING SCREEN MOTOR
REF. 37 CONVEYOR MOTOR




REF. 38 UPPER CONVEYOR GEAR REDUCER DRAIN
REF. 39 UPPER CONVEYOR GEAR REDUCER FILL
REF. 40 UPPER CONVEYOR GEAR REDUCER LEVEL







REF 45 TRUNNION




REF 51 CRANKCASE FILL
REF 55 OIL FILTER
REF 57 WATER PUMP




REF 52 CRANKCASE BREATHER
REF 53 CRANKCASE LEVEL GAGE
REF 54 TACHOMETER DRIVE



REF 56 CRANKCASE DRAIN



REF 58 STARTER



REF 59 CLUTCH THROWOUT BEARING
REF 60 CLUTCH SHAFT BEARING

NOTE: SERVICE THE REMAINING
FILTERS IN A SIMILAR
MANNER.

NOTE: CLEAN COVER AND BODY.
REPLACE ELEMENT AND
PERFORMED PACKING.
OPERATE ENGINE AND
CHECK FOR LEAKS.




Figure 18. Oil filter assemblies service




Figure 19. Crankcase breather service.

Section III. PREVENTIVE MAINTENANCE SERVICES

28. General

To insure that the roll crusher is ready for operation at all times, it must be inspected systematically, so that defects may be discovered and corrected before they result in serious damage or failure. The necessary preventive maintenance services to be performed are listed and

would damage the equipment if continued. All deficiencies are will be recorded together with action taken on DA Form 2. Inspection and Maintenance Worksheet at the earliest possible opportunity.


29. Daily Preventive Maintenance

DAILY

TM 5-3820-205-10/1

EAGLE MODEL 5230B

ROLL CRUSHER



LUBRICATE IN ACCORDANCE WITH CURRENT LUBRICATION ORDER

ITEM

PAR. REF


1 TIRES. Perform visual check for proper inflation. Correct air pressure is 100 psi.

2 HOPPER AND CHUTES. Check for proper operation. Check liners for excessive wear. Check deflectors for wear and proper adjustment. When hopper is loaded, deflectors should barely touch conveyor belt. (Weekly)

3 FIRE EXTINGUISHER. Inspect for broken seal.

| | | |
|-----|--|--|
| 4.1 | <u>FUEL TANK.</u> Check level. Drain sediment from tank. (Biweekly). | |
| 5 | <u>AIR SYSTEM.</u> Drain condensation from reservoir and filters after use. | |
| 6 | <u>OPERATOR'S ELECTRICAL CONTROL BOX.</u> Check for proper operation. Make sure switches are in correct positions and cables are connected. Make sure ground rod is securely mounted and there are no loose connections. Check for tightly sealed box. WARNING: Do not connect electrical power or operate the equipment if the ground connection is not properly installed. Death by electrocution could result from contacting ungrounded equipment should some electrical fault develop in power equipment or lines. | |
| 7 | <u>CONVEYOR BELT ASSEMBLIES.</u> Check for excessive wear, frayed condition, proper adjustment, and alignment. Conveyor belt should be adjusted just enough to prevent slipping when loaded. Check rollers for excessive wear, material buildup, and defective bearings. Check belt scrapers for excessive wear and proper adjustment. Adjust belt scrapers so they barely touch conveyor belt. (Weekly) | |
| 8 | <u>BATTERIES.</u> Check electrolyte level and hand tightness of connections. Fill to 3/8 inch above filler plates. In freezing weather run the engine one hour after adding water. (Weekly) | |

CONTINENTAL MODEL SD802



| | | |
|----|--|----|
| 9 | <u>AIR CLEANER</u> . Check to see if red signal is visible. | |
| 10 | <u>PRIMARY FUEL FILTER</u> . Drain sediment. (Weekly) | 51 |
| 11 | <u>ENGINE OIL LEVEL</u> . Check oil level. Add oil to proper level. | |
| 12 | <u>RADIATOR</u> . Check coolant level. Fill to 2 inches below filler neck. | |
| 13 | <u>MASTER CLUTCH</u> . Check for proper operation. | |
| 14 | <u>CONTROLS AND INSTRUMENTS</u> . Normal readings are: Coolant temperature 165°F to 185°F. Engine oil pressure 55 to 65 psi Battery-generator indicator Green Range Tachometer 1,400 RPM | |
| | <u>NOTE: OPERATION</u> . During operation check all controls for proper operation. | |

30. General

This section provides information useful in diagnosing and correcting unsatisfactory operation or failure of the roll crusher and its components. Each trouble symptom stated is

followed by a list of probable causes of the trouble. The possible remedy recommended is described opposite the probable cause. Any operational trouble that is beyond the scope of the operator or crew must be reported to organizational maintenance.

31. Engine Hard To Start, or Fails To Start

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|---|
| Atmospheric temperature low..... | Use ether starting aids (par. 22). |
| No fuel in tank..... | Fill the fuel tank (par. 54). |
| Dirt, gum, or water in fuel lines or tank..... | Service the fuel tank (par. 54). |
| Air trapped in fuel lines..... | Bleed fuel line (par. 52). |
| Fuel filters clogged..... | Clean the primary fuel filter element (par. 51). Replace the secondary fuel filter element (par. 51). |
| Throttle lever not in the start position..... | Place throttle lever in the start position. |
| Cranking speed too low..... | Report this condition to organizational maintenance. |

32. Engine Operates Erratically or Lacks Power

| <i>Probable cause</i> | <i>Possible remedy</i> |
|----------------------------------|---|
| Dirt, gum, or water in fuel..... | Service fuel tank and lines and fill with clean fuel (par. 54). |
| Air cleaner clogged..... | Service air cleaner (par. 53). |
| Fuel filters clogged..... | Clean the primary fuel filter element (par. 51). Replace the secondary fuel filter element (par. 51). |
| Air in the fuel system..... | Bleed fuel lines (par. 52). |

33. Exhaust Smokes Excessively

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Crankcase oil level too high..... | Drain oil until proper level is obtained (LO 5-3820 205-20/1-1). |
| Engine cold causing poor combustion..... | Report this condition to organizational maintenance. |
| Engine overloaded..... | Reduce load on engine. |
| Air cleaner clogged..... | Service air cleaner (par. 53). |

34. Engine Overheats

| <i>Probable cause</i> | <i>Possible remedy</i> |
|-------------------------|---|
| Coolant level low..... | Fill radiator to proper level (par. 56). |
| Fan belts loose..... | Tighten fan belts (par. 57). |
| Exhaust restricted..... | Remove restriction or report to organizational maintenance. |
| Engine overloaded..... | Reduce load on engine. |
| Water pump faulty..... | Report this condition to organizational maintenance. |

35. Engine Knocks or Develops Unusual Noise

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--------------------------------|--|
| Accessory mountings loose..... | Tighten mountings or report to organizational maintenance. |
| Crankcase oil supply low..... | Stop engine and check oil supply. Replenish oil. |

| <i>Probable cause</i> | <i>Possible remedy</i> |
|--|--|
| Air trapped in fuel lines..... | Bleed fuel lines (par. 52). |
| Engine overheated (safety control operated)..... | Inspect the coolant level (par. 56), and fan belt adjustment (par. 57), and radiator for obstructions. |
| Restriction in air intake..... | Service the air cleaner (par. 53). |
| Oil pressure low (safety control operated)..... | Check the oil level in the crankcase. Replenish if necessary (LO 5-3820-205-20/1-1). |

37. Conveyor Does Not Run Properly or Will Not Run

| <i>Probable cause</i> | <i>Possible remedy</i> |
|-------------------------------------|--|
| Too much slack in drive belts..... | Adjust conveyor drive belts (pars. 70 and 76). |
| Circuit breaker tripped..... | Correct the cause of overload and reset the circuit breaker. |
| Grease on drive sheave or belt..... | Clean grease off belt or drive sheave with appropriate cleaning solvent. |

38. Crusher Rolls Do Not Turn or Come Up To Normal Speed

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---|---|
| Roll drive belts slipping due to dirt or grease on belts and pulleys..... | Clean crusher rolls drive belts and pulley. |
| Engine clutch slips..... | Adjust clutch (par. 63). |

39. Screen Vibrates Excessively

| <i>Probable cause</i> | <i>Possible remedy</i> |
|---------------------------------|--|
| Loose rubber mounts..... | Tighten mounting hardware for rubber mounts. |
| Motor drive belts slipping..... | Adjust drive belts (par. 67). |

40. Screen Will Not Vibrate

| <i>Probable cause</i> | <i>Possible remedy</i> |
|------------------------------|--|
| Drive belts slipping..... | Adjust drive belts (par. 67). |
| Circuit breaker tripped..... | Correct the cause of overload and reset circuit breaker. |

41. Feeder Will Not Operate or Works Slowly

| <i>Probable cause</i> | <i>Possible remedy</i> |
|------------------------------|--|
| Drive belts slipping..... | Adjust drive belts (par. 70). |
| Circuit breaker tripped..... | Correct the cause of overload and reset circuit breaker. |

42. Rotary Elevator Will Not Turn or Turns at Low Speed

| <i>Probable cause</i> | <i>Possible remedy</i> |
|------------------------------|--|
| Drive belts slipping..... | Adjust drive belts (par. 72). |
| Circuit breaker tripped..... | Correct the cause of overload and reset circuit breaker. |

43. Electric Motors Will Not Run

| <i>Probable cause</i> | <i>Possible remedy</i> |
|-----------------------------------|--|
| Main circuit breaker tripped..... | Correct cause of emergency and reset main circuit breaker. |
| Voltage source fluctuating..... | Check power source for proper voltage (par. 81). |

Upon the decision of the unit commander during emergencies, the following expedient repairs may be used to correct temporary operational troubles in the field where supplies and repair parts for normal corrective maintenance

are not available. Equipment so repaired be removed from operation as soon as possible and properly repaired before being placed in operation again.

46. Engine Gradually Loses Power

Trouble
Fuel filters clogged

Expedient remedy
Discard the fuel filters and operate the engine with new filters until replacements are available.

47. Engine Overheats or Runs Cold

Trouble
Coolant thermostat defective

Expedient remedy
Remove defective thermostat and operate engine until replacement is available.

48. Loss of Lubricating Oil

Trouble
Small hole in crankcase oil pan
Damaged oil line

Expedient remedy
Plug hole with wooden plug or metal screw.
Tape or wrap the oil line with a suitable material until a new oil line can be installed.

49. Loss of Fuel

Trouble
Hole in fuel tank
Fuel line damaged

Expedient remedy
Plug hole with wooden plug or metal screw.
Tape or wrap fuel line with a suitable material until a new fuel line can be installed.

Section VI. FUEL SYSTEM

50. General

The engine fuel system consists of a 100-gallon fuel tank, fuel lines and fittings, primary fuel filter, primer pump, secondary fuel filter, fuel injector pump, and six fuel injectors.

51. Primary and Secondary Fuel Filters Service

Service the primary and secondary fuel filters as instructed on figure 21.
Note. Service the fuel filters weekly.

52. Bleeding the Fuel System

Bleed the fuel system in the sequence as instructed on figure 22.


53. Air Cleaner Service

Service the air cleaner as instructed on figure 23.

54. Fuel Tank and Strainer Service

Service the fuel tank and strainer as instructed on figure 24.

Caution: The manual control fording valve located inside the fuel tank cap is closed before shipment is made from contractor's plant. For proper ventilation of fuel tank, valve must be opened when crusher is in operation.




NOTE: CLEAN THE BODY.
REPLACE ELEMENT AND
PREFORMED PACKING.

NOTE: AFTER SERVICING THE
FILTERS, BLEED THE FUEL
SYSTEM. START THE ENGINE.
INSPECT FOR LEAKS.

NOTE: CLEAN THE BODY AND
ELEMENT. REPLACE
PREFORMED PACKING.
REPLACE DEFECTIVE
ELEMENT.

EMC 3020-255-10/1/22


Figure 21. Primary and secondary fuel filters service.



NOTE: RELEASE LOCK AND OPERATE HAND PRIMER
UNTIL FUEL FLOWS WITHOUT AIR FROM
VENT PLUG. TIGHTEN VENT PLUG.

EMC 3820-205-10/1/23 ①

Figure 22. Bleeding the fuel system.



NOTE: CRANK ENGINE WITH STARTER UNTIL FUEL FLOWS WITHOUT AIR FROM FUEL LINE CONNECTOR. TIGHTEN CONNECTOR. REPEAT PROCESS ON EACH INJECTOR.


EMC 3820-205-10/1/23②

Figure 22—Continued.



Figure 23. Air cleaner service.

REMOVE CAP AND FILL TANK
WITH PROPER FUEL.



FUEL GAGE

NOTE: CLEAN CAP AND STRAINER. INSPECT
FOR BROKEN OR DEFECTIVE GAGE.

A

DRAIN VALVE

FUEL SHUTOFF VALVE

NOTE: OPEN DRAIN VALVE AND DRAIN FUEL
SEDIMENT AND CONDENSATION INTO A
SUITABLE CONTAINER.

B

The liquid cooling system consists of the radiator, hoses, lines, fittings, water pump, fan, and coolant passages in the engine cylinder heads and block. The coolant temperature is regulated from 165° to 185° F. by two thermostats located inside the thermostat housing.

Service the radiator as instructed
25.


57. Fan Belts Adjustment

Adjust the fan belts as instructed
26.

NOTE: BEFORE SERVICING,
START AND OPERATE
THE ENGINE UNTIL
NORMAL OPERATING
TEMPERATURES ARE
REACHED.



REMOVE CAP AND FILL
WITH PROPER COOLANT.



COVER

NOTE: FILL TO 2 INCHES
BELOW FILLER NECK.


A


NOTE: REMOVE DIRT AND DUST
FROM RADIATOR AND SCREEN.

RADIATOR DRAIN

ENGINE BLOCK DRAIN

REMOVE DRAIN PLUG (2)
AND DRAIN SYSTEM.





FAN BELTS

ADJUSTING STRAP

LOOSEN SCREW

LOOSEN SCREW(2)

GENERATOR

NOTE: ADJUST TENSION ON BELTS TO A
1/2 INCH DEFLECTION WHEN NEW

The engine electrical system consists of the generator, generator regulator, four 12-volt batteries, and the safety cutout control assembly and components. The batteries are connected in series-parallel to provide 24 volts for the engine electrical system. The electrical system has a negative ground.


59. Batteries Service

a. Service the batteries as instructed on figure 27.

open flame near storage batteries during soon after charging. Hydrogen gas is generated during charging which can cause an explosion if ignited. Do not lay tools across battery terminals which could create a spark. Avoid spilling electrolyte on hands or clothing.

b. To inspect and adjust the battery clamp, proceed as follows:

- (1) Loosen locknut and place clamp handle up or at right angle to battery terminal.






Figure 27—Continued.

(2) Remove clamps from battery terminals; inspect clamps for loose or corroded condition. Remove corrosion and coat battery terminals and clamps with grease.

(3) Install clamps on battery terminals. Tighten bushing nut to fit between lug and battery terminal.
 (4) Tighten locknut and push clamp until parallel with terminal.


Section IX. AIRBRAKE SYSTEM

60. General

The airbrake system has two filters to re-

61. Air System Service

a. Service the air filters as instructed.



A



NOTE: DRAIN ACCUMULATED MOISTURE FROM TANK.

B

62. General

The engine clutch assembly engages and disengages the power from the diesel engine to the main drive belts of the crusher.

63. Engine Clutch Assembly

Adjust the engine clutch
struted on figure 29.

REMOVE PLATE

ROCKFORD

POWER TAKE-OFF

REMOVE SCREW 2

MODEL

PTA-114130-D




SERIAL NO

CLUTCH ADJUSTMENT: REMOVE COVER AND RELEASE CLUTCH ADJUSTMENT LOCK. TURN ADJUSTING RING CLOCKWISE UNTIL A FIRM FEELING IS OBSERVED TO ENGAGE CLUTCH RE-ENGAGE LOCK.

LUBRICATION: CLUTCH THROWOUT BEARING DAILY. SHAFT BEARINGS EVERY 30 HOURS OF OPERATION.

FOR GEAR REDUCTION TYPE ON S.A.E. 30 OIL ON GEAR BOX. KEEP FILLED TO OIL LEVEL.

NOTE: ROTATE CLUTCH ASSEMBLY UNTIL THE ADJUSTMENT LOCK IS IN AN ACCESSIBLE POSITION



REMOVE CASSETT

sists of a smooth roll and a grooved roll for crushing stone. It has a spring on each side to allow the smooth roll to move beyond its adjusted clearance to allow tramp iron and other items to pass through the rolls that would otherwise damage the crusher rolls. An adjusting screw, located on each side to adjust the clearance between the crusher rolls, aids in obtaining the desired grade of aggregate.

for the O-rings will be changed. In some cases it may require several hours of operation before the O-ring seat properly against the seal plate and the oil stops leaking. A leak of 2 to 3 quarts of oil in 8 hours is not considered excessive (gearcase capacity is 50 qt) compared to the cost of replacing the O-rings. Furthermore, the O-rings are not designed as a positive-type seal but are designed to allow seepage which will lubricate the O-rings and prevent dust from entering the gearcase. The oil level of the gearcase should be checked each day. Refer to LO 5-3820-205-20/1-1.




Figure 80. Crusher rolls, adjustment.

General

The vibrating screen is driven by an electric motor. Power is transmitted to the vibrating screen, from the electric motor, by two V-belts. The vibrator screens determine the grades of aggregate desired. When the vibrator screens are changed, the crusher roll clearance must be adjusted (par. 67) to the size of the largest screen opening used.


67. Vibrating Screen Drive Belts Adjustment

Adjust the vibrating screen drive belts as instructed on figure 31.


68. Vibrating Screens Replacement

Replace the vibrating screens with the proper sized screens to obtain the desired grades of aggregate in the numerical sequence as instructed on figure 32.


Note. Muffler and plate removal is only necessary when lower screen is to be removed.



A




B



MSC 3020-205-10/1/32



A—Upper screen removal

Figure 32. Vibrating screens, replacement.



B—Muffler removal

Figure 32—Continued.




an electric motor. Power is transmitted from the electric motor to the feeder by two V-belts. on figure 33.



REMOVE NUT (4).

REMOVE BELT GUARD.



NOTE: ADJUST MAIN (FEED) CONVEYOR
DRIVE BELTS IN A SIMILAR MANNER.

LOOSEN NUT (2).

MOVE TURNBUCKLE
CLOCKWISE TO LOOSEN;
COUNTERCLOCKWISE TO
TIGHTEN BELTS.

NOTE: TIGHTEN THE DRIVE BELTS TO $\frac{3}{4}$
INCH DEFLECTION UNDER NORMAL
THUMB PRESSURE AT A POINT MIDWAY
BETWEEN THE SHEAVES. TIGHTEN THE
NUT (2).

regate being discharged by the return conveyor onto the main conveyor. It is driven by an electric motor. Power is transmitted from the electric motor to the rotary elevator by two V-belts.

72. Rotary Elevator Drive Belts Adjustment

a. Remove the belt guard on the rotary eleva-

tor. Adjust the rotary elevator drive belts as instructed on figure 34.

c. Install the rotary elevator drive belt guard in the same manner as the feeder drive belt guard (par. 71).




Figure 34. Rotary elevator drive belts, adjustment.

crusher aggregate being discharged by the crusher rolls into the roll elevator. It is driven by an electric motor. Power is transmitted from the electric motor to the return (under) conveyor by two V-belts.

a. Remove the return (under) conveyor belt guard from the unit as instructed on figure 36.

b. Adjust the return (under) conveyor drive belts in the same manner as the feeder drive belts (par. 71).

c. Install the return (under) conveyor drive belt guard on the unit in reverse of the instructions on figure 36.




Figure 35. Return (under) conveyor drive belt guard, removal and installation.

5. General

The main (feed) conveyor assembly conveys aggregate from the feeder hopper and roll elevator to the vibrator screen assembly. The main (feed) conveyor is driven by an electric motor. Power is transmitted from the electric motor to the main (feed) conveyor by two V-belts.

76. Main (Feed) Conveyor Drive Belt Adjustment

- Remove the main (feed) conveyor drive belt guard from the unit as instructed on figure 36.
- Adjust the main (feed) conveyor drive belts in the same manner as the feeder drive belts (par. 71).
- Install the main (feed) conveyor drive belt guard on the unit in reverse of the instructions on figure 36.




Figure 36. Main (feed) conveyor drive belt guard, removal and installation.

CHAPTER 4

DEMOLITION OF THE ROLL CRUSHER TO PREVENT ENEMY USE IN CONJUNCTION WITH THE ROLL CRUSHER

77. General

When capture or abandonment of the roll crusher to an enemy is imminent, the responsible unit commander must make the decision either to destroy the equipment or to render it inoperative. Based on this decision, orders are issued which cover the desired extent of destruction. Whatever method of demolition is employed, it is essential to destroy the same vital parts of all roll crushers and all corresponding repair parts.

78. Demolition To Render the Roll Crusher Inoperative

a. *Demolition by Mechanical Means.* Use sledge hammers, crowbars, picks, axes, or any other heavy tools which may be available to destroy the following:

- (1) Engine block and manifolds.
- (2) Engine governor, fuel pump, and water pump.
- (3) Electric motors.
- (4) Electric cables and wiring.
- (5) Conveyor belts.
- (6) The radiator and clutch housing.
- (7) The electrical control boxes (open doors and smash inner components).
- (8) Gearboxes.

Note. The above steps are the minimum requirements for this method.

b. *Demolition by Misuse.* Perform the following steps to render the roll crusher inoperative.

- (1) Drain the radiator and engine crankcase. Pour sand in the engine crank-

79. Demolition by Explosives or Weapons Fire

a. *Explosives.* Place as many of the following charges shown in figure 37 as the situation permits and detonate them simultaneously with detonating cord and suitable detonator.

- (1) One ½-pound charge on each cylinder head.
- (2) One ½-pound charge between injection pump and engine block.
Note. The above charges are the minimum requirements for this method.
- (3) One ½-pound charge on main (feed) conveyor motor.
- (4) One ½-pound charge on vibrating screen vibrator.
- (5) One ½-pound charge on rotary elevator motor.
- (6) One ½-pound charge on feeder motor.
- (7) One ½-pound charge on return (under) conveyor motor.
- (8) One ½-pound charge on the vibrating screen motor.
- (9) One 1-pound charge on clutch housing.
- (10) Six ½-pound charges between crusher rolls.
- (11) Two ½-pound charges inside rotary elevator wheel.

b. *Weapons Fire.* Fire on the roll crusher with the heaviest practical weapons available.

80. Other Demolition Methods

a. *Scattering and Concealment.* Remove as easily accessible parts such as injection pump

ONE ½ POUND CHARGE ON
MAIN (FEED) CONVEYOR MOTOR

ONE ½ POUND CHARGE ON
VIBRATING SCREEN VIBRATOR

ONE ½ POUND CHARGE ON
EACH CYLINDER HEAD (C)

ONE ½ POUND CHARGE ON
DRY ELEVATOR MOTOR

ONE ½ POUND CHARGE ON
MOTOR

ONE ½ POUND CHARGE ON
RETURN (UNDER)
CONVEYOR MOTOR

ONE ½ POUND CHARGE ON
VIBRATING SCREEN MOTOR

ONE ½ POUND CHARGE BETWEEN
FUEL INJECTION PUMP
AND ENGINE BLOCK

ONE ½ POUND CHARGE

EMC 2020 205 10/1/10

er and around, the conveyor belts, tires, electric motors, fuel tank, and engine. Saturate packing with gasoline, oil, or diesel fuel ignite.

Submersion. Totally submerge the roll over, if possible, in a body of water to produce water damage and concealment. Salt water damage metal parts more than fresh water.

Training

All operators should receive thorough train-

ing to FM 5-28. Simulated destruction, using all of the methods listed above, should be included in the operator training program. It must be emphasized in training, that demolition operations are usually necessitated by critical situations when time available for carrying out destruction is limited. For this reason, it is necessary that operators be thoroughly familiar with all methods of destruction of equipment and be able to carry out demolition instructions without reference to this or any other manual.

1. Dictionaries of Terms and Abbreviations

AR 320-5 Dictionary of United States Army Terms.
AR 320-50 Authorized Abbreviations and Brevity Codes.

2. Fire Protection

TM 5-687 Repairs and Utilities: Fire Protection Equipment and Appliances; Inspections, Operations, and Preventive Maintenance.
TM 9-1799 Ordnance Maintenance: Fire Extinguishers.

3. Lubrication

LO 5-3820-205-20/1-1 Lubrication Order.

4. Painting

TM 9-1213 Painting Instructions for Field Use.

5. Preventive Maintenance

AR 750-5 Maintenance Responsibilities and Shop Operation.
TM 9-1870-1 Care and Maintenance of Pneumatic Tires,
TM 9-6140-200-15 Storage Batteries, Lead-Acid Type.
TM 38-750 The Army Equipment Records System and Procedures.

6. Publication Indexes

DA Pam 310-4 Index of Technical Manuals, Technical Bulletins, Supply Manuals (types 4, 6, 7, 8, and 9), Supply Bulletins, Lubrication Orders, and Modification Orders.

7. Training Aids

FM 5-25 Explosives and Demolitions.
FM 21-5 Military Training.
FM 21-6 Techniques of Military Instruction.
FM 21-30 Military Symbols.

8. Supply Publications

SM 10 C9100-SL Petroleum, Petroleum-Base Products, and Related Material.
SM 3-C6800-ML List of Standard Lubricants, Hydraulic Fluids, Liquid Fuels, and Preservative Material Used by the Army.

APPENDIX II

BASIC ISSUE ITEMS LIST AND MAINTENANCE AND OPERATING SUPPLIES

Section I. INTRODUCTION

1. General

Section II lists the accessories, tools, and publications required in 1st echelon maintenance and operation, initially issued with, or authorized for the roll crusher. Section III lists the maintenance and operating supplies required for initial operation.

2. Explanation of Columns Contained in Section II

a. Source Codes. The information provided each column is as follows:

- (1) *Materiel.* This column lists the basic materiel code number of the supply service assigned responsibility for the part. Blank spaces denote supply responsibility of the preparing agency. Other basic materiel code numbers are—

- 3—Chemical Materiel
- 9—Ordnance Materiel
- 10—Quartermaster Materiel
- 12—Adjutant General

- (2) *Source.* The selection status and source of supply for each part are indicated by one of the following code symbols:

- (a) P—applied to high-mortality repair parts which are stocked in or supplied from the supply service depot system, and authorized for use at indicated maintenance echelons.

- (b) Pi—applied to repair parts which are stocked in

stall, or manufacture the part is indicated by the following code symbol

O—Organizational Maintenance
(1st and 2d Echelon)

b. Federal Stock Numbers. The Federal stock number will be shown in this column, and will be used for requisitioning purposes

c. Description.


- (1) The item name and a brief description of the part are shown.
- (2) A five-digit Federal supply code for manufacturers and/or other supply services is shown in parentheses followed by the manufacturer's part number. This number shall be used for requisitioning purposes when no Federal stock number is indicated in the Federal stock number column.
- Example:* (90129) X861784.

d. Unit of Issue. If no abbreviation is shown in this column, the unit of issue is "each".

e. Quantity Authorized. This column lists the quantities of repair parts, accessories, tools, or publications authorized for issue to the equipment operator or crew as required.

f. Quantity Issued with Equipment. This column lists the quantities of repair parts, accessories, tools, or publications that are initially issued with each item of equipment. Those indicated by an asterisk are to be requisitioned through normal supply channels as required.

g. Illustrations. This column is subdivided into two columns which provide the following information.



| | | | | | |
|---|----------------------|----|---------------------|----|-----------------------|
| 4 | Hand grease gun | 13 | Hand oiler | 21 | Adjustable wrench |
| 5 | Wire screen | 14 | Hand hydraulic jack | 22 | Block chock assembly |
| 6 | Ground rod assembly | 15 | Service hose | 23 | Handcrank, cable reel |
| 7 | Trestle | 16 | Feeder power cable | 24 | Handcrank, starting |
| 8 | Wheel bearing wrench | 17 | Deep style socket | 25 | Hand hammer |
| 9 | Wiring harness | | | | |

Figure 38.—Continued

3. Federal Supply Code for Manufacturers

| | |
|-------|--|
| 14351 | Continental Motors Corp. |
| 92858 | Hannay, Clifford B. & Son, Inc. |
| 00000 | Ordnance Corps |
| 18990 | Eagle Crusher Co. |
| 63477 | Wagner Electric Corp. |
| 90129 | Joy Manufacturer Co. Electric Products |
| 55719 | Snap-on Tool Corp. Div. |

4. Explanation of Columns Contained in Section III

a. Item. This column contains numerical sequenced item numbers, assigned to each component application, to facilitate reference.

b. Component Application. This column identifies the component application of each maintenance or operating supply item.

c. Source of Supply. This column lists the basic materiel code number of the supply service assigned responsibility for the item. Blank spaces denote supply responsibility of the preparing agency. Other basic materiel code numbers are—

9—Ordnance Materiel

10—Quartermaster Materiel

11—Signal Materiel

12—Adjutant General

55—Transportation Materiel

d. Federal Stock Number. The Federal stock number will be shown in this column and will be used for requisitioning purposes.

e. Description. The item and a brief description are shown.

f. Quantity Required for Initial Operation. This column lists the quantity of each maintenance or operation supply item required for initial operation of the equipment.

g. Quantity Required for 8 Hours Operation. Quantities listed represent the estimated requirements for an average 8 hours of operation.

h. Notes. This column contains informative notes keyed to data appearing in the preceding column.

GROUP 31--BASIC ISSUE ITEMS
MANUFACTURER INSTALLED

3100--BASIC ISSUE ITEMS, MANU-
FACTURER OR DEPOT INSTALLED

| | | | | | | | | |
|--|--|--|---------------|---|-----|---|---|----|
| | | | 5140-057-2554 | BATTERY, STORAGE: 12 v, 6 cell (Repair Parts Manual Group 0612). | | 4 | 4 | |
| | | | | BLOCK, CHOCK ASSEMBLY: w/ chain (00000) 8343584 (Repair Parts Manual Group 3100). | | 4 | 4 | 38 |
| | | | | CABLE, POWER: pigtail (90129) X861724 (Repair Parts Manual Group 2202). | | 1 | 1 | 38 |
| | | | | CABLE, POWER: 100 feet long (90129) X8617-25 (Repair Parts Manual Group 2202). | | 1 | 1 | 38 |
| | | | | CABLE, FEEDER POWER: 75 feet long (18990) 20610. | | 1 | 1 | 38 |
| | | | 7520-559-9618 | CASE: operation and maintenance pub- lications, cotton duck, water repellent and mildew resistant. | | 1 | 1 | |
| | | | | CRANK, HAND: cable reel (29858) H- 10616 A-32 (Repair Parts Manual Group 1808). | | 1 | 1 | 38 |
| | | | | CRANK, HAND: starting (14351) 31- R02020 (Repair Parts Manual Group 0107). | | 1 | 1 | 38 |
| | | | | DEPARTMENT OF THE ARMY LUBRICATION ORDER LO 5- 3820-205-20/1-1. | | 1 | 1 | |
| | | | | DEPARTMENT OF THE ARMY OPERATOR'S MANUAL TM 5- 3820-205-10/1. | | 2 | 2 | |
| | | | | DEPARTMENT OF THE ARMY ORGANIZATIONAL MAINTEN- ANCE MANUAL TM 5-3820- 205-20/1. | | 2 | 2 | |
| | | | | DEPARTMENT OF THE ARMY ORGANIZATIONAL MAINTEN- ANCE REPAIR PARTS AND SPECIAL TOOL LIST TM 5-3820- 205-20F/1. | | 2 | 2 | |
| | | | 6810-249-9354 | ELECTROLYTE, SULPHURIC ACID (Repair Parts Manual Group 0612). | Gal | 8 | 8 | |
| | | | 4210-383-7129 | EXTINGUISHER, FIRE, CARBON DIOXIDE: charged, hand; nonshat- terable cylinder; permanent shutoff valve; squeeze-grip or trigger control; 5-lb MIL Spec E-468, type I, class 1 (Repair Parts Manual Group 7603). | | 1 | 1 | |
| | | | | HARNESS, WIRING: trailer coupling (00000) 7728815 (Repair Parts Man- ual Group 2202). | | 1 | 1 | 38 |

| Source codes | | | | Federal stock No. | Description | Unit of issue | Expendability | Quantity authorized | Quantity issued with equipment | F |
|--------------|--------|-------------|----------------|-------------------|---|---------------|---------------|---------------------|--------------------------------|---|
| Material | Source | Maintenance | Recoverability | | | | | | | |
| | P | O | | | HOSE, SERVICE: (63477) AD2611 (Repair Parts Manual Group 2202). | | | 1 | 1 | |
| | P | O | | | PAD, JACK (18990) 20310 (Repair Parts Manual Group 3100). | | | 4 | 4 | |
| | P | O | | | ROD ASSEMBLY, GROUND: (18990) 30162 (Repair Parts Manual Group 3100). | | | 3 | 3 | |
| | P | O | | 3820-730-5039 | SCREEN, ROLLER: ¼ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5038 | SCREEN, ROLLER: ¾ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5037 | SCREEN, ROLLER: ½ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5036 | SCREEN, ROLLER: ¾ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5035 | SCREEN, ROLLER: 1 in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5034 | SCREEN, ROLLER: 1½ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5033 | SCREEN, ROLLER: 2 in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | P | O | | 3820-730-5032 | SCREEN, ROLLER: 2½ in. mesh (Repair Parts Manual Group 7528). | | | 2 | 2 | |
| | | | | | GROUP 32—BASIC ISSUE ITEMS TROOP INSTALLED | | | | | |
| | | | | | 3200—BASIC ISSUE ITEMS TROOP INSTALLED OR AUTHORIZED | | | | | |
| 10 | P | O | | 5120-277-8079 | EXTENSION, SOCKET WRENCH: 16 in., ¾ in. square drive. | | | 1 | * | |
| 9 | P | O | | 4910-273-3662 | GAGE, TIRE PRESSURE: calibrations 10- to 160-lb range. | | | 1 | * | |
| 10 | P | O | | 4930-360-2801 | GREASE GUN, HAND: lever operated, 16-oz capacity. | | | 1 | * | |
| 10 | P | O | | 5120-243-2063 | HAMMER, HAND: machinist, ball-peen, ½-lb head. | | | 1 | * | |
| 10 | P | O | | 5120-240-5368 | HANDLE, SOCKET WRENCH: 18½ in., ¾ in. sq drive. | | | 1 | * | |
| 10 | P | O | | 5120-244-7329 | JACK, HYDRAULIC, HAND: self contained, single pump, w/screw extension FED GGG-J-51, type VII, class 2, style B, 5-ton capacity. | | | 1 | * | |
| 10 | P | O | | 4930-260-9166 | OILER, HAND: 16-oz capacity | | | 1 | * | |
| 10 | P | O | | 5120-223-7396 | PLIERS, SLIP JOINT: straight nose, | | | 1 | * | |

| SP. No. | Part No. | Mfg. or Name | Re- covery ability | Federal stock No. | Description | Unit of issue | Ex- pend- ability | Qty au- thor- ized | Qty issued with equip- ment | Fig- ure | Item |
|---------|----------|-----------------|--------------------------|-------------------|---|------------------|-------------------------|-----------------------------|---|-------------|------|
| 1 | P | 0 | | 4910-262-0392 | TRESTLE, MOTOR VEHICLE MAINTENANCE: 5 ton capacity, adjustable type 15 in. closed h, 25 in. extended h, 12 in. lg o/a 10 in. w o/a base; MIL SPEC T-14521 size 5 ton. | | | 1 | * | 38 | 7 |
| 1 | P | 0 | | 5120-240-5328 | WRENCH, OPEN END, ADJUSTA- BLE: opening 0 to 0.947, 8 in. long. | | | 1 | * | 38 | 21 |
| 1 | P | 0 | | 5120-240-1414 | WRENCH, OPEN END, ADJUSTA- BLE: single-head type, 18 in. FED GG-631, type 1. | | | 1 | * | 38 | 21 |
| 1 | P | 0 | | 5120-277-6470 | WRENCH, OPEN END, ADJUSTA- BLE: single-head type, 36 in. | | | 1 | * | 38 | 21 |
| 1 | P | 0 | | 5120-393-0560 | WRENCH WHEEL BEARING | | | 1 | * | 38 | 8 |

Section III. MAINTENANCE AND OPERATING SUPPLIES

| Component application | Source of supply | Federal stock No. | Description | Quantity required for initial operation | Quantity required for 8 hours operation | Notes |
|---|------------------|-------------------|--|---|---|--|
| CRANKCASE | 10 | 9150-265-9436(2) | OIL, LUBRICATING: 55-gal drum as follows: OE 30 OE 10 OES FUEL OIL, DIESEL: bulk as follows: DF-A DF-1 DF-2 CAPSULE, METAL: pressure primed (1 MO-10) WATER: ANTIFREEZE: 55-gal drums as follows: Ethylene Glycol Compound Arctic OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING, GEAR: 55-gal drums as follows: GO 140 GO 90 GOS GREASE, AUTOMOTIVE AND ARTILLERY: 35-lb pail GAA | 24 qt | (3) | (1) Includes quantity of engine oil system |
| | 10 | 9150-265-9429(2) | | 24 qt | (3) | Crankcase—18 qt |
| | 10 | 9150-242-7604(2) | | 24 qt | (3) | Oil Filter—6 qts |
| | 10 | 9140-286-5283(2) | | 100 gal (5) | 76 gal (6) | (2) See SM 10 C9100 for additional data and procedure. |
| ENGINE STARTING AIDS | 10 | 9140-286-5286(2) | | 100 gal (5) | 76 gal (6) | (3) See LO 5-3820-1 for grade applicability |
| | 10 | 9140-286-5294(2) | | 100 gal (5) | 76 gal (6) | plenishment interval |
| | 10 | 2990-355-6377 | | 1 (8) | | (4) Use oil as prescribed |
| | 10 | | | 70 qt | (7) | (5) Tank capacity. |
| RADIATOR | 9 | 6850-293-1990 | OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING: (4) OIL, LUBRICATING, GEAR: 55-gal drums as follows: GO 140 GO 90 GOS GREASE, AUTOMOTIVE AND ARTILLERY: 35-lb pail GAA | 5 qt | (3) | (6) Average fuel consumption 9.5 gal per hour operation. |
| | 9 | 6850-174-1806 | | 4 qt | (3) | (7) Refer to organization for quantities, temperatures, specifications and replenishment |
| | 10 | 9150-577-5848 | | 2 qt | (3) | (8) Quantity indicated for minimum required for start when temperature below 40° F. |
| | 10 | 9150-577-5845 | | 2 qt | (3) | |
| GEAR ASSEMBLY, GEAR DRIVE, CRUSHER FRAMES | 10 | 9150-257-5442 | | 4-lb | 1-lb | |
| | 10 | 9150-577-5848 | | 92 qt | (3) | |
| | 10 | 9150-577-5845 | | 92 qt | (3) | |
| | 10 | 9150-257-5442 | | 92 qt | (3) | |
| GEAR POINTS | 10 | 9150-190-0907 | GAA | 4-lb | 1-lb | |

INDEX

| | Paragraph | Page | | Paragraph | Page |
|---|-----------|------|--|-----------|------|
| Adjustments: | | | Fire extinguisher | | |
| Crusher rolls adjustment..... | 65 | 72 | (carbon dioxide type)..... | | |
| Engine clutch assembly adjustment..... | 63 | 70 | Fuel system: | | |
| Fan belts adjustment..... | 57 | 64 | Air cleaner service..... | | |
| Feeder drive belts adjustment..... | 70 | 78 | Bleeding the fuel system..... | | |
| Main (feed) conveyor drive belts adjustment..... | 76 | 83 | Fuel tank and strainer service..... | | |
| Return (under) conveyor drive belts adjustment..... | 74 | 82 | General..... | | |
| Rotary elevator drive belt adjustment..... | 72 | 81 | Primary and secondary fuel filters service..... | | |
| Vibrating screen drive belts adjustment..... | 68 | 73 | Troubleshooting..... | | |
| Air brake system: | | | Identification and tabulated data..... | | |
| Air system service..... | 61 | 68 | Lubrication: | | |
| General..... | 60 | 68 | Detailed lubrication information..... | | |
| Cold weather starting aid..... | 22 | 36 | General lubrication information..... | | |
| Controls and instruments: | | | Troubleshooting..... | | |
| Controls and instruments..... | 11 | 20 | Main (feed) conveyor assembly: | | |
| General..... | 10 | 20 | General..... | | |
| Cooling system: | | | Main (feed) conveyor drive belts adjustment..... | | |
| Fan belts adjustment..... | 57 | 64 | Troubleshooting..... | | |
| General..... | 55 | 64 | Operating details..... | | |
| Radiator service..... | 56 | 64 | Operation in dusty or sandy areas..... | | |
| Troubleshooting..... | 34 | 56 | Operation in extreme heat..... | | |
| Demolition of the roll crusher to prevent enemy use: | | | Operation in salt water areas..... | | |
| Demolition by explosives or weapons fire..... | 79 | 84 | Operation under rainy or humid condition..... | | |
| Demolition to render the roll crusher inoperative..... | 78 | 84 | Operation of auxiliary material used in conjunction with the roll crusher: | | |
| General..... | 77 | 84 | Cold weather starting aid..... | | |
| Other demolition methods..... | 80 | 84 | Fire extinguisher (carbon dioxide type)..... | | |
| Training..... | 81 | 87 | Operation of equipment: | | |
| Description..... | 8 | 2 | General..... | | |
| Detailed lubrication information..... | 27 | 38 | Operating details..... | | |
| Difference in models..... | 5 | 7 | Operation at high altitude..... | | |
| Engine clutch assembly: | | | Operation in dusty or sandy areas..... | | |
| Engine clutch assembly adjustment..... | 63 | 70 | Operation in extreme cold (below 0° F.)..... | | |
| General..... | 62 | 70 | Operation in extreme heat..... | | |
| Engine electrical system: | | | Operation in saltwater areas..... | | |
| Batteries service..... | 59 | 67 | Operation under rainy or humid conditions..... | | |
| General..... | 58 | 67 | Starting the engine..... | | |
| Feeder assembly: | | | Stopping the engine..... | | |
| Feeder drive belts adjustment..... | 70 | 78 | | | |
| General..... | | | | | |

| | | | | |
|--|----|----|---|--------|
| Return (under) conveyor drive belts adjustment | 74 | 82 | Cooling system | 34 |
| Roll crusher assembly | | | Electrical system | 43, 44 |
| Crusher rolls adjustment | 65 | 72 | Engine assembly | 31-33 |
| General | 64 | 72 | Feeder assembly | 41 |
| Troubleshooting | 38 | 57 | Fuel system | 36 |
| Rotary elevator assembly | | | General | 30 |
| General | 71 | 81 | Lubrication | 35 |
| Rotary elevator drive belt adjustment | 72 | 81 | Main (feed) conveyor assembly | 37 |
| Troubleshooting | 42 | 57 | Roll crusher assembly | 38 |
| | | | Rotary elevator assembly | 42 |
| | | | Vibrating screen assembly | 39, 40 |
| Unloading | 1 | 2 | Vibrating screen assembly: | |
| Service upon receipt of equipment | | | General | 66 |
| Inspecting and servicing the roll crusher | 7 | 8 | Troubleshooting | 39, 40 |
| Installation or setting-up instructions | 8 | 8 | Vibrating screen drive belts adjustment | 67 |
| Movement to a new work site | 9 | 12 | Vibrating screens adjustment | 68 |
| Unloading the roll crusher | 6 | 8 | | |

EARLE G. WHEEL
General, United States
Chief of Staff.

Official:

J. C. LAMBERT,
Major General, United States Army,
The Adjutant General.

Distribution:

Active Army:

USASA (2)
ACSI (1)
DCSLOG (1)
CNGB (1)
TSG (1)
CofEngrs (3)
CSigO (1)
CofT (1)
CofSptS (1)
Army Maint Bd (1)
USAARTYBD (2)
USAARMBD (2)
USAARMBD (2)
USAIB (2)
USAAEDB (2)
USAAESWBD (2)
USAAVNBD (2)
USCONARC (3)
OS Maj Comd (5) except
USASETAF (2)
USARJ (10)
USAMOCOM (2)
USASMCOM (1)
MDW (1)
Armies (2)
Corps (2)
Div (2)
Engr Bde (1)
Svc Colleges (2)
Br Svc Sch (2) except
USAES (100)
USMA (2)
GENDEP (OS) (10)

Engr Dep (OS) (10)
Army Dep (2)
USA Trans Tml Comd (2)
Army Tml (1)
USAOSA (2)
Div Engr (2)
Engr Dist (2)
USAERDL (3)
USA Mbl Spt Cen (36)
ENGR Cen (5)
ESCO (10)
Fld Comd, DASA (8)
AMS (3)
Engr Fld Maint Shops (2)
USAREUR Engr Proc Cen (2)
USAREUR Engr Sup Con Agcy (10)
Chicago Proc Ofc (10)
USAREURCOMZ (2)
USA Corps (1)
MAAG (1)
JBUSMC (1)
Units org under fol TOE:
5-48 (2)
5-114 (2)
5-115 (2)
5-117 (2)
5-237 (5)
5-262 (5)
5-267 (1)
5-278 (5)
5-279 (2)
5-500 (EA, EB, GB) (2)

NG: None.

USAR: Same as Active Army except allowance is one copy to each unit.
For explanation of abbreviations used, see AR 320-50.